VD2EDDT:

Rpc: 9454578783 Rpm:#956987217



D

Е

F

G

Н

J

K

M

Ν

0

Ρ

# **CONTENTS**

IDZJUDII	Inicator Adicator ant Value D
SERVICE INFORMATION6	Injector Adjustment Value R Fuel Pump Learning Value ( EGR Volume Control Valve
MODIFICATION NOTICE	Learning Value Clear EGR Volume Control Valve
<b>INDEX FOR DTC7</b> U1000	Learning FUEL PUMP
P0016 - P0123       7         P0182 - P0217       7         P0222 - P0488       8         P0563 - P0686       8         P1268 - P1275       9         P1610 - P1616       9         P1622 - P2229       9	ON BOARD DIAGNOSTIC Introduction Three Trip Detection Logic ation Logic Emission-Related Diagnostin NATS (Nissan Anti-Theft Symalfunction Indicator (MI)
PRECAUTIONS	OBD System Operation Cha  TROUBLE DIAGNOSIS  Trouble Diagnosis Introducti
	DTC Inspection Priority Cha Basic Inspection Symptom Matrix Chart Engine Control Component
PREPARATION         15           Special Service Tool         15           Commercial Service Tool         16	Circuit Diagram ECM Harness Connector Te ECM Terminal and Reference CONSULT-III Function (ENG
ENGINE CONTROL SYSTEM         17           Schematic         17           System Chart         18	Generic Scan Tool (GST) For CONSULT-III Reference Va
Fuel Injection Control System	TROUBLE DIAGNOSIS FO INCIDENT  Description  Diagnosis Procedure
Crankcase Ventilation System	POWER SUPPLY AND GR Wiring Diagram
BASIC SERVICE PROCEDURE22	Diagnosis Procedure Component Inspection

Procedure After Replacing ECM	2 23 24 24
ON BOARD DIAGNOSTIC (OBD) SYSTEM3	2
Introduction	
Three Trip Detection Logic and One Trip Detec-	
tion Logic	
Emission-Related Diagnostic Information3	
NATS (Nissan Anti-Theft System)3	
Malfunction Indicator (MI)	6
OBD System Operation Chart	
TROUBLE DIAGNOSIS4	1
Trouble Diagnosis Introduction4	
DTC Inspection Priority Chart4	4
Basic Inspection4	
Symptom Matrix Chart4 Engine Control Component Parts Location5	8
Circuit Diagram5	
ECM Harness Connector Terminal Layout5	7
ECM Terminal and Reference Value5	
CONSULT-III Function (ENGINE)6	
Generic Scan Tool (GST) Function6	7
CONSULT-III Reference Value in Data Monitor	
Mode6	8
TROUBLE DIAGNOSIS FOR INTERMITTENT	
INCIDENT7	0
Description	
Description7 Diagnosis Procedure7	0
Diagnosis Procedure7	
POWER SUPPLY AND GROUND CIRCUIT7	1
POWER SUPPLY AND GROUND CIRCUIT7 Wiring Diagram	' <b>1</b> '1
POWER SUPPLY AND GROUND CIRCUIT7	' <b>1</b> '1 '8

Ground Inspection	81	Component Inspection	
DTC U1000 CAN COMMUNICATION LINE.	83	Removal and Installation	114
Description		DTC P0117, P0118 ECT SENSOR	115
On Board Diagnosis Logic		Description	
DTC Confirmation Procedure		On Board Diagnosis Logic	
Wiring Diagram		DTC Confirmation Procedure	
Diagnosis Procedure		Wiring Diagram	
		Diagnosis Procedure	
DTC P0016 CKP - CMP CORRELATION	85	Component Inspection	
On Board Diagnosis Logic		Removal and Installation	
DTC Confirmation Procedure	85		
Diagnosis Procedure	85	DTC P0122, P0123 APP SENSOR	119
DTC DOOGG FUEL SYSTEM	07	Description	119
DTC P0088 FUEL SYSTEM		CONSULT-III Reference Value in Data Monitor	
On Board Diagnosis Logic	87	Mode	
DTC Confirmation Procedure		On Board Diagnosis Logic	
Diagnosis Procedure		DTC Confirmation Procedure	
Removal and Installation	88	Wiring Diagram	
DTC P0089 FUEL PUMP	89	Diagnosis Procedure	
On Board Diagnosis Logic		Component Inspection	
DTC Confirmation Procedure		Removal and Installation	123
Diagnosis Procedure		DTC D0402 D0402 FUEL DUMP TEMPERA	
Removal and Installation		DTC P0182, P0183 FUEL PUMP TEMPERA-	
Nomoval and installation	50	TURE SENSOR	
DTC P0093 FUEL SYSTEM	91	Description	124
On Board Diagnosis Logic	91	CONSULT-III Reference Value in Data Monitor	
Overall Function Check	91	Mode	
Diagnosis Procedure	92	On Board Diagnosis Logic	
Component Inspection	92	DTC Confirmation Procedure	
Removal and Installation		Wiring Diagram	
		Diagnosis Procedure	
DTC P0101 MAF SENSOR		Removal and Installation	127
Component Description	94	DTC P0192, P0193 FRP SENSOR	128
CONSULT-III Reference Value in Data Monitor		Description	
Mode		CONSULT-III Reference Value in Data Monitor	120
On Board Diagnosis Logic		Mode	128
DTC Confirmation Procedure		On Board Diagnosis Logic	
Wiring Diagram		DTC Confirmation Procedure	
Diagnosis Procedure		Wiring Diagram	
Component Inspection		Diagnosis Procedure	
Removal and Installation	102	Component Inspection	
DTC P0102, P0103 MAF SENSOR	103	Removal and Installation	131
Component Description			
CONSULT-III Reference Value in Data Monitor	103	DTC P0200 FUEL INJECTOR	132
Mode	103	On Board Diagnosis Logic	132
On Board Diagnosis Logic		DTC Confirmation Procedure	132
DTC Confirmation Procedure		Diagnosis Procedure	132
Wiring Diagram		DTC D0004 D0004 FUEL IN IECTOR	400
Diagnosis Procedure		DTC P0201 - P0204 FUEL INJECTOR	
Component Inspection		Component Description	133
Removal and Installation	110	CONSULT-III Reference Value in Data Monitor	. =
Nomoval and installation	1 10	Mode	
DTC P0112, P0113 IAT SENSOR	111	On Board Diagnosis Logic	
Component Description		DTC Confirmation Procedure	
On Board Diagnosis Logic		Wiring Diagram	
DTC Confirmation Procedure		Diagnosis Procedure	
Wiring Diagram	112	Component Inspection	
http://www.com/probac	ากใส้ใก	Removal and Installation	. 137 I con

DTC P0217 ENGINE OVER TEMPERATURE	.138	Removal and Installation	172	•
Description	. 138	DTC P0380 GLOW RELAY	173	
Mode	120	On Board Diagnosis Logic	173	
		DTC Confirmation Procedure	173	
On Board Diagnosis Logic		Wiring Diagram	174	E
Overall Function Check		Diagnosis Procedure		
Wiring Diagram		Component Inspection		
Diagnosis Procedure		·		
Main 12 Causes of Overheating		DTC P0403 EGR SYSTEM	177	
Component Inspection	. 145	Description	177	
DTC P0222, P0223 APP SENSOR	. 147	CONSULT-III Reference Value in Data Monitor		
Description		Mode		
CONSULT-III Reference Value in Data Monitor		On Board Diagnosis Logic		
Mode	1/7	DTC Confirmation Procedure	178	
		Wiring Diagram	179	
On Board Diagnosis Logic	. 147	Diagnosis Procedure		
DTC Confirmation Procedure		Removal and Installation	183	
Wiring Diagram				
Diagnosis Procedure	. 149	DTC P0405, P0406 EGR SENSOR	184	
Component Inspection		Description	184	
Removal and Installation	. 151	CONSULT-III Reference Value in Data Monitor		
DTC D0225 CVD SENSOD	450	Mode	185	
DTC P0335 CKP SENSOR		On Board Diagnosis Logic	185	
Description	. 152	DTC Confirmation Procedure	185	
CONSULT-III Reference Value in Data Monitor		Wiring Diagram		
Mode		Diagnosis Procedure		
On Board Diagnosis Logic		Removal and Installation		
DTC Confirmation Procedure	. 152	Nemoval and matallation	109	
Wiring Diagram	. 153	DTC P0409 EGR SYSTEM	190	
Diagnosis Procedure	. 154	Description		
Component Inspection	. 156	CONSULT-III Reference Value in Data Monitor		
Removal and Installation	. 156	Mode	191	
		On Board Diagnosis Logic		
DTC P0336 CKP SENSOR	. 157	DTC Confirmation Procedure		
Description	. 157	Wiring Diagram		
CONSULT-III Reference Value in Data Monitor		Diagnosis Procedure	102	
Mode	. 157	Diagnosis Procedure  Removal and Installation	105	
On Board Diagnosis Logic	. 157	Removal and installation	195	
DTC Confirmation Procedure		DTC P0488 EGR SYSTEM	196	
Wiring Diagram		Description		
Diagnosis Procedure		CONSULT-III Reference Value in Data Monitor	130	
Component Inspection		Mode	107	
Removal and Installation	162	On Board Diagnosis Logic		
Nemoval and motaliation	. 102			
DTC P0340 CMP SENSOR	. 163	DTC Confirmation Procedure		
Description		Wiring Diagram		
On Board Diagnosis Logic		Diagnosis Procedure		
DTC Confirmation Procedure		Removal and Installation	200	
Wiring Diagram		DTC DOES? DATTEDY VOLTAGE	004	
		DTC P0563 BATTERY VOLTAGE		
Diagnosis Procedure		On Board Diagnosis Logic		
Component Inspection		DTC Confirmation Procedure		
Removal and Installation		Diagnosis Procedure	201	
DTC P0341 CMP SENSOR		DTC P0606 ECM		
Description		Description		
On Board Diagnosis Logic		On Board Diagnosis Logic		
DTC Confirmation Procedure		DTC Confirmation Procedure	203	
Wiring Diagram		Diagnosis Procedure	203	
Diagnosis Procedure	. 170	-		
hthomponeathaspactiadulae wix comfombade	122 ute	on DTGZP0628, POGRAD SUBSIDBH MBUHOS@gmail	L	<b>.</b>

Description	205	Description	239
CONSULT-III Reference Value in Data Monitor		CONSULT-III Reference Value in Data Monitor	
Mode		Mode	
On Board Diagnosis Logic		On Board Diagnosis Logic	
DTC Confirmation Procedure		DTC Confirmation Procedure	
Wiring Diagram		Wiring Diagram	
Diagnosis Procedure		Diagnosis Procedure	
Component Inspection		Component Inspection	
Removal and Installation	209	Removal and Installation	243
DTC P0642, P0643 SENSOR POWER SUP-		DTC P1274 FUEL PUMP	244
PLY		Description	244
On Board Diagnosis Logic	210	CONSULT-III Reference Value in Data Monitor	
DTC Confirmation Procedure		Mode	
Wiring Diagram	211	On Board Diagnosis Logic	244
Diagnosis Procedure		DTC Confirmation Procedure	
		Wiring Diagram	245
DTC P0652, P0653 SENSOR POWER SUP-		Diagnosis Procedure	
PLY	214	Component Inspection	247
On Board Diagnosis Logic	214	Removal and Installation	248
DTC Confirmation Procedure			
Wiring Diagram		DTC P1275 FUEL PUMP	249
Diagnosis Procedure		Description	249
Diagnosio i roccadio	210	CONSULT-III Reference Value in Data Monitor	
DTC P0668, P0669 ECM	218	Mode	249
Description		On Board Diagnosis Logic	
On Board Diagnosis Logic		DTC Confirmation Procedure	
DTC Confirmation Procedure		Wiring Diagram	
Diagnosis Procedure			
Diagnosis Frocedure	210	Diagnosis Procedure	
DTC P0686 ECM RELAY	220	Component Inspection	
On Board Diagnosis Logic		Removal and Installation	253
DTC Confirmation Procedure		DTC P1622 INJECTOR ADJUSTMENT VAL	_
Wiring Diagram		UE	
Diagnosis Procedure			
Component Inspection		Description	
Component inspection	220	On Board Diagnosis Logic	
DTC P1268 - P1271 FUEL INJECTOR	227	DTC Confirmation Procedure	
Component Description		Diagnosis Procedure	254
CONSULT-III Reference Value in Data Monitor		DTC P1623 INJECTOR ADJUSTMENT VAL	_
Mode	227		
On Board Diagnosis Logic		UE	
DTC Confirmation Procedure		Description	
		On Board Diagnosis Logic	
Wiring Diagram		DTC Confirmation Procedure	
Diagnosis Procedure		Diagnosis Procedure	255
Component Inspection		DTO DOLOG ADD OFNOOD	
Removal and Installation	233	DTC P2135 APP SENSOR	
DTC P1272 FUEL PUMP	22.4	Description	257
		CONSULT-III Reference Value in Data Monitor	
Description	234	Mode	
CONSULT-III Reference Value in Data Monitor		On Board Diagnosis Logic	257
Mode		DTC Confirmation Procedure	
On Board Diagnosis Logic		Wiring Diagram	
DTC Confirmation Procedure		Diagnosis Procedure	
Wiring Diagram	235	Component Inspection	
Diagnosis Procedure		Removal and Installation	
Component Inspection		Tomovar and motaliation	201
Removal and Installation		DTC P2146, P2149 FUEL INJECTOR POWER	₹
		SUPPLY	
DTC P1273 FUEL PUMP	239		
http://probadordemodulos.wix.com/probad	orauto	omothz <sup>enent De</sup> scription probadordemodulos@gmai	II:Ćďŕr

CONSULT-III Reference Value in Data Monitor	000
ModeOn Board Diagnosis Logic	
DTC Confirmation Procedure	
Wiring Diagram	
Diagnosis Procedure	
	. 200
DTC P2147, P2148 FUEL INJECTOR CIR-	
CUIT	
Component Description	. 266
CONSULT-III Reference Value in Data Monitor	
Mode	
On Board Diagnosis Logic	266
DTC Confirmation Procedure	
Wiring Diagram	. 267
Diagnosis Procedure	
Component Inspection	
Removal and Installation	. 270
DTC P2228, P2229 BARO SENSOR	. 271
Description	
On Board Diagnosis Logic	271
DTC Confirmation Procedure	
Diagnosis Procedure	. 271
GLOW CONTROL SYSTEM	273
Description	
Wiring Diagram	
Diagnosis Procedure	
Component Inspection	
Removal and Installation	
HEAT UP SWITCH	280
Description	
CONSULT-III Reference Value in Data Monitor	. 200
Mode	. 280
Wiring Diagram	

Diagnosis Procedure	282
Component Inspection	
DD AVE CWITCH	
BRAKE SWITCH	
Description CONSULT-III Reference Value in Data Monitor	
Mode	
Wiring Diagram	
Diagnosis Procedure	
Component Inspection	
PNP SWITCH	
Description	
CONSULT-III Reference Value in Data Monitor	
Mode	
Wiring Diagram Diagnosis Procedure	
Diagnosis Procedure	291
START SIGNAL	293
Wiring Diagram	293
Diagnosis Procedure	
MI & DATA LINK CONNECTORS	206
Wiring Diagram	
Willing Diagram	290
SERVICE DATA AND SPECIFICATIONS	
(SDS)	
General Specification	
Mass Air Flow Sensor	
Intake Air Temperature Sensor	
Engine Coolant Temperature Sensor	
Fuel Rail Pressure Sensor	
Fuel Injector Crankshaft Position Sensor	
Camshaft Position Sensor	
Glow Plug	
Fuel Pump	

Α

EC

С

D

Е

G

J

Κ

M

Ν

0

Ρ

# **MODIFICATION NOTICE**

< SERVICE INFORMATION > [YD25DDTi]

# **SERVICE INFORMATION**

# **MODIFICATION NOTICE**

Major Modification Item

INFOID:0000000003844114

• YD25DDTi (with common rail) engine has newly been added.

INFOID:0000000003759278

Α

EC

C

D

Е

F

G

Н

K

L

M

Ν

0

Ρ

# **INDEX FOR DTC**

U1000

DT	C* <sup>1</sup>	Items		
CONSULT-III GST* <sup>2</sup>	ECM*3	(CONSULT-III screen item)	Reference page	
U1000	1000*4	CAN COMM CIRCUIT	EC-83	

<sup>\*1: 1</sup>st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

P0016 - P0123

DTC\*<sup>1</sup>

DTC*1		ltems	
CONSULT-III GST* <sup>2</sup>	3 ECM*	(CONSULT-III screen item)	Reference page
P0016	0016	CMP/CKP RELATION	<u>EC-85</u>
P0088	0088	HIGH FUEL PRESS	EC-87
P0089	0089	FUEL PUMP	EC-89
P0093	0093	FUEL LEAK	<u>EC-91</u>
P0101	0101	MAF SENSOR	EC-94
P0102	0102	MAF SEN/CIRCUIT	EC-103
P0103	0103	MAF SEN/CIRCUIT	EC-103
P0112	0112	IAT SEN/CIRCUIT	EC-111
P0113	0113	IAT SEN/CIRCUIT	EC-111
P0117	0117	ECT SEN/CIRCUIT	EC-115
P0118	0118	ECT SEN/CIRCUIT	<u>EC-115</u>
P0122	0122	APP SEN 1/CIRCUIT	EC-119
P0123	0123	APP SEN 1/CIRCUIT	EC-119

<sup>\*1: 1</sup>st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

P0182 - P0217

INFOID:0000000003759280

רם	「C* <sup>1</sup>	Itama	
CONSULT-III GST* <sup>2</sup>	ECM* <sup>3</sup>	Items (CONSULT-III screen item)	Reference page
P0182	0182	FUEL TEMP SEN/CIRC	EC-124
P0183	0183	FUEL TEMP SEN/CIRC	EC-124
P0192	0192	FRP SEN/CIRC	EC-128
P0193	0193	FRP SEN/CIRC	EC-128
P0200	0200	INJECTOR	EC-132
P0201	0201	CYL1 INJECTOR	EC-133
P0202	0202	CYL2 INJECTOR	EC-133

http://probadordemodulos.wix.com/probadorautomotriz

<del>probadordemodulos@gmail.com</del>

<sup>\*2:</sup> This number is prescribed by ISO 15031-6.

<sup>\*3:</sup> In Diagnostic Test Mode II (Self-diagnostic results).

<sup>\*4:</sup> The troubleshooting for this DTC needs CONSULT-III.

<sup>\*2:</sup> This number is prescribed by ISO 15031-6.

<sup>\*3:</sup> In Diagnostic Test Mode II (Self-diagnostic results).

DT	·C*1	Items	
CONSULT-III GST* <sup>2</sup>	ECM* <sup>3</sup>	(CONSULT-III screen item)	Reference page
P0203	0203	CYL3 INJECTOR	EC-133
P0204	0204	CYL4 INJECTOR	EC-133
P0217	0217	ENG OVER TEMP	EC-138

<sup>\*1: 1</sup>st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

P0222 - P0488

INFOID:0000000003759281

DT	-C* <sup>1</sup>	Items	
CONSULT-III GST* <sup>2</sup>	ECM* <sup>3</sup>	(CONSULT-III screen item)	Reference page
P0222	0222	APP SEN 2/CIRCUIT	EC-147
P0223	0223	APP SEN 2/CIRCUIT	EC-147
P0335	0335	CKP SEN/CIRCUIT	EC-152
P0336	0336	CKP SENSOR	EC-157
P0340	0340	CMP SEN/CIRCUIT	<u>EC-163</u>
P0341	0341	CMP SENSOR	<u>EC-168</u>
P0380	0380	GLOW RELAY	<u>EC-173</u>
P0403	0403	EGR SYSTEM	EC-177
P0405	0405	EGR SENSOR	EC-184
P0406	0406	EGR SENSOR	EC-184
P0409	0409	EGR SYSTEM	EC-190
P0488	0488	EGR SYSTEM	<u>EC-196</u>

<sup>\*1: 1</sup>st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

P0563 - P0686

DTO	C*1	lt a man	
CONSULT-III GST* <sup>2</sup>	ECM* <sup>3</sup>	Items (CONSULT-III screen item)	Reference page
P0563	0563	BATTERY VOLTAGE	EC-201
P0606	0606	ECM	EC-203
P0628	0628	FUEL PUMP/CIRC	EC-205
P0629	0629	FUEL PUMP/CIRC	EC-205
P0642	0642	SENSOR PWR/CIRC1	EC-210
P0643	0643	SENSOR PWR/CIRC1	EC-210
P0652	0652	SENSOR PWR/CIRC2	EC-214
P0653	0653	SENSOR PWR/CIRC2	EC-214
P0668	0668	ECM	EC-218
P0669	0669	ECM	EC-218

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com probadordemodulos@gmail.com

<sup>\*2:</sup> This number is prescribed by ISO 15031-6.

<sup>\*3:</sup> In Diagnostic Test Mode II (Self-diagnostic results).

<sup>\*2:</sup> This number is prescribed by ISO 15031-6.

 $<sup>^{*}3</sup>$ : In Diagnostic Test Mode II (Self-diagnostic results).

INFOID:0000000003759287

EL-106

EL-106

Α

EC

D

Е

L

M

Ν

Ρ

\*1: 1st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

\*2: This number is prescribed by ISO 15031-6.

\*3: In Diagnostic Test Mode II (Self-diagnostic results).

P1268 - P1275 INFOID:0000000003759286

DTC*1		Items	
CONSULT-III GST* <sup>2</sup>	ECM* <sup>3</sup>	(CONSULT-III screen item)	Reference page
P1268	1268	INJECTOR 1	EC-227
P1269	1269	INJECTOR 2	EC-227
P1270	1270	INJECTOR 3	EC-227
P1271	1271	INJECTOR 4	EC-227
P1272	1272	FRP RELIEF VALVE	EC-234
P1273	1273	FUEL PUMP	EC-239
P1274	1274	FUEL PUMP	EC-244
P1275	1275	FUEL PUMP	EC-249

<sup>\*1: 1</sup>st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

P1610 - P1616

DTC\*1 Items Reference page CONSULT-III (CONSULT-III screen item) ECM\*3 GST\*2 P1610 1610 LOCK MODE EL-102 P1611 1611 ID DISCORD, IMM-ECM EL-103 P1612 CHAIN OF ECM-IMMU 1612 EL-103 P1614 1614 CHAIN OF IMMU-KEY EL-105

DIFFERENCE OF KEY

**ECM** 

1615

1616

# P1622

P1615

P1616

1622 - P2229	INFOID:0000000003759290
622 - P2229	INFOID:0000000003759290

DTC*1		Itama	
CONSULT-III GST* <sup>2</sup>	ECM* <sup>3</sup>	Items (CONSULT-III screen item)	Reference page
P1622	1622	INJ ADJ VAL UNRGST	EC-254
P1623	1623	INJ ADJ VAL ERROR	EC-255
P2135	2135	APP SENSOR	EC-257
P2146	2146	INJ PWR/CIRC	EC-262
P2147	2147	INJECTOR/CIRC	EC-266
P2148	2148	INJECTOR/CIRC	EC-266
P.2149 .	2149	INT PWR/CIRC	FG-262

ttp://probadordem\_dulos.wix.com/probadorautomotriz

probadord modulos@amail.com

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

<sup>\*2:</sup> This number is prescribed by ISO 15031-6.

<sup>\*3:</sup> In Diagnostic Test Mode II (Self-diagnostic results).

<sup>\*1: 1</sup>st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

<sup>\*2:</sup> This number is prescribed by ISO 15031-6.

<sup>\*3:</sup> In Diagnostic Test Mode II (Self-diagnostic results).

# **INDEX FOR DTC**

# < SERVICE INFORMATION >

[YD25DDTi]

DTC*1		Items	
CONSULT-III GST* <sup>2</sup>	ECM* <sup>3</sup>	(CONSULT-III screen item)	Reference page
P2228	2228	BARO SEN/CIRC	EC-271
P2229	2229	BARO SEN/CIRC	EC-271

<sup>\*1: 1</sup>st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

<sup>\*2:</sup> This number is prescribed by ISO 15031-6.

<sup>\*3:</sup> In Diagnostic Test Mode II (Self-diagnostic results).

INFOID:0000000003759292

# **PRECAUTIONS**

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" INFOID:0000000003761794


The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along v a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SUPPLEMENTAL RESTRAINT SYSTEM" and "SEAT BELTS" of this Service Manual.

### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SUPPLEMENTAL RESTRAINT SYSTEM".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

# Precaution for Procedure without Cowl Top Cover

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



# On Board Diagnosis (OBD) System of Engine

The ECM has an on board diagnostic system. It will light up the malfunction indicator (MI) to warn the driver of a malfunction causing emission deterioration.

### **CAUTION:**

- Be sure to turn the ignition switch OFF and disconnect the battery negative cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to "HARNESS CONNEC-TOR" in EL section.
- · Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to light up due to the short circuit.
- · Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MI to light up due to the malfunction of the fuel system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

EC

D

Е


Н

Ν


http://probadordemodulos.wix.com/probadorautomotriz

Precaution INFOID:0000000037559294

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect battery negative cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned OFF.
- Before removing parts, turn ignition switch OFF and then disconnect battery negative cable.




· Do not disassemble ECM.




MBIB0625E

 When connecting ECM harness connector, fasten it securely with levers as far as they will go as shown in the figure.



- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
  - Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Securely connect ECM harness connectors.
   A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to IC's.
- Keep engine control system harness at least 10cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of IC's, etc.
- Keep engine control system parts and harness dry.



Α

EC

D

Е

F

Н

K


M


Ν

0

Ρ


- Before replacing ECM, perform ECM Terminals and Reference Value inspection and make sure ECM functions properly. Refer to EC-57, "ECM Terminal and Reference Value".
- · Handle mass air flow sensor carefully to avoid damage.
- · Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Even a slight leak in the air intake system can cause serious incidents.
- Do not shock or jar the camshaft position sensor, crankshaft position sensor.
- After performing each TROUBLE DIAGNOSIS, perform DTC Confirmation Procedure or Overall Function Check.
   The DTC should not be displayed in the DTC Confirmation Procedure if the repair is completed. The Overall Function Check should be a good result if the repair is completed.






 When measuring ECM signals with a circuit tester, never allow the two tester probes to contact.
 Accidental contact of probes will cause a short circuit and

- damage the ECM power transistor.
  Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground
- Do not disassemble fuel pump.
   If NG, take proper action.
- Do not disassemble fuel injector.
   If NG, replace fuel injector.




http://probadordemodulos.wix.com/probadorautomotriz

- · Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarilv.
- · Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
- Keep the antenna as far as possible from the electronic control units.
- Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls.
   Do not let them run parallel for a long distance.
- Adjust the antenna and feeder line so that the standing-wave radio can be kept smaller.
- Be sure to ground the radio to vehicle body.



SEF708Y

# **PREPARATION**

# **Special Service Tool**

INFOID:0000000003759295

Α

EC

С

D

Е

G

Н

K


Tool number Tool name EG17650301 Radiator cap tester adapter


KV11106030 Positioning stopper pin


KV11106040 TORX wrench

KV11106050 Hexagonal wrench

KV11106060 Sprocket holder









Description

Adapting radiator cap tester to radiator cap and radiator filler neck

a: 28 (1.10) dia.

b: 31.4 (1.236) dia.

**c: 41.3 (1.626) dia.** Unit: mm (in)

Fixing fuel pump sprocket

a: 6 mm (0.24 in) dia.

b: 80 mm (3.15 in) dia.

Removing and installing fuel pump sprocket

a: T70

b: 26 mm (1.02 in)

Removing and installing fuel pump sprocket

a: 6 mm (0.24 in) (Face to face)

b: 42 mm (1.65 in)

Holding fuel pump sprocket

M

Ν

0


Р

# **Commercial Service Tool**

INFOID:0000000003759296

Tool name

Socket wrench




Description

Removing and installing engine coolant temperature sensor

Α

# **ENGINE CONTROL SYSTEM**

Schematic INFOID:000000003759297



http://probadordemodulos.wix.com/probadorautomotriz

# System Chart

INFOID:0000000003759299

Input (Sensor)	ECM Function	Output (Actuator)
Accelerator pedal position sensor     Fuel rail pressure sensor	Fuel injection control	Fuel injector     Fuel pump
<ul> <li>Fuel pump temperature sensor</li> <li>Engine coolant temperature sensor</li> <li>Mass air flow sensor</li> </ul>	Fuel injection timing control	Fuel injector     Fuel pump
<ul><li>Intake air temperature sensor</li><li>Crankshaft position sensor</li></ul>	Fuel cut control	Fuel injector     Fuel pump
<ul> <li>Camshaft position sensor</li> <li>Vehicle speed sensor*<sup>1</sup></li> <li>ABS actuator and electric unit (control unit)*<sup>1</sup></li> <li>Ignition switch</li> </ul>	Glow control system	Glow relay     Glow indicator lamp*2
	On board diagnostic system	Malfunction indicator (MI)*2
• Stop lamp switch	EGR volume control	EGR volume control valve
<ul> <li>Air conditioner switch*<sup>1</sup></li> <li>Park/neutral position switch</li> <li>Battery voltage</li> <li>EGR volume control valve control position sensor</li> </ul>	Cooling fan control	Cooling fan relay

<sup>\*1:</sup> The input signal is sent to the ECM through CAN communication line.

# **Fuel Injection Control System**

INFOID:0000000003759300

### SYSTEM DESCRIPTION

Three types of fuel injection control are provided to accommodate engine operating conditions; normal control, idle control and start control. The ECM determines the appropriate fuel injection control. Under each control, the amount of fuel injected is adjusted to improve engine performance.

Pulse signals are sent to fuel injectors according to the input signals to adjust the amount of fuel injected to preset value.


# START CONTROL

Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator	
Engine coolant temperature sensor	Engine coolant temperature	Fuel injection control (start Fuel pump		
Crankshaft position sensor	Engine speed			
Camshaft position sensor	Piston position		Fuel injector Fuel pump	
Ignition switch	Start signal	control)		
Fuel rail pressure sensor	Fuel rail pressure			

When the ECM receives a start signal from the ignition switch, the ECM adapts the fuel injection system for the start control. The amount of fuel injected at engine starting is a preset program value in the ECM. The program is determined by the engine speed, engine coolant temperature and fuel rail pressure.

For better start ability under cool engine conditions, the lower the coolant temperature becomes, the greater the amount of fuel injected. The ECM ends the start control when the engine speed reaches the specific value, and shifts the control to the normal or idle control.



# **IDLE CONTROL**

Input/Output Signal Chart

<sup>\*2:</sup> The output signal is sent from the ECM through CAN communication line.

Α

EC

Е

F

Н

M

Ν

0

Ρ

Sensor	Input Signal to ECM	ECM Function	Actuator
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor	Engine speed		
Battery	Battery voltage	Fuel injection	
Accelerator pedal position sensor	Accelerator pedal position	control (Idle	Fuel injector Fuel pump
Fuel rail pressure sensor	Fuel rail pressure	control)	. 46. 545
Vehicle speed sensor	Vehicle speed*		
Air conditioner switch	Air conditioner signal*		

<sup>\*:</sup> The input signal is sent to the ECM through CAN communication line.

When the ECM determines that the engine speed is at idle, the fuel injection system is adapted for the idle control. The ECM regulates the amount of fuel injected corresponding to changes in load applied to the engine to keep engine speed constant. The ECM also provides the system with a fast idle control in response to the engine coolant temperature signal.


### NORMAL CONTROL

Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor	Engine speed	Fuel injection control (Normal control)	Fuel injector Fuel pump
Accelerator pedal position sensor	Accelerator position		
Fuel rail pressure sensor	Fuel rail pressure		

The amount of fuel injected under normal driving conditions is determined according to sensor signals. The crankshaft position sensor detects engine speed, the accelerator pedal position sensor detects accelerator pedal position and fuel rail pressure sensor detects fuel rail pressure. These sensors send signals to the ECM.

The fuel injection data, predetermined by correlation between various engine speeds, accelerator pedal positions and fuel rail pressure are stored in the ECM memory, forming a map. The ECM determines the optimal amount of fuel to be injected using the sensor signals in comparison with the map.



### MAXIMUM AMOUNT CONTROL

Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Mass air flow sensor	Amount of intake air	Fuel injection	Fuel Injector
Engine coolant temperature sensor	Engine coolant temperature	control (Maxi-	
Crankshaft position sensor	Engine speed	mum amount control)	
Accelerator pedal position sensor	Accelerator pedal position	Control)	

The maximum injection amount is controlled to an optimum by the engine speed, intake air amount, engine coolant temperature, and accelerator opening in accordance with the driving conditions.

This prevents the oversupply of the injection amount caused by decreased air density at a high altitude or during a system failure.

### **DECELERATION CONTROL**

Input/Output Signal Chart

# **ENGINE CONTROL SYSTEM**

# < SERVICE INFORMATION >

[YD25DDTi]

Sensor	Input Signal to ECM	ECM Function	Actuator
Accelerator pedal position sensor	Accelerator pedal position	Fuel injection	Fuel injector
Crankshaft position sensor	Engine speed	control (Decel- eration control)	Fuel pump

The ECM sends a fuel cut signal to the fuel injectors and fuel pump during deceleration for better fuel efficiency. The ECM determines the time of deceleration according to signals from the accelerator pedal position sensor and crankshaft position sensor.

# **Fuel Injection Timing Control System**

INFOID:0000000003759301

### **DESCRIPTION**

The target fuel injection timing in accordance with the engine speed and the fuel injection amount are recorded as a map in the ECM beforehand. The ECM determines the optimum injection timing using sensor signals accordance with the map.

# Air Conditioning Cut Control

INFOID:0000000003759302

### INPUT / OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Air conditioner switch	Air conditioner ON signal*		Air conditioner relay
Accelerator pedal position sensor	Accelerator pedal opening angle	Air conditioner	
Vehicle speed sensor	Vehicle speed*	cut control	
Engine coolant temperature sensor	Engine coolant temperature		

<sup>\*:</sup> The input signal is sent to the ECM through CAN communication line.

### SYSTEM DESCRIPTION

This system improves acceleration when the air conditioner is used.

When the accelerator pedal is fully depressed, the air conditioner is turned off for a few seconds.

When engine coolant temperature becomes excessively high, the air conditioner is turned off. This continues until the engine coolant temperature returns to normal.

# Fuel Cut Control (At No Load & High Engine Speed)

INFOID:0000000003759303

### INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator	
Vehicle speed sensor	Vehicle speed*		Fuel injector	
Accelerator pedal position sensor	Accelerator pedal position	Fuel cut control		
Crankshaft position sensor	Engine speed			

<sup>\*:</sup> The input signal is sent to the ECM through CAN communication line.

If the engine speed is above 2,800 rpm under no load (for example, the shift position is neutral and engine speed is over 2,800 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will be operated until the engine speed reaches 1,500 rpm, then fuel cut will be cancelled.

### NOTE:

This function is different from deceleration control listed under <u>EC-18</u>, "Fuel Injection Control System".

# Crankcase Ventilation System


INFOID:0000000003759304

**DESCRIPTION** 

Α

Е


In this system, blow-by gas is sucked into the air duct after oil separation by oil separator in the rocker cover.



# **INSPECTION**

### Ventilation Hose

- Check hoses and hose connections for leaks.
- Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



# **CAN Communication**

### SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to EL-110, "CAN System Specification Chart", about CAN communication for detail.

M

INFOID:0000000003759305

Ν

Ρ

# BASIC SERVICE PROCEDURE

**Fuel Filter** INFOID:0000000003843895


# **DESCRIPTION**

A water draining cock is on the lower side and a priming pump for bleeding air is on the upper side.

### AIR BLEEDING

Pump the priming pump (1) to bleed air.

- · When air is bled completely, the pumping of the priming pump suddenly becomes heavy. Stop the operation at that time.
- If it is difficult to bleed air by the pumping of the priming pump (the pumping of the priming pump does not become heavy), disconnect the fuel supply hose between the fuel filter and the fuel gallery. Then, perform the operation described above, and make sure that fuel comes out. (Use a pan, etc. so as not to spill fuel. Do not let fuel get on engine and other parts.) After that, connect the hose, then bleed air again.
- Start engine and let it idle for at least 1 minute after performing air bleeding.



# WATER DRAINING

- Remove the fuel filter, filter bracket, protector assembly from the dash panel as follows.
- Remove the air cleaner case (upper), air duct assembly, and vacuum hose for brake booster (between the vacuum pump and vacuum pipe). **CAUTION:**

After the duct is removed, cover the opening with gum tape, etc. to prevent foreign object from getting into the engine during the operation.

- b. Remove the mounting nuts on the dash panel, then remove the fuel filter, filter bracket, and protector assembly from the dash panel.
  - It is not necessary to disconnect the fuel hose.
- Using a tool such as a pliers, loosen the water draining cock at the bottom of the fuel filter.

Loosening drain cock four to five turns causes water to start draining.

Do not remove drain cock by loosening it excessively. If water dose not drain properly, move the priming up and down. **CAUTION:** 

When the water is drained, the fuel is also drained. Use a pan, etc. to avoid fuel adherence to the rubber parts such as the engine mount insulator.

Do not over-tighten the water draining cock. This will damage the cock thread, resulting in water or fuel leak.

- Bleed air of the fuel filter. Refer to "AIR BLEEDING".
- Start the engine.

# Procedure After Replacing ECM

When replacing ECM, the following procedure must be performed.


- Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to EL-96, "ECM Re-communicating Function".
- Perform EC-22, "Injector Adjustment Value Registration".
- Perform EC-23, "Fuel Pump Learning Value Clearing".
- Perform EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear".
- Perform EC-24, "EGR Volume Control Valve Closed Position Learning".

# Injector Adjustment Value Registration

INFOID:0000000003759308

INFOID:0000000003759307

probadordemodulos@gmail.com



Up and

Drain cock


MFSQR#Batcondemodulos.wix.com/probadorautomotriz

Injector adjustment value indicates manufacturing tolerance and the value is printed on the top of fuel injector. The injector adjustment value which is correctly stored in ECM is needed for precise fuel injection control. A performance of emission control and a drivability may effect when there is a mismatch between the following two values.

The injector adjustment value stored in ECM

- The injector adjustment value of the injector which is installed on the vehicle Injector Adjustment Value Registration must be performed after the following cases.
- Injector(s) are replaced.
- ECM is replaced.

For the first case, Injector Adjustment Value Registration for the replaced fuel injector must be performed. And for the second case, Injector Adjustment Value Registration for all the fuel injectors must be performed.



Example: Injector adjustment value = D121ABCD1A061234000000000000E6

### OPERATION PROCEDURE

- Before performing this procedure, record injector adjustment value printed on a fuel injector.
- When all fuel injectors are replaced or ECM is replaced, it is recommended to perform "INJ ADJ VAL CLR" in "WORK SUPPORT" mode before performing this procedure. By performing "INJ ADJ VAL CLR" in "WORK SUPPORT" mode, injector adjustment value stored in ECM is initialized.
- Turn ignition switch ON (engine stopped). 1.
- Select "ENTER INJECTOR CALIB DATA" in "WORK SUPPORT" mode with CONSULT-III. 2.
- Touch "START".

### NOTE:

When touching "START", CONSULT-III reads injector adjustment values stored in ECM.

- Select the number of the cylinder which needs Injector Adjustment Value Registration.
- Input injector adjustment value, and touch "ENTER".

# NOTE:

Input injector adjustment value is stored in CONSULT-III.

Repeat step 4 - 5 till there is no cylinder which needs Injector Adjustment Value Registration, and touch "START".

# NOTE:

When touching "START", injector adjustment values stored in CONSULT-III are written onto ECM mem-

- 7. After "CMND FINISHED" is displayed, make sure that the following values are same for each cylinder.
  - Injector adjustment value which is printed on a fuel injector.
  - Injector adjustment value which is displayed on CONSULT-III screen.

- In this step, CONSULT-III reads injector adjustment values stored in ECM and displays the values on the CONSULT-III screen. This is for checking if injector adjustment values are written onto ECM memory
- If DTC is detected, perform DTC Confirmation Procedure for the DTC, and check if the same DTC is detected again.

# Fuel Pump Learning Value Clearing

INFOID:0000000003759309

DESCRIPTION

EC

Α

Е

Н

M

Ν

http://probadordemodulos.wix.com/probadorautomotriz

# **BASIC SERVICE PROCEDURE**

# < SERVICE INFORMATION >

[YD25DDTi]

In order to always keep optimum fuel pressure in fuel rail, the ECM controls fuel pump in high precision with monitoring the signal of fuel rail pressure sensor.

Accordingly, the ECM always learns characteristic value of fuel pump. Fuel Pump Learning Value Clearing is an operation to clear the value of the fuel pump learning.

Fuel Pump Learning Value Clearing should be performed under the following conditions.

- Fuel pump is changed.
- ECM is replaced with used one which stores the fuel pump learning value of other fuel pump.

### **OPERATION PROCEDURE**

### NOTE:

When removing fuel pump, perform Fuel Pump Learning Value Clearing before starting engine.

# (III) With CONSULT-III

- 1. Turn ignition switch ON.
- Select "PUMP LEARNT CLEAR" in "ACTIVE TEST" mode with CONSULT-III.
- 3. Touch "CLEAR" and wait a few seconds.
- 4. Make sure that "CMPLT" is displayed on CONSULT-III screen.

# **W** Without CONSULT-III

Fuel pump learning value can be erased from the back up memory in the ECM by the same operation as erasing DTC. In detail, refer to EC-32, "Emission-Related Diagnostic Information".

# EGR Volume Control Valve Closed Position Learning Value Clear

INFOID:0000000003759310

EGR volume control valve closed position learning value should be cleared under the following cases.

- EGR volume control valve is removed.
- EGR volume control valve is replaced.

# **OPERATION PROCEDURE**

### NOTE:

Always perform the following procedure with engine coolant temperature 0 to 30°C (32 to 86°F).

- 1. Turn ignition switch ON.
- 2. Select "EGR/V LEARN CLR" in "WORK SUPPORT" mode with CONSULT-III.
- Touch "CLEAR" and wait a few seconds.
- 4. Make sure the "CMPLT" is displayed on CONSULT-III screen.

# EGR Volume Control Valve Closed Position Learning

INFOID:0000000003759311

EGR Volume Control Valve Closed Position Learning is an operation to learn the fully closed position of the EGR volume control valve by monitoring the EGR volume control valve control position sensor output signal. It must be performed under any of the following conditions:

- EGR volume control valve is replaced.
- ECM is replaced.

### **OPERATION PROCEDURE**

- 1. Turn ignition switch ON and wait at least 10 seconds.
- Turn ignition switch OFF and wait at least 10 seconds.
   Make sure that EGR volume control valve moves during above 10 seconds by confirming the operating sound.

FUEL PUMP

### Components

Α

D

Е

Н


K

M

Ν

0

Р



1. Washer

4. O-ring

7. Coupling

10. Key

13. Spill hose

 $\Diamond$ : Engine front Fuel pump sprocket

Adjusting shim

8. Oil seal

11. Fuel pump

Seal washer

Sprocket nut

Spacer

12. Fuel hose

Refer to "HOW TO USE THIS MANUAL" in GI section for symbol marks in the figure.

### Removal and Installation

### **CAUTION:**

- Before removing and installing fuel pump, be sure to remove sprocket. Never loosen or remove installation nut in the center of fuel pump. If loosened or removed, replace fuel pump.
- · After removing timing chain, never turn crankshaft and camshaft separately, or valves will strike piston heads.
- When installing camshafts, chain tensioners, oil seals, or other sliding parts, lubricate contacting surfaces with new engine oil.
- When fuel pump is replaced with new one or another one, perform fuel pump leaning value cleaning before starting engine. Refer to EC-23, "Fuel Pump Learning Value Clearing".

### REMOVAL

- Remove engine cover, vacuum gallery and heater feed pipe. Refer to EM-6.
- Remove fuel hose and spill hose from fuel pump. Refer to EM-8. **CAUTION:**


### Be careful not to spill fuel in the engine component.

- 3. Disconnect harness connectors from fuel pump.
- Remove injection tube center, clip and insert rubber. Refer to <u>EM-8</u>. **CAUTION:**


http: Bercaretta indente spilo sueixincure lengine doma promentriz

probadordemodulos@gmail.com


- 5. Remove secondary timing chain. Refer to "TIMING CHAIN" in EM section.
- 6. Hold fuel pump sprocket and remove bolt.
- a. Insert the positioning stopper pin [SST (KV11106030)] into the hole 6 mm (0.24 in) in the diameter on the fuel pump sprocket.
- b. Using the TORX wrench [SST (KV11106040)], turn pump shaft little by little to adjust the position of fuel pump sprocket so that the holes align.
- c. Push the positioning stopper pin [SST (KV11106030)] through fuel pump sprocket to fuel pump body to hold fuel pump sprocket.




 Insert the positioning stopper pin until its flange contacts the fuel pump sprocket.



 Using the hexagonal wrench [SST (KV11106050)] remove tightening bolts of fuel pump sprocket.





Α

EC

C

D

Е

F

Н

K


M

Ν

Ρ

Using the sprocket holder [SST (KV11106060)], hold fuel pump sprocket to prevent falling.

 Rework sprocket holder [SST (KV11106060)] to use, as shown in the figure.




• When the sprocket holder is installed, if the positioning stopper pin [SST (KV11106030)] interferes, pull out the positioning stopper pin approximately 10 mm (0.39 in), then install it.

- · After the sprocket holder is installed temporarily, tighten the sprocket holder after making extension bar and TORX socket (size: E10) (commercial service tool) insert into the machined bore.
- · The length of the sprocket holder mounting bolts should be approximately 15 mm (0.59 in) (M6 thread length).
- Check that the a- and b-faces of the sprocket holder contact the bottom side of the sprocket (small diameter side). **CAUTION:**

Never remove the sprocket holder [SST (KV11106060)] until fuel pump is installed.


 After the sprocket holder is installed, pull out the positioning stopper pin from fuel pump sprocket.



Fuel pump KV11106030 Fuel pump sprocket KV11106060 MBIA0075E

9. Using the extension bar and the TORX socket (size: E10) (commercial service tool), remove the tightening bolts.

Never disassemble or adjust fuel pump.



10. Remove the fuel pump toward the rear of engine. **CAUTION:** 

For removal, be careful not to drop the seal washer into the engine.

The seal washer of the tightening bolts cannot be reused.


11. Remove adjusting shim.

CAUTION:


12. Attach a suitable tool in the M8 bolt hole on coupling.

http://probadordemodulos.wix.com/probadorautomotriz

13. Loosen sprocket nut with the TORX wrench [SST (KV11106040)].



14. Remove coupling with a suitable puller.




MBIA0014E

- 15. Remove spacer from fuel pump.
- 16. Remove oil seal from spacer.

# INSPECTION AFTER REMOVAL


**Timing Chain** 

Check for cracks and excessive wear at roller links. Replace timing chain if necessary.



# **INSTALLATION**

1. Install new oil seal to spacer.



Install spacer to fuel pump.

Α

EC


D

Е

F


Н

- 3. Install coupling to fuel pump of spacer.
  - Using the TORX wrench [SST (KV11106040)], tighten the sprocket nut to fix the coupling.




4. Install adjusting shim.

 For shim adjustment, measure dimension L [Distance between front surface of coupling and the fuel pump flange (spacer)] at two opposing points near the coupling bolt center. Use the average of these two measurements to select the shim grade that marked on adjusting shim.



 The shim adjustment is required only when the fuel pump is replaced.




Part No. of adjusting shim	Grade number	Measuring dimension L mm (in)	Туре
16614 8H800	0.5 t	39.23 - 39.77 (1.5445 - 1.5657)	А
16614 8H810	1.0 t	38.76 - 39.23 (1.5260 - 1.5445)	В
16614 8H860	1.2 t	38.57 - 38.76 (1.5185 - 1.5260)	С
16614 8H820	1.6 t	38.18 - 38.57 (1.5031 - 1.5185)	D
16614 8H800 + 16614 8H860	0.5 t + 1.2 t	38.09 - 38.18 (1.4996 - 1.5031)	A + C
16614 8H810 + 16614 8H810	1.0 t + 1.0 t	37.80 - 38.09 (1.4882 - 1.4996)	B + B
16614 8H860 + 16614 8H810	1.2 t + 1.0 t	37.60 - 37.80 (1.4803 - 1.4882)	C + B
16614 8H820 + 16614 8H810	1.6 t + 1.0 t	37.21 - 37.60 (1.4650 - 1.4803)	D + B

Р

M


Ν

Before fuel pump is installed, check that spacer and the 6 mm (0.24 in) dia. hole on coupling are aligned.




Insert fuel pump to the mounting position from the rear side of the engine, and install the tightening bolts with seal washer. CAUTION:


Be careful not to drop the seal washer into engine.




- 7. Using the extension bar and the TORX socket (size: E10) (commercial service tool), tighten the tightening bolts of fuel pump.
- 8. Remove the sprocket holder [SST (KV11106060)].



- 9. Using the TORX wrench [SST (KV11106040)], turn the pump shaft gradually to adjust the position of fuel pump sprocket. Then, insert the positioning stopper pin [SST (KV11106030)] to the 6 mm (0.24 in) dia. hole of the fuel pump sprocket through the pump body.
- 10. Remove the TORX wrench [SST (KV11106040)].



- 11. Using the hexagonal wrench [SST (KV11106050)], tighten the sprocket tightening bolt.
  - When the washer of the fuel pump sprocket is removed, install it with the marking "F" (front) facing the front of the engine.
- 12. Pull out the positioning stopper pin [SST (KV11106030)].



probadordemodulos@gmail.com

# **BASIC SERVICE PROCEDURE**

# < SERVICE INFORMATION >

- 13. Install secondary timing chain. Refer to "TIMING CHAIN" in EM section.
- 14. Following steps below, install injection tube center. Refer to EM-8.
- a. Pre-set clip and insert rubber to injection tube center.
- b. Pre-tight nut of injection tube center to fuel pump and fuel rail by hand. (until seal surface touched)
- c. Adjust clip dimension and tight bolt for clip to intake manifold by tool.
- d. Tight nut of injection tube center to fuel pump by tool.
- e. Tight nut of injection tube center to fuel rail by tool.
- 15. Connect the harness connector to fuel pump.
- 16. Install fuel hoses. Refer to EM-8.
- 17. Hereafter, install in the reverse order of removal. **CAUTION:**

When fuel pump is replaced with new one or another one, perform fuel pump leaning value cleaning before starting engine. Refer to <a href="EC-23">EC-23</a>, "Fuel Pump Learning Value Clearing".

[YD25DDTi]

EC

Α

С

D

Ε

F

Н

ı

J

K

L

M

Ν

0

Р

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

Introduction INFOID:000000003759315

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information	ISO Standard
Diagnostic Trouble Code (DTC)	Service \$03 of ISO 15031-5
Freeze Frame data	Service \$02 of ISO 15031-5
1st/2nd Trip Diagnostic Trouble Code (1st/2nd Trip DTC)	Service \$07 of ISO 15031-5
Calibration ID	Service \$09 of ISO 15031-5

The above information can be checked using procedures listed in the table below.

×: Applicable —: Not applicable

	DTC	1st trip DTC	2nd trip DTC	Freeze Frame data
CONSULT-III	×	×	×	×
GST	×	×	×	×
ECM	×	×*	×*	_

<sup>\*:</sup> When DTC and 1st/2nd trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator (MI) on the instrument panel lights up when the same malfunction is detected in three consecutive trips (Three trip detection logic).

# Three Trip Detection Logic and One Trip Detection Logic

INFOID:0000000003759316

On board diagnosis (OBD) system of this vehicle has "Three Trip Detection Logic" and "One Trip Detection Logic". For which logic each self-diagnosis corresponds with, refer to <a href="EC-32">EC-32</a>, "Emission-Related Diagnostic Information".

"Trip" of "Three Trip Detection Logic" means a driving mode in which the self-diagnosis is performed while driving.

### THREE TRIP DETECTION LOGIC

When a malfunction is detected for the first time, 1st trip DTC is stored in the ECM memory. MI does not illuminate at this stage. <1st trip>

When the same malfunction is detected again during the next driving, 2nd trip DTC is stored in the ECM memory and 1st trip DTC is cleared from the ECM memory. MI does not illuminate at this stage. <2nd trip>

When the same malfunction is detected again at the third driving, DTC and Freeze Frame Data are stored in the ECM memory and 2nd trip DTC is cleared from the ECM memory. MI illuminates at the same time when DTC is stored. <3rd trip>

In other words, DTC and Freeze Frame Data are stored and MI illuminates when the same malfunction occurs in 3 consecutive trips.

This is called "Three Trip Detection Logic".

### ONE TRIP DETECTION LOGIC

When a malfunction is detected for the first time, DTC and Freeze Frame Data are stored in the ECM memory and MI lights up. This is called "One Trip Detection Logic". Some self-diagnoses will not illuminate MI when DTC is stored. (Refer to <a href="EC-32">EC-32</a>, "Emission-Related Diagnostic Information".) 1st/2nd trip DTC is not stored for one trip detection logic.

# **Emission-Related Diagnostic Information**

INFOID:0000000003759317

EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

< SERVICE INFORMATION >

[YD25DDTi]

X: Applicable —: Not applicable Α DTC\*1 MI lighting Items Trip Reference page **CONSULT-III** (CONSULT-III screen item) up ECM\*3 GST\*2 U1000 CAN COMM CIRCUIT 1 EC-83 1000\*4 NO DTC IS DETECTED. P0000 **FURTHER TESTING** 0000 C MAY BE REQUIRED. P0016 0016 CMP/CKP RELATION 3 EC-85 X P0088 0088 HIGH FUEL PRESS 3 X EC-87 P0089 0089 **FUEL PUMP** 3 EC-89 X 0093 **FUEL LEAK** 3 EC-91 P0093 × MAF SENSOR 3 P0101 0101 EC-94 P0102 0102 MAF SEN/CIRCUIT 3 EC-103 P0103 0103 MAF SEN/CIRCUIT 3 EC-103 X P0112 0112 IAT SEN/CIRCUIT 3 EC-111 X P0113 0113 IAT SEN/CIRCUIT 3 EC-111 X P0117 0117 ECT SEN/CIRCUIT 3 EC-115 X P0118 0118 ECT SEN/CIRCUIT 3 EC-115 X P0122 0122 **APP SEN 1/CIRCUIT** 1 EC-119 Н P0123 0123 **APP SEN 1/CIRCUIT** EC-119 1 P0182 0182 FUEL TEMP SEN/CIRC 3 EC-124 Χ P0183 **FUEL TEMP SEN/CIRC** 3 EC-124 0183 X P0192 FRP SEN/CIRC EC-128 0192 3 X P0193 0193 FRP SEN/CIRC 3 EC-128 X P0200 0200 INJECTOR 3 × EC-132 P0201 0201 CYL1 INJECTOR 3 EC-133 X **CYL2 INJECTOR** K P0202 0202 3 EC-133 × P0203 0203 CYL3 INJECTOR 3 EC-133 **CYL4 INJECTOR** P0204 0204 3 EC-133 X **ENG OVER TEMP** P0217 0217 1 EC-138 0222 APP SEN 2/CIRCUIT P0222 1 EC-147 P0223 0223 **APP SEN 2/CIRCUIT** 1 EC-147 M P0335 0335 CKP SEN/CIRCUIT 3 EC-152 × P0336 **CKP SENSOR** 3 EC-157 0336 Χ N CMP SEN/CIRCUIT 3 P0340 0340 EC-163 × P0341 0341 **CMP SENSOR** 3 EC-168 X P0380 0380 **GLOW RELAY** 3 EC-173 × P0403 0403 **EGR SYSTEM** 3 EC-177 X P0405 0405 **EGR SENSOR** 3 EC-184 Х P P0406 0406 **EGR SENSOR** 3 EC-184 X P0409 0409 **EGR SYSTEM** 3 EC-190 × **EGR SYSTEM** P0488 0488 3 × EC-196 **BATTERY VOLTAGE** P0563 0563 1 EC-201 **ECM** P0606 0606 3 EC-203 P0628 0628 FUEL PUMP/CIRC 3 EC-205

EC-3333

probadordemodulos@gmail.com

http://probadordemodulos.wix.com/probadorautomotriz

DTC*1		14		NALE 1 C	
CONSULT-III GST* <sup>2</sup>	ECM*3	Items (CONSULT-III screen item)	Trip	MI lighting up	Reference page
P0629	0629	FUEL PUMP/CIRC	3	×	EC-205
P0642	0642	SENSOR PWR/CIRC1	3	×	EC-210
P0643	0643	SENSOR PWR/CIRC1	3	×	EC-210
P0652	0652	SENSOR PWR/CIRC2	3	×	EC-214
P0653	0653	SENSOR PWR/CIRC2	3	×	EC-214
P0668	0668	ECM	3	×	EC-218
P0669	0669	ECM	3	×	EC-218
P0686	0686	ECM RELAY	1	_	EC-220
P1268	1268	INJECTOR 1	1	_	EC-227
P1269	1269	INJECTOR 2	1	_	EC-227
P1270	1270	INJECTOR 3	1	_	EC-227
P1271	1271	INJECTOR 4	1	_	EC-227
P1272	1272	FRP RELIEF VALVE	3	×	EC-234
P1273	1273	FUEL PUMP	3	×	EC-234
P1274	1274	FUEL PUMP	1	×	EC-234
P1275	1275	FUEL PUMP	1	×	EC-234
P1610	1610	LOCK MODE	1	_	<u>EL-102</u>
P1611	1611	ID DISCORD, IMM-ECM	1	_	<u>EL-103</u>
P1612	1612	CHAIN OF ECM-IMMU	1	_	EL-103
P1614	1614	CHAIN OF IMMU-KEY	1	_	EL-105
P1615	1615	DIFFERENCE OF KEY	1	_	<u>EL-106</u>
P1616	1616	ECM	1	_	<u>EL-106</u>
P1622	1622	INJ ADJ VAL UNRGST	1	_	EC-254
P1623	1623	INJ ADJ VAL ERROR	1	_	EC-255
P2135	2135	APP SENSOR	1	_	EC-257
P2146	2146	INJ PWR/CIRC	3	×	EC-262
P2147	2147	INJECTOR/CIRC	3	×	EC-266
P2148	2148	INJECTOR/CIRC	3	×	EC-266
P2149	2149	INJ PWR/CIRC	3	×	EC-262
P2228	2228	BARO SEN/CIRC	3	×	EC-271
P2229	2229	BARO SEN/CIRC	3	×	EC-271

<sup>\*1: 1</sup>st trip DTC No. and 2nd trip DTC No. are the same as DTC No.

# DTC AND 1ST/2ND TRIP DTC

The number of 1st/2nd trip DTC is the same as the number of DTC.

When a malfunction is detected during 1st trip, 1st trip DTC is stored in the ECM memory. MI does not illuminate at this time. When the same malfunction is detected in the next trip (2nd trip), 2nd trip DTC is stored in the ECM memory and 1st trip DTC is cleared from the ECM memory. MI does not illuminate at this time. In addition, DTC is stored in the ECM memory and MI lights up when the same malfunction is detected during the following consecutive trip (3rd trip).

The procedure for erasing DTC, 1st trip DTC, and 2nd trip DTC from the ECM memory is described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".

<sup>\*2:</sup> This number is prescribed by ISO 15031-6.

<sup>\*3:</sup> In Diagnostic Test Mode II (Self-diagnostic results).

<sup>\*4:</sup> The troubleshooting for this DTC needs CONSULT-III.

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

### [YD25DDTi] < SERVICE INFORMATION >

For malfunctions in which 1st/2nd trip DTC are displayed, Refer to "EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS".

1st/2nd trip DTC is specified in Service \$07 of ISO15031-5. 1st/2nd trip DTC detection occurs without lighting up MI and therefore does not warn the driver of a malfunction.

When 1st/2nd trip DTC is detected, check, print out or write down, and erase 1st/2nd trip DTC as specified with step II of Work Flow, refer to EC-41, "Trouble Diagnosis Introduction". Then perform DTC Confirmation Procedure or Overall Function Check to try to duplicate the malfunction. If the malfunction is duplicated, it is necessary to investigate the cause again.

How to Read DTC and 1st/2nd Trip DTC

DTC and 1st/2nd trip DTC can be read by the following procedures.

# (P) With CONSULT-III

# **6 With GST**

CONSULT-III or GST (Generic Scan Tool): Examples: P0117, P0335, P1268, etc.

These numbers are prescribed by ISO 15031-6.

(CONSULT-III also displays the malfunctioning parts and systems.)

A sample of CONSULT-III display for DTC and 1st/2nd trip DTC is shown in the figure. DTC and 1st/2nd trip DTC are displayed in the "SELF-DIAG RESULTS" mode of CONSULT-III.

"TIME" data shows how many times the vehicle was driven after the last detection of DTC or 1st/2nd trip DTC. When DTC or 1st/2nd trip DTC has been detected currently, "TIME" becomes "0".

- CONSULT-III displays for DTC and 1st/2nd trip DTC become the same.
- The output of a DTC indicates a malfunction. However, GST does not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-III can identify the malfunction status. Therefore the use of CONSULT-III (If available) is recommended.

### FREEZE FRAME DATA

ECM records driving conditions such as calculated load value, engine coolant temperature, engine speed, vehicle speed, and intake manifold pressure at the moment a malfunction is detected.

The data stored together with DTC is called Freeze Frame Data, and is displayed on CONSULT-III or GST. When 1st/2nd trip DTC is detected, Freeze Frame Data is not recorded.

Only a set of Freeze Frame Data can be stored in the ECM memory. When ECM records Freeze Frame Data, and another Freeze Frame Data is generated after that, the first (original) Freeze Frame Data is not updated in ECM and it remains.

When the DTC is erased from ECM memory, Freeze Frame Data is erased with DTC. The procedure for erasing DTC is described in "HOW TO ERASE ÉMISSION-RELATED DIAGNOSTIC INFORMATION".

### HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

How to Erase DTC and 1st Trip DTC

# (III) WITH CONSULT-III

### NOTE:

- If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
- Select "ENGINE" with CONSULT-III. 1.
- Select "SELF-DIAG RESULTS".
- Touch "ERASE". (DTC in ECM will be erased.)

# **WITH GST**

### NOTE:

 If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.

### **MO TOOLS**

### NOTE:

- If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
- If the battery is disconnected, the emission-related diagnostic information will be lost within 24 hours.
- The following data are cleared when the ECM memory is erased.
- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- 2nd trip diagnostic trouble codes

http://srobaderdemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

EC

Е

Н

K

M

Ν

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

# NATS (Nissan Anti-Theft System)

INFOID:0000000003759318

- If the security indicator lights up with the ignition switch in the ON position or "NATS MALFUNC-TION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-III using NATS program card. Refer to <u>FL-95</u>.
- Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DAIG RESULTS" mode with CONSULT-III.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-III using NATS program card.
   Therefore, be sure to receive all keys from vehicle owner. Regarding the procedure of NATS initials.

Therefore, be sure to receive all keys from vehicle owner. Regarding the procedure of NATS initialization and all NATS ignition key ID registration, refer to CONSULT-III operation manual, NATS.


# Malfunction Indicator (MI)

INFOID:0000000003759319

## **DESCRIPTION**

The MI is located on the instrument panel.

- The MI will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
   If the MI does not light up, refer to <u>EC-296</u>.
- When the engine is started, the MI should go off. If the MI remains on, the on board diagnostic system has detected an engine system malfunction.



### ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following three functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in	BULB CHECK	This function checks the MI bulb for damage (blown, open circuit, etc.).  If the MI does not come on, check MI circuit. (See <u>EC-296</u> .)
	Engine stopped		
	ginetunning	MALFUNCTION WARNING	This is a usual driving condition. When ECM detects a mal- function, the MI will light up to inform the driver that a mal- function has been detected.
Mode II	Ignition switch in	SELF-DIAGNOSTIC RESULTS	This function allows DTCs to be read.
	Engine stopped		
HOW TO SWI	TCH DIAGNOS	TIC TEST MODE	

NOTE:


[YD25DDTi]

- · It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned OFF.

How to Set Diagnostic Test Mode II (Self-diagnostic Results)

- 1. Confirm that accelerator pedal is fully released, turn ignition switch ON and wait 3 seconds.
- Repeat the following procedure quickly five times within 5 seconds.
- a. Fully depress the accelerator pedal.
- b. Fully release the accelerator pedal.
- 3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MI starts blinking.
- 4. Fully release the accelerator pedal.

ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).



How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

- Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to "How to Set Diagnostic Test Mode II (Self-diagnostic Results)".
- Fully depress the accelerator pedal and keep it for more than 10 seconds.The emission-related diagnostic information has been erased from the backup memory in the ECM.
- 3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

#### DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to <u>EC-296</u>.

#### DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MI	Condition					
ON	When the malfunction is detected.					
OFF	No malfunction.					

These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)

#### DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

EC

С

D

Е

F

Н

1

K


L

N

0

Р

In this mode, the DTC is indicated by the number of blinks of the MI as shown below. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The "zero" is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle. A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC 0000 refers to no malfunction. (See EC-32, "Emission-Related Diagnostic Information".)

How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to "How to Erase Diagnostic Test Mode II (Self-diagnostic Results)".

- If the battery is disconnected, the DTC will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

# **OBD System Operation Chart**

INFOID:0000000003759320

#### RELATIONSHIP BETWEEN MI, 1ST/2ND TRIP DTC, DTC, AND DETECTABLE ITEMS

- When the malfunction is detected for the first time, 1st trip DTC is stored in the ECM memory.
- When the same malfunction is detected during 2nd consecutive trip, 2nd trip DTC is stored and 1st trip DTC is cleared.
- When the same malfunction is detected during 3rd consecutive trip, DTC and Freeze Frame Data are stored and MI illuminates. Refer to <u>EC-32</u>, "<u>Three Trip Detection Logic and One Trip Detection Logic"</u> for details.1st/2nd trip DTC are cleared from the ECM memory.
- MI will go off after the vehicle is driven 3 consecutive times with no malfunction (driving pattern A).
- 1st/2nd trip DTC, DTC, and Freeze Frame Data will be stored until the vehicle is driven 41 times (driving pattern B) without the same malfunction recurring. "TIME" data displayed in the "SELF-DIAG RESULTS" mode of CONSULT-III shows the number of times the vehicle is driven without the same malfunction recurring.

#### SUMMARY CHART

Items	Trip	Counter	Driving Pattern
MI (goes off)	3	2	A
DTC, Freeze Frame Data (clear)	41	40	В
1st/2nd Trip DTC (clear)	41	40	В

Refer to "RELATIONSHIP BETWEEN MI, DTC, 1ST/2NDTRIP DTC AND DRIVING PATTERNS" for details of pattern A and B.

RELATIONSHIP BETWEEN MI, DTC, 1ST/ 2NDTRIP DTC AND DRIVING PATTERNS

Α

EC

Е


Н

K

M

Ν

Р



- \*1: CONSULT-III displays for DTC and 1st/2nd trip DTC become the same.
- \*2: 1st/2nd trip DTC becomes the same display in mode7 of GST.
- \*3: When the same malfunction is detected in three consecutive trips, MI will light up.

- \*4: MI will go off after vehicle is driven 3 times (pattern A) without any malfunctions.
- 5: When the malfunction is detected for \*6: the first time, 1st trip DTC is stored in the ECM memory.
  - When the same malfunction is detected during 2nd consecutive trip, 2nd trip DTC is stored and 1st trip DTC is cleared.

- \*7: When the same malfunction is detected during 3rd consecutive trip, DTC and Freeze Frame Data are stored.
- \*8: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 41 times (pattern B) without the same malfunction.

#### <Driving Pattern A>

Driving pattern A means the vehicle operation as follows:

Engine speed should go over 500 rpm at least 5 seconds and the DTC Confirmation Procedure is performed.

- The A counter will be cleared when the same malfunction is detected.
- The A counter will be counted up when the same malfunction is not detected.
- The MI will go off when the A counter reaches 3.


probadordemodulos@gmail.com

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

#### < SERVICE INFORMATION >

[YD25DDTi]

Driving pattern B means the vehicle operation as follows:



- The B counter will be cleared when the same malfunction is detected.
- The B counter will be counted up when the same malfunction is not detected.
- The DTC will not be displayed after the B counter reaches 40.

# TROUBLE DIAGNOSIS

## **Trouble Diagnosis Introduction**

#### INFOID:0000000003759321

Α

EC


C

D


Н

#### INTRODUCTION

The engine has an ECM to control major systems such as fuel injection control, fuel injection timing control, glow control system, etc. The ECM accepts input signals from sensors and instantly actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no malfunctions such as vacuum leaks, or other malfunctions with the engine.




It is much more difficult to diagnose a malfunction that occurs intermittently rather than continuously. Most intermittent malfunctions are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.



A visual check only may not find the cause of the incidents. A road test with CONSULT-III (or GST) or a circuit tester connected should be performed. Follow the "WORK FLOW".

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A Diagnostic Worksheet like the example on "WORK FLOW" should be used.

Start your diagnosis by looking for conventional incidents first. This will help troubleshoot driveability incidents on an electronically controlled engine vehicle.




**WORK FLOW** 

Ν

0

Ρ



- If time data of "SELF-DIAG RE-SULTS" is other than "0", perform
- \*4 If malfunctioning part cannot be detected, perform EC-70.

\*2 If the incident cannot be verified, per- \*3 form EC-70.

If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to EC-71.

Description for Work Flow

STEP	DESCRIPTION	Δ
STEPI	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DI-AGNOSTIC WORK SHEET".	
STEP II	Before confirming the concern, check and write down (print out using CONSULT-III or GST) the (1st/2nd trip) DTC and the freeze frame data (When 1st/2nd trip DTC is detected, Freeze Frame Data is not recorded.), then erase the DTC and the data. (Refer to EC-32, "Emission-Related Diagnostic Information".) The (1st/2nd trip) DTC and the freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform EC-70. Study the relationship between the cause, specified by (1st/2nd trip) DTC, and the symptom described by the customer. (The Symptom Matrix Chart will be useful. See EC-48, "Symptom Matrix Chart".) Also check related service bulletins for information.	C
STEP III	Try to confirm the symptom and under what conditions the incident occurs.  The DIAGNOSTIC WORK SHEET and the freeze frame data are useful to verify the incident. Connect CONSULT-III to the vehicle and check real time diagnosis results.  If the incident cannot be verified, perform <u>EC-70</u> .  If the malfunction code is detected, skip STEP IV and perform STEP V.	E
STEP IV	Try to detect the (1st/2nd trip) DTC by driving in (or performing) the DTC Confirmation Procedure. Check and read the (1st/2nd trip) DTC and freeze frame data by using CONSULT-III or GST. If the incident cannot be verified, perform <u>EC-70</u> . In case the DTC Confirmation Procedure is not available, perform the Overall Function Check instead. The (1st/2nd trip) DTC cannot be displayed by this check, however, this simplified check is an effective alternative. The NG result of the Overall Function Check is the same as the (1st/2nd trip) DTC detection.	F
STEP V	Take the appropriate action based on the results of STEP I through IV.  If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX.  If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-45, "Basic Inspection".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-48, "Symptom Matrix Chart".)	Н
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) Harness Layouts. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-III. Refer to EC-57, "ECM Terminal and Reference Value", EC-68, "CONSULT-III Reference Value in Data Monitor Mode".  The Diagnostic Procedure in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "SERVICE INFORMATION FOR ELECTRICAL INCIDENT".  Repair or replace the malfunction parts.  If malfunctioning part cannot be detected, perform EC-70.	J
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint.  Perform the DTC Confirmation Procedure and confirm the normal code [DTC No. P0000] is detected. If the incident is still detected in the final check, perform STEP VI by using a method different from the previous one.  Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st/2nd trip) DTC in ECM. (Refer to EC-32, "Emission-Related Diagnostic Information".)	L

#### DIAGNOSTIC WORK SHEET

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one shown below in order to organize all the information for troubleshooting.

KEY	PO	INTS

WHAT ..... Vehicle & engine model
WHEN ..... Date, Frequencies
WHERE..... Road conditions
HOW ..... Operating conditions,
Weather conditions,
Symptoms

SEF907L

M

0

Р

Worksheet Sample

Customer nar	ne MR/MS	Model & Year	VIN						
Engine #		Trans.	Mileage						
Incident Date		Manuf. Date	In Service Date						
	☐ Startability	☐ Impossible to start ☐ No combus ☐ Partial combustion affected by th ☐ Partial combustion when engine ☐ Possible but hard to start ☐ Other	nrottle position						
Symptoms	□ Idling	☐ No fast idle ☐ Unstable ☐ H☐ Others [	High idle ☐ Low idle ]						
	☐ Driveability	☐ Stumble ☐ Surge ☐ Knock ☐ Others [	☐ Lack of power ]						
	☐ Engine stall	☐ At the time of start ☐ While idling ☐ While accelerating ☐ While dece	elerating						
Incident occu	rrence	☐ Just after delivery ☐ Recently ☐ In the morning ☐ At night [	☐ In the daytime						
Frequency		☐ All the time ☐ Under certain cond	ditions						
Weather cond	litions	☐ Not affected							
	Weather	☐ Fine ☐ Raining ☐ Snowing	Others [						
	Temperature	☐ Hot ☐ Warm ☐ Cool ☐	Cold Humid °F						
Engine condit	ions	Cold During warm-up  Engine speed  0 2,000	After warm-up  4,000 6,000 8,000 rpm						
Road condition	ons	☐ In town ☐ In suburbs ☐ Hig	jhway ☐ Off road (up/down)						
Driving condit	ions	□ Not affected     □ At starting    □ While idling    □ At racing     □ While accelerating    □ While cruising     □ While decelerating    □ While turning (RH/LH)  Vehicle speed    □    □    □							
Malfunction in	ndicator	0 10 20 ☐ Turned on ☐ Not turned on	30 40 50 60 MPH						

# **DTC Inspection Priority Chart**

INFOID:0000000003759322

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

[YD25DDTi]

INFOID:0000000003759324

Priority	Detected items (DTC)	
1	U1000 CAN communication line     P0016 Crankshaft position - camshaft position correlation	Α
	<ul> <li>P0101 P0102 P0103 Mass air flow sensor</li> <li>P0112 P0113 Intake air temperature sensor</li> <li>P0117 P0118 Engine coolant temperature sensor</li> <li>P0122 P0123 P0222 P0223 P2135 Accelerator pedal position sensor</li> </ul>	EC
	<ul> <li>P0182 P0183 Fuel pump temperature sensor</li> <li>P0192 P0193 Fuel rail pressure sensor</li> <li>P0335 P0336 Crankshaft position sensor</li> </ul>	(
	<ul> <li>P0340 P0341 Camshaft position sensor</li> <li>P0563 Battery voltage</li> <li>P0606 P0668 P0669 ECM</li> <li>P0642 P0643 P0652 P0653 Sensor power supply</li> </ul>	С
	<ul> <li>P1610 - P1616 NATS</li> <li>P1622 P1623 Injector adjustment value</li> <li>P2228 P2229 Barometric pressure sensor</li> </ul>	E
2	<ul> <li>P0089 P0628 P0629 P1272 - P1275 Fuel pump</li> <li>P0200 - P0204 P1268 - P1271 P2146 - P2149 Fuel injector</li> <li>P0380 Glow relay</li> <li>P0405 P0406 EGR volume control valve control position sensor</li> <li>P0686 ECM relay</li> </ul>	F
3	<ul> <li>P0088 P0093 Fuel system</li> <li>P0217 Engine over temperature (OVERHEAT)</li> <li>P0403 P0409 P0488 EGR function</li> </ul>	(

## Basic Inspection

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied.

Headlamp switch is OFF.

- For vehicles equipped with daytime light systems, perform one of the following procedures before starting engine not to illuminate headlamps.

Apply parking brake

- Set lighting switch to the 1st position
- · Air conditioner switch is OFF.
- Rear defogger switch is OFF.
- Steering wheel is in the straight-ahead position, etc.

# 1.INSPECTION START

- 1. Check service records for any recent repairs that may indicate a related malfunction.
- 2. Check the current need for scheduled maintenance, especially for fuel filter and air cleaner filter. Refer to MA-3 (For Europe), MA-8 (For Australia).
- 3. Open engine hood and check the following:
- Harness connectors for improper connections
- Vacuum hoses for splits, kinks, or improper connections
- Wiring for improper connections, pinches, or cuts
- 4. Start engine and warm it up to the normal operating temperature.

>> GO TO 2.

# 2. PREPARATION FOR CHECKING IDLE SPEED

SEPTIZI

http://probadordemodulos.wix.com/probadorautomotriz

L

N

 $\bigcirc$ 

< SERVICE INFORMATION > [YD25DDTi]

#### (III) With CONSULT-III

Connect CONSULT-III to the data link connector.

#### **Without CONSULT-III**

Install diesel tacho tester to the vehicle.

>> GO TO 3.

# 3. CHECK IDLE SPEED

# (III) With CONSULT-III

- 1. Select "CKPS·RPM (TDC)" in "DATA MONITOR" mode with CONSULT-III.
- 2. Read idle speed.

M/T: 750±25 rpm (in Neutral position)

# **W** Without CONSULT-III

Read idle speed.

M/T: 750±25 rpm (in Neutral position)

#### OK or NG

OK >> INSPECTION END

NG >> GO TO 4.

## 4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

## OK or NG

OK >> GO TO 5.

NG >> Repair or replace.

# 5.BLEED AIR FROM FUEL SYSTEM

- 1. Stop engine.
- 2. Use priming pump to bleed air from fuel system. Refer to EC-22, "Fuel Filter".

>> GO TO 6.

## 6. CHECK IDLE SPEED AGAIN

# (III) With CONSULT-III

- 1. Start engine and let it idle.
- 2. Select "CKPS·RPM (TDC)" in "DATA MONITOR" mode with CONSULT-III.
- 3. Read idle speed.

M/T: 750±25 rpm (in Neutral position)

## **Without CONSULT-III**

Read idle speed.

M/T: 750±25 rpm (in Neutral position)

#### OK or NG

OK >> INSPECTION END

NG >> GO TO 7.

#### .DRAIN WATER FROM FUEL FILTER

Drain water from fuel filter. Refer to EC-22, "Fuel Filter".

>> GO TO 8.

# 8. CHECK IDLE SPEED AGAIN

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

# **TROUBLE DIAGNOSIS**

< SERVICE INFORMATION >	[YD25DDTi]
<ul> <li>With CONSULT-III</li> <li>Start engine and let it idle.</li> <li>Select "CKPS·RPM (TDC)" in "DATA MONITOR" mode with CONSULT-III.</li> <li>Read idle speed.</li> </ul>	А
M/T: 750±25 rpm (in Neutral position)	EC
<b>™</b> Without CONSULT-III	C
Read idle speed.	C
M/T: 750±25 rpm (in Neutral position)  OK or NG	D
OK >> INSPECTION END	
NG >> GO TO 9.  9. CHECK AIR CLEANER FILTER	Е
Check air cleaner filter for clogging or breaks.	
OK or NG	F
OK >> GO TO 10. NG >> Replace air cleaner filter.	
10.check battery voltage	G
Check battery voltage.	
Voltage: More than 12.13 V	Н
OK or NG OK >> GO TO 12.	I
NG >> GO TO 11.	1
11.CHECK BATTERY  Refer to EL-12.	J
OK or NG	
OK >> Check charging system. Refer to "BATTERY" in EL section.  NG >> Repair or replace.	K
12. CHECK COMPRESSION PRESSURE	
Check compression pressure. Refer to "MEASUREMENT OF COMPRESSION PRE	SSURE" in EM section.
<u>OK or NG</u> OK >> GO TO 13.	
NG >> Follow the instruction of "CHECKING COMPRESSION PRESSURE".  13.CHECK IDLE SPEED AGAIN	M
With CONSULT-III	N
<ol> <li>Start engine and let it idle.</li> <li>Select "CKPS·RPM (TDC)" in "DATA MONITOR" mode with CONSULT-III.</li> </ol>	N
3. Read idle speed.	0
M/T: 750±25 rpm (in Neutral position)	
Without CONSULT-III Read idle speed.	Р
M/T: 750±25 rpm (in Neutral position)	
OK or NG	
OK >> INSPECTION END NG >> 1. Replace fuel injector.	
http://probador@nt@lslos.wix.com/probadorautomotriz probador	demodulos@gmail.com

# Symptom Matrix Chart

INFOID:0000000003759325

						SY	MPT(	ОМ						e G
		HARD/NO START/RESTART	(EXCP. HA)			ENGINE STALL								Reference page
SYSTEM — Basic engine control system	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING	HESITATION/SURGING/FLAT SPOT		LACK OF POWER	POOR ACCELERATION	HI IDLE	LOW IDLE	
Warranty symptom code		Α	ΑA			AB			AD	P	Æ	P	۱F	
Fuel pump	5	5	5	5	5	5	5	5		5	5	ĺ	5	_
Fuel filter	1	1	1	1						1				EC-22
Fuel injector	3	3	3	3	3	3	3	3	3	4	4	3	3	EC-133
Glow control system	1	1	1	1					1					EC-273
Engine body	3	3	3	3	3	3	3		3	4	4		3	EM-18
EGR system										3	3			EC-177, EC-190, EC-196
Air cleaner and duct										3	3			Refer to Service Manual
Fuel rail pressure relief valve	3	3	3	3	3	3	3	3		3	3		3	EC-91

							SY	MPT(	OM						age	
			HARD/NO START/RESTART (EXCP. HA)				ENGINE STALL								Reference page	EC C
SYST	EM — Basic engine control system				НОТ				_							D
			(b	NGINE IS	NGINE IS				T SPOT							Е
		irst firing)	ut first firin	START WHEN ENGINE IS COLD	START WHEN ENGINE IS HOT		Ŋ	RATING	RGING/FL/	NOIL	œ	ATION				F
		START (with first firing)	NO START (without first firing)			щ	DURING DRIVING	N DECELERATING	HESITATION/SURGING/FLAT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	щ	DLE		G
		NO S	NO ST	HARD TO	HARD TO	AT IDLE	DURIN	WHEN	HESIT	KNOC	LACK	POOR	HI IDLE	LOW IDLE		Н
Warra	anty symptom code		-	λA			AB		AC	AD	ļ	۸E	A	۱F		
	Fuel pump circuit	4	4	4	4	4	4	4	4		4	4		4	EC-205	1
	Fuel injector circuit	1	1	1	1	1	1	1	1	1	1	1	1	1	EC-133	1
	Fuel injector adjustment value								1	1	1	1			EC-22	
	Mass air flow sensor circuit								1		1	1			EC-94,	J
	Engine coolant temperature circuit			1		1		1			1			1	EC-103 EC-115	
	Vehicle speed signal circuit					·						1			EL-111	K
	Accelerator pedal position sensor circuit								1		1	1			EC-119, EC-147, EC-257	L
SOL	Fuel rail pressure sensor circuit	1	1	1	1						1				EC-128	
ENGINE CONTROL	Crankshaft position sensor circuit		1	1	1	1	1	1	1	1	1	1			EC-152, EC-157	M
GINE	Camshaft position sensor circuit			3	3						3				<u>EC-163</u> , <u>EC-168</u>	
面	Start signal circuit	1	1	1	1	1		1	1		1	1			EC-293	Ν
	Ignition switch circuit		1			1	1	1							EC-71	
	Heat up switch circuit												1		EC-280	0
	Power supply for ECM circuit		1			1	1	1							EC-71	
	Cooling fan relay circuit														EC-138	
	01 1 : :	1	1	1	1										EC-173	Р
	Glow relay circuit					i							Ú.	Ú.	i .	
	ECM relay (Self-shutoff) circuit		1				1	1	1						EC-220	
		2	1 2	2	2	2	2	2	2	2	2	2	2	2	EC-220 EC-203, EC-218, EC-271	

Http://probadorautomotriz

probadordemodulos@gmail.com

(continued on next table)


					S	YMPT	ОМ					age
SYSTEM — Basic engine control system			IDLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE	CONSUMPTION	CONSUMPTION	TVC AND COMME	ABINORIMAL SIMIONE COLOR	R CHARGE)	tes.	.T-III?	Reference page
	ROUGH IDLE/HUNTING	ROUGH IDLE/HUNTING	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENG	EXCESSIVE FUEL CON	EXCESSIVE OIL CONSI	BLACK SMOKE	WHITE SMOKE	DEAD BATTERY (UNDER CHARGE)	Malfunction indicator illuminates.	Can be detected by CONSULT-III?	
Warranty symptom code	AG	AH	AJ	AK	AL	AM	A	ŀΡ	НА	Σ	Ca	
Fuel pump	5	5	5		5		5			1	1	_
Fuel filter							1					EC-22
Fuel injector	3	3	3		4		4	4		1	1	EC-133
Glow control system								1				EC-273
Engine body		3	3	3	3	1		3				<u>EM-18</u>
EGR system							3					EC-177, EC-190, EC-196
Air cleaner and duct							3					Refer to Service Manual
Fuel rail pressure relief valve	3	3	3		3		3			1	1	EC-91

						S'	YMPTO	DM					age	•
SYSTEM — Basic engine control system				DLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE	CONSUMPTION	MPTION		ABNORMAL SMOKE COLOR	R CHARGE)	es.	۲-۱۱۱۶	Reference page	A EC
		ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGIN	EXCESSIVE FUEL CONS	EXCESSIVE OIL CONSUMPTION	BLACK SMOKE	WHITE SMOKE	DEAD BATTERY (UNDER	Malfunction indicator illuminates.	n be detected by CONSULT-III?		D E F
Warı	ranty symptom code	AG	AH	AJ	AK	AL	AM	,	ΑP	НА		Can		0
	Fuel pump circuit	4	4	4		4					1	1	EC-239	G
	Fuel injector circuit	1	1	1		1		1	1		1	1	EC-133	
	Fuel injector adjustment value	1	1			1		1	1			1	EC-22	Н
	Mass air flow sensor circuit							1			1	1	<u>EC-94,</u> <u>EC-103</u>	
	Engine coolant temperature circuit	1	1		1			1			1	1	EC-115	
	Vehicle speed signal circuit										1	1	EL-111	
	Accelerator pedal position sensor circuit			1							1	1	EC-119, EC-147, EC-257	J
ROL	Fuel rail pressure sensor circuit							1			1	1	EC-128	
CONTROL	Crankshaft position sensor circuit	1	1								1	1	EC-152, EC-157	K
ENGINE	Camshaft position sensor circuit										1	1	EC-163, EC-168	L
Ш	Start signal circuit												EC-293	
	Ignition switch circuit												EC-71	
	Heat up switch circuit												EC-280	M
	Power supply for ECM circuit										1	1	EC-71	
	Cooling fan relay circuit				2								EC-138	Ν
	Glow relay circuit	1							1				EC-173	
	ECM relay (Self-shutoff) circuit											1	EC-220	
	ECM	2	2	2	2	2	2	2	2	2	2	2	EC-203, EC-218, EC-271	0
			I	I	1		1	1	1	1	1	1	I	

<sup>1 - 5:</sup> The numbers refer to the order of inspection.

# **Engine Control Component Parts Location**


INFOID:0000000003759326



JMBIA1284ZZ

- 1. Glow relay
- 4. Mass air flow sensor
- 7. Fuel injector
- 10. Fuel Pump

- 2. Cooling fan motor
- 5. Camshaft position sensor
- 8. Fuel rail pressure sensor
- 11. EGR volume control valve
- 3. Engine coolant temperature sensor
- 6. Glow plug
- 9. Fuel rail pressure relief valve
- 12. Fuel filter



- 1. Fuel pump temperature sensor
- 4. Fuel rail pressure sensor
- 2. Fuel pump

3. Fuel rail pressure relief valve

Α

EC

D

Е

G


Н


M

Ν

0


Ρ






Glow relay
 : Vehicle front


Engine coolant temperature sensor






1. Mass air flow sensor

2. Fuel injector







1. Glow plug connecting plate

e 2. Glow plug

3. Glow relay

: Vehicle front






1. Camshaft position sensor

⟨⇒ : Vehicle front

2. Crankshaft position sensor


probadordemodulos@gmail.com



ECM
 Yehicle front

2. PNP switch

3. PNP switch harness connector




1. Cooling fan motor connector

2. Cooling fan motor




3. Heat up switch


: Vehicle front




Accelerator pedal position sensor



2. Stop lamp switch







# **ECM Harness Connector Terminal Layout**

INFOID:0000000003759329

INFOID:0000000003759330







EC

C


D

PBIB3368E


#### **ECM** Terminal and Reference Value

#### **PREPARATION**

- 1. ECM (1) is located behind the instrument lower panel.
- 2. Remove ECM cover.



- 3. When disconnecting ECM harness connector, loosen it with levers as far as they will go as shown in the figure.
- Connect a break-out box and Y-cable adapter between the ECM and ECM harness connector.
  - Use extreme care not to touch 2 pins at one time.
  - Data is for comparison and may not be exact.



#### **ECM INSPECTION TABLE**

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

Ν

M

(

Ρ

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)			
+	_	Signal name		(Арргох.)			
1 (B) 2 (B) 3 (B)	_	ECM ground	_	_			
4 (L)	114	Fuel injector power supply (For cylinder No. 1 and 3)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed NOTE: The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 7.5 V ★    No.0 V/Div   20 ms/Div   T   MBIB1295E			
5 (P)	(B)	Fuel injector power supply (For cylinder No. 2 and 4)	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 8.0 V ★    Indicate   Property   Propert			
7 (OR)	114 (B)	EGR volume control valve (Close)	<ul> <li>[Ignition switch OFF]</li> <li>Warm-up condition</li> <li>For a few seconds after turning ignition switch OFF.</li> </ul>	1.0 - 2.0 V★  ↑↓ (Periodically changes)  BATTERY VOLTAGE  (11 - 14 V)  MBIB1783E			
8 (Y)	114 (B)	EGR volume control valve (Open)	<ul> <li>[Ignition switch OFF]</li> <li>Warm-up condition</li> <li>For a few seconds after turning ignition switch OFF.</li> </ul>	1.0 - 2.0 V★  ↑↓ (Periodically changes)  BATTERY VOLTAGE  (11 - 14 V)  MBIB1783E			

## < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)
+	-	Signal name		(Approx.)
10	444		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	Approximately 5.8 V ★  → S.0V/Div S ms/Div MBIB0885E
10 114 (G) (B)		Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 5.5 V *  MBIB0886E
13	114	Heat up switch	[Ignition switch ON] • Heat up switch: OFF	Approximately 0 V
(BR)	(B)	neat up switch	[Ignition switch ON] • Heat up switch: ON	BATTERY VOLTAGE (11 - 14 V)
21 (Y)		Fuel injector No. 4	[Engine is running]  • Warm-up condition  • Idle speed	Approximately 7.5 V ★
22 (R)	114	Fuel injector No. 4	NOTE: The pulse cycle changes depending on rpm at idle	>> 10.0 V/Div 20 ms/Div T MBIB1297E
23 (W)	(B)	(B) Fuel injector No. 2  Fuel injector No. 2		Approximately 8.0 V ★
24 (OR)			<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	≥≥ 10.0 V/Div 20 ms/Div T MBIB1298E
29	114	Fuel numn	[Engine is running] • Warm-up condition • Idle speed	Approximately 0.3 V *  221.0 V/Div 5 ms/Div MBIB0887E
(B) (B)		[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	Approximately 0.3 V	

http://probadordemodulos.wix.com/probadorautomotriz

	NAL NO.	Description	Condition	Value	
+	_	Signal name	os.isino.	(Approx.)	
37 (L)	114 (B)	Glow relay	Refer to <u>EC-173</u> .		
40 (G)		Fuel injector No. 3	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li><li>NOTE:</li></ul>	Approximately 7.5 V	
41 (BR)	114 (B)	Fuel injector No. 3	The pulse cycle changes depending on rpm at idle		MBIB1297E
42 (PU)		Fuel injector No. 1		Approximately 8.0 V	
43 (SB)		Fuel injector No. 1	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>		
45 (W)	66 (B)	Camshaft position sensor power supply	[Ignition switch ON]	Approximately 5 V	MBIB1298E
(,		очьы		Approximately 3.5 V	
46	65	Crankshaft position sensor	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>		MBIB0879E
(G)	(Y)	Craimonan position concor		Approximately 3.5 V	
			<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>		
			<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 4.7 V	MBIB0880E
47 (R)	66 (B)	Camshaft position sensor	rpm at idie	Approximately 4.7 V	MBIB0877E
			<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>		
					MBIB0878E

http://probadordemodulos.wix.com/probadorautomotriz

## < SERVICE INFORMATION >

	NAL NO. color)	Description	Condition	Value (Approx.)
+	-	Signal name	Signal name	
48 (W)	68	Fuel rail pressure sensor	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	1.4 - 1.7 V
49 (W)	` '		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	1.7 - 2.0 V
50 (BR)	69 (PU)	Fuel pump temperature sensor	[Engine is running]  • Warm-up condition	Approximately 0 - 4.8 V Output voltage varies with fuel pump temperature
51 (GY)	70 (LG)	Engine coolant temperature sensor	[Engine is running] • Warm-up condition	Approximately 0 - 4.8 V Output voltage varies with engine coolant temperature
			[Ignition switch ON]	Approximately 0.4 V
54	73	Mass air flow sensor	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	1.3 - 1.8 V
(G)	(B)	Wass all now series.	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Engine is revving from idle to about 4,000 rpm.</li> </ul>	1.3 - 1.8 V to Approximately 4.0 V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)
55 (W)	74 (R)	Intake air temperature sensor	[Engine is running] • Warm-up condition	Approximately 0 - 4.8 V Output voltage varies with intake air temperature
63 (R)	68 (B)	Fuel rail pressure sensor power supply	[Ignition switch ON]	Approximately 5 V
65 (Y)	_	Crankshaft position sensor ground	_	_
66 (B)	_	Camshaft position sensor ground	_	_
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_
68 (B)	_	Fuel rail pressure sensor ground	_	_
69 (PU)	_	Fuel pump temperature sensor ground	_	_
70 (LG)	_	Engine coolant temperature sensor ground	_	_
73 (B)	_	Mass air flow sensor ground	_	_
74 (R)	_	Intake air temperature sensor ground	_	_
77 (SB)	_	EGR volume control valve control position sensor ground	_	_
81 (P)	77 (SB)	EGR volume control valve control position sensor	<ul> <li>[Ignition switch OFF]</li> <li>Warm-up condition</li> <li>For a few seconds after turning ignition switch OFF.</li> </ul>	Voltage should fluctuates between 0.5 and 2.5 V, then drop to 0V.
82 (W)	84 (R)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V

RMINAL NO. (Wire color)	Description	Condition	Value
+ -	Signal name		(Approx.)
33 84	Accelerator pedal position sensor	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully released	0.5 - 1.0 V
B) (R)	1	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully depressed	3.7 - 4.7 V
B4 R)	Accelerator pedal position sensor 1 ground	_	_
B7 P) —	CAN communication line	_	_
39 114 .G) (B)	Data link connector	_	_
90 92 (L) (Y)	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5 V
91 92	Accelerator pedal position sensor	<ul><li>[Ignition switch ON]</li><li>Engine: Stopped</li><li>Accelerator pedal: Fully released</li></ul>	0.15 - 0.6 V
G) (Y)	2	<ul><li>[Ignition switch ON]</li><li>Engine: Stopped</li><li>Accelerator pedal: Fully depressed</li></ul>	1.85 - 2.4 V
92 Y) —	Accelerator pedal position sensor 2 ground	_	_
95 (L) —	CAN communication line	_	_
99 114	Start cianal	[Ignition switch ON]	Approximately 0 V
(B)	Start signal	[Ignition switch START]	BATTERY VOLTAGE (11 - 14 V)
00 114	Stop lamp switch	[Ignition switch OFF] • Brake pedal: Fully released	Approximately 0 V
GY) (B)	Cop lamp officer	[Ignition switch OFF] • Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14 V)
05 114	ECM relay (self shut-off)	<ul><li>[Ignition switch ON]</li><li>[Ignition switch OFF]</li><li>For a few seconds after turning ignition switch OFF</li></ul>	0 - 1.0 V
G) (B)	,	<ul> <li>[Ignition switch OFF]</li> <li>More than a few seconds after turning ignition switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14 V)
07 (L) 114 08 (B)	Ignition switch	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)
10 114	Dark/neutral position switch	[Ignition switch ON] • Shift lever: Neutral	Approximately 0 V
BR) (B)	Park/neutral position switch	[Ignition switch ON] • Except the above position	BATTERY VOLTAGE (11 - 14 V)
13 114 C) (B)	ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V
G) (B)		[Ignition switch OFF] • More than a few seconds after turning	BATTERY VOLTAGE (11 - 14 V)

http://probadordemodulos.wix.com/probadorautomotriz

## TROUBLE DIAGNOSIS

## < SERVICE INFORMATION >

[YD25DDTi]

Α

C

D

Е

G

Н

K

M

	NAL NO. color)	Description	Condition	Value (Approx.)
+	_	Signal name		(Αρρίολ.)
114 (B)	_	ECM ground	_	_
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)
121 (L)	114 (B)	Power supply for ECM (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14 V)

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# **CONSULT-III Function (ENGINE)**

INFOID:0000000003759331

#### **FUNCTION**

Diagnostic test mode Function			
Work support  This mode enables a technician to adjust some devices faster and more accurately by follow dications on the CONSULT-III unit.			
Self-Diagnostic Results	Self-diagnostic results such as 1st/2nd trip DTC, DTC and freeze frame data can be read and erased quickly.*		
Data Monitor	Input/Output data in the ECM can be read.		
Active Test	Diagnostic Test Mode in which CONSULT-III drives some actuators apart from the ECMs and also shifts some parameters in a specified range.		
Function Test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.		
ECM Part Number	ECM part number can be read.		

<sup>\*:</sup> The following emission-related diagnostic information is cleared when the ECM memory is erased.

- · Diagnostic trouble codes
- 1st/2nd trip diagnostic trouble codes
- · Freeze frame data

#### ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

Ρ

0

				DIAGNOSTIC TEST MODE			
			SELF-DIA	G RESULTS	DATA		
	Item			FREEZE FRAME DATA	MONITOR	ACTIVE TEST	
		Crankshaft position sensor	×	×	×		
		Camshaft position sensor	×				
		Engine coolant temperature sensor	×	×	×	×	
m		Vehicle speed sensor	×	×	×		
'RT		Fuel pump temperature sensor	×		×	×	
Τ Ρ		Accelerator pedal position sensor 1	×		×		
ENGINE CONTROL COMPONENT PARTS		Accelerator pedal position sensor 2	×		×		
<u>S</u>		Fuel rail pressure sensor	×		×		
NO.	INPUT	Mass air flow sensor	×	×	×		
2L C	INFOI	Intake air temperature sensor	×	×			
ĪŘ		Battery voltage	×		×		
S		Park/neutral position (PNP) switch	×		×		
Ä		EGR volume control valve control position sensor	×		×		
<u>8</u>		Stop lamp switch	×		×		
ш		Heat up switch			×		
		Ignition switch (Start signal)			×		
		Air conditioner switch signal			×		
		Barometric pressure sensor (built-into ECM)	×		×		
		Fuel pump	×		×	×	
		Fuel injector	×		×	×	
	OUTPUT	Glow relay	×		×	×	
		Cooling fan relay	×		×	×	
		EGR volume control valve	×		×	×	

X: Applicable

## **WORK SUPPORT MODE**

#### Work Item

WORK ITEM	DESCRIPTION	USAGE
ENTER INJCTR CALIB DATA	Injector adjustment value is written onto ECM memory.	When performing Injector Adjustment Value Registration.
EGR/V LEARN CLR	EGR volume control valve learning value stored in ECM is cleared.	<ul> <li>EGR volume control valve closed position learning value should be cleared under the following cases.</li> <li>EGR volume control valve is removed.</li> <li>EGR volume control valve is replaced.</li> </ul>
INJ ADJ VAL CLR	Injector adjustment value stored in ECM is initialized.	Before changing injector adjust- ment value stored in ECM, it is recommended to perform this work item.

## **SELF-DIAGNOSTIC MODE**

<sup>\*:</sup> This item includes 1st/2nd trip DTCs.

## **TROUBLE DIAGNOSIS**

# < SERVICE INFORMATION > [YD25DDTi]

Self Diagnostic Item

Regarding items of DTC and 1st/2nd trip DTC, refer to EC-32, "Emission-Related Diagnostic Information".

#### Freeze Frame Data

Freeze frame data item	Description		
DIAG TROUBLE CODE [PXXXX]	The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to EC-32, "Emission-Related Diagnostic Information".)		
CAL/LD VALUE [%]  • The calculated load value at the moment a malfunction is detected is displayed.			
COOLANT TEMP [°C] or [°F]	The engine coolant temperature at the moment a malfunction is detected is displayed.		
ENGINE SPEED [rpm]	The engine speed at the moment a malfunction is detected is displayed.		
VEHICL SPEED [km/h] or [mph]	The vehicle speed at the moment a malfunction is detected is displayed.		
INT/A TEMP SE [°C] or [°F]	• The intake air temperature at the moment a malfunction is detected is displayed.		
FUEL/R PRESS [kPa]	The fuel rail pressure at the moment a malfunction is detected is displayed.		
MASS AIRFLOW [g/s]	[g/s] • The mass air flow at the moment a malfunction is detected is displayed.		

## DATA MONITOR MODE

Monitored item	Unit	Description	Remarks
CKPS-RPM (TDC)	[rpm]	The engine speed computed from the crank- shaft position sensor signal is displayed.	
COOLAN TEMP/S	[°C] or [°F]	The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed.	When the engine coolant temperature circuit is open or short, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
VHCL SPEED SE	[km/h] or [mph]	The vehicle speed computed form the vehicle speed sensor signal is displayed.	
FUEL TEMP SEN	[°C] or [°F]	The fuel temperature (determined by the signal voltage of the fuel pump temperature sensor) is displayed.	
ACCEL POS SEN	[V]	The accelerator pedal position sensor 1 signal voltage is displayed.	
ACCEL SEN 2	[V]	The accelerator pedal position sensor 2 signal voltage is displayed.	
ACT CR PRESS	[MPa]	The Fuel rail pressure (determined by the signal voltage of the fuel rail pressure sensor) is displayed.	
BATTERY VOLT	[V]	The power supply voltage of ECM is displayed.	
P/N POSI SW	[ON/OFF]	<ul> <li>Indicates [ON/OFF] condition from the park/ neutral position switch signal.</li> </ul>	
START SIGNAL	[ON/OFF]	indicates [ON/OFF] condition from the starter signal.	
AIR COND SIG	[ON/OFF]	<ul> <li>Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.</li> </ul>	
BRAKE SW	[ON/OFF]	indicates [ON/OFF] condition from the stop lamp switch signal.	
IGN SW	[ON/OFF]	Indicates [ON/OFF] condition from ignition switch signal.	
WARM UP SW	[ON/OFF]	Indicates [ON/OFF] condition from heat up switch signal.	

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

Α

EC

D

C

Е

F

G

Н

K

L

M

Ν

0

Ρ

## < SERVICE INFORMATION >

Monitored item	Unit	Description	Remarks
MAS AIR/FL SE	[V]	The signal voltage of the mass air flow sensor is displayed.	
MAIN INJ WID	[msec]	Indicates the actual main fuel injection pulse width compensated by ECM according to the input signals.	
PUMP CURRENT	[mA]	Indicates the fuel pump power supply current from the ECM.	
GLOW RLY	[ON/OFF]	The glow relay control condition (determined by ECM according to the input signal) is dis- played.	
COOLING FAN*	[LOW/HI/OFF]	Indicates the control condition of the cooling fans (determined by ECM according to the input signal).  LOW: Operates at low speed.  HI: Operates at high speed.  OFF: Stopped	
INT/A VOLUME	[mg/]	The intake air volume computed from the mass air flow sensor signal is displayed.	
BARO SEN	[kPa]	The barometric pressure (determined by the signal voltage from the absolute pressure sensor built into the ECM) is displayed.	
CYL COUNT	[1/2/3/4]	The cylinder being injected is displayed. Cylinder No.1 is injected. Cylinder No.2 is injected. Cylinder No.3 is injected. Cylinder No.4 is injected.	
TRVL AFTER MIL	[km] or [mile]	Distance traveled while MI is activated.	
EGR/V ANGLE	[°]	<ul> <li>The opening angle of EGR volume control value is displayed.</li> <li>The opening becomes larger as the value increases.</li> </ul>	
EGR V/POS SEN	[mV]	The EGR volume control valve control position sensor signal voltage is displayed.	

#### NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

#### **ACTIVE TEST MODE**

TEST ITEM	CONDITION	JUDGMENT	CHECK ITEM (REMEDY)
POWER BAL- ANCE	Engine: After warming up, idle the engine.     A/C switch: OFF     Shift lever: Neutral position     Cut off each injector signal one at a time using CONSULT-III.	Engine runs rough or dies.	Harness and connectors     Compression     Fuel injector
ENG COOLANT TEMP	Engine: Return to the original trouble condition     Change the engine coolant temperature using CONSULT-III.	If trouble symptom disappears, see CHECK ITEM.	Harness and connectors     Engine coolant temperature sensor     Fuel injector
GLOW RLY	Ignition switch: ON (Engine stopped)     Turn the glow relay ON and OFF using CONSULT-III and listen to operating sound.	Glow relay makes the operating sound.	Harness and connectors     Glow relay

<sup>\*:</sup> The cooling fan rotation has two stages (OFF and ON) although the display of CONSULT-III has three stages (OFF,LOW and HI).

## **TROUBLE DIAGNOSIS**

#### < SERVICE INFORMATION >

[YD25DDTi]

Α

D

Е

G

Н

M

Ν

Ρ

TEST ITEM	CONDITION	JUDGMENT	CHECK ITEM (REMEDY)
FUEL/T TEMP SEN	Engine: Return to the original trouble condition     Change the fuel tank temperature using CONSULT-III.	If trouble symptom disappears, see CHECK ITEM.	Harness and connectors     Fuel tank temperature sensor     Fuel injector
PRES REGULA- TOR	Ignition switch: ON     Change fuel rail pressure using CONSULT-III.	Fuel leaks.	Fuel line     Fuel pressure relief valve
PUMP LEANT CLEAR	This mode is used for performing Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".    Value Clearing   Value Clearin		
TRG EGR/V AN- GLE	Ignition switch: ON     Change EGR volume control valve opening angle (within the range of 0 - 70°) using CONSULT-III.	EGR volume control valve makes an operating sound.	Harness and connectors     EGR volume control valve

# Generic Scan Tool (GST) Function

INFOID:0000000003759332

#### **DESCRIPTION**

Generic Scan Tool (OBD II scan tool) complying with ISO 15031-4 has 7 different functions explained below. ISO9141 is used as the protocol.

The name "GST" or "Generic Scan Tool" is used in this service manual.




#### **FUNCTION**

Diagnostic test mode		Function	
Service \$01	READINESS TESTS	This diagnostic service gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.	
Service \$02	(FREEZE DATA)	This diagnostic service gains access to emission-related data value which were stored by ECM during the freeze frame. For details, refer to EC-32, "Emission-Related Diagnostic Information".	
Service \$03	DTCs	This diagnostic service gains access to emission-related power train trouble codes which were stored by ECM.	
Service \$04	CLEAR DIAG INFO	This diagnostic service can clear all emission-related diagnostic information. This includes:  Clear number of diagnostic trouble codes (Service \$01)  Clear diagnostic trouble codes (Service \$03)  Clear trouble code for freeze frame data (Service \$01)  Clear freeze frame data (Service \$02)  Reset status of system monitoring test (Service \$01)  Clear on board monitoring test results (Service \$07)	
Service \$06	(ON BOARD TESTS)	This diagnostic service is not applicable on this vehicle.	
Service \$07	(ON BOARD TESTS)	This diagnostic service enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.	
Service \$09	(CALIBRATION ID)	This diagnostic service enables the off-board test device to request specific vehicle information such as Vehicle Identification Number (VIN) and Calibration IDs.	


#### INSPECTION PROCEDURE

1. Turn ignition switch OFF.

- 2. Connect "GST" to data link connector (1), which is located under drivers side dash panel.
- 3. Turn ignition switch ON.



- 4. Enter the program according to instruction on the screen or in the operation manual.
- (\*: Regarding GST screens in this section, sample screens are shown.)



Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.

**OBD II FUNCTIONS** 

F0: DATA LIST

F1: FREEZE DATA

F2: DTCs

F3: SNAPSHOT

F4: CLEAR DIAG INFO

F5: O2 TEST RESULTS F6: READINESS TESTS

F7: ON BOARD TESTS

F8: EXPAND DIAG PROT

F9: UNIT CONVERSION

Sample screen\* SEF416S

## CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759333

#### Remarks:

- 1 Specification data are reference values.
- 1 Specification data are output/input values which are detected or supplied by the ECM at the connector.

\* Specification data may not be directly related to their components signals/values/operations.

MONITOR ITEM	CONDITION		SPECIFICATION
CKPS-RPM (TDC)	Run engine and compare CONSULT-III value with the tachometer indication.		Almost the same speed as the ta- chometer indication
COOLAN TEMP/S	Engine: After warming up		More than 70°C (158°F)
VHCL SPEED SE	Turn drive wheels and compare CONSULT-III value with the speed- ometer indication		Almost the same speed as the speed- ometer indication
FUEL TEMP SEN	Engine: After warming up		More than 40°C (104°F)
ACCEL POS SEN*1	Ignition switch: ON     (Engine stopped)	Accelerator pedal: Fully released	0.5 - 1.0 V
ACCEL POS SEN		Accelerator pedal: Fully depressed	4.0 - 4.8 V
ACCEL SEN 2*1	Ignition switch: ON     (Engine stopped)	Accelerator pedal: Fully released	0.3 - 1.2 V
		Accelerator pedal: Fully depressed	3.7 - 4.8 V
ACT CR PRESS	<ul><li>Engine: After warming up</li><li>Air conditioner switch: OFF</li><li>Shift lever: Neutral</li><li>No load</li></ul>	Idle	25 - 35 MPa
		2,000 rpm	50 - 60 MPa

http://probadordemodulos.wix.com/probadorautomotriz

MONITOR ITEM	CONDITION		SPECIFICATION
BATTERY VOLT	Ignition switch: ON (Engine stopped)		11 - 14 V
P/N POSI SW	• Ignition switch: ON	Shift lever: Neutral	ON
	Ignition switch: ON	Except above	OFF
START SIGNAL	<ul> <li>Ignition switch: ON → START –</li> </ul>	→ ON	$OFF \to ON \to OFF$
	Foreign Afternoons in the control of the	Air conditioner switch: OFF	OFF
AIR COND SIG	Engine: After warming up, idle the engine	Air conditioner switch: ON (Compressor operates.)	ON
DD AVE CW	Inviting assistate ONI	Brake pedal: Fully released	OFF
BRAKE SW	Ignition switch: ON	Brake pedal: Slightly depressed	ON
IGN SW	<ul> <li>Ignition switch: ON → OFF</li> </ul>		$ON \rightarrow OFF$
A/ADAALID OM/	1 11 21 21	Heat up switch: OFF	OFF
WARM UP SW	Ignition switch: ON	Heat up switch: ON	ON
		Ignition switch: ON (Engine stopped)	Approximately 0.4 V
	<ul> <li>Engine: After warming up</li> <li>Air conditioner switch: OFF</li> </ul>	Idle	1.3 - 1.8 V
MAS AIR/FL SE*1	Shift lever: Neutral     No load	Engine is revving from idle to about 4,000 rpm.	1.3 - 1.8 V to Approximately 4.0 V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)
	Engine: After warming up     Shift lever: Neutral     Idle speed	No load	0.50 - 0.70 msec
MAIN INJ WID		Blower fan switch: ON	0.50 - 0.80 msec
	Engine: After warming up     Air conditioner switch: OFF     Shift lever: Neutral     No load	Idle	1,600 - 2,000 mA
PUMP CURRENT		2,000 rpm	1,500 - 1,900 mA
GLOW RLY	Refer to EC-273.		
	When cooling fan is stopped.		OFF
COOLING FAN*2	When cooling fans operate at low speed.		LOW
	When cooling fans operate at high speed.		HI
NT/A VOLUME	Engine: After warming up, idle the engine		150 - 450 mg/
BARO SEN	• Ignition switch: ON		Altitude Approx. 0m: Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m: Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m: Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m: Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)
CYL COUNT	Engine is running		$1 \to 3 \to 4 \to 2$
TRVL AFTER MIL	Ignition switch: ON	Vehicle has traveled after MI has turned ON.	0 - 65,535 km (0 - 40,723 mile)
EGR/V ANGLE	Ignition switch: ON (Engine stopped)		Approx. 0°
EGR V/POS SEN	Ignition switch: ON (Engine stopped)		1,050 - 1,350 mV

#### NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

<sup>\*1:</sup> This signal is converted by ECM internally. Thus, this differs from ECM terminals voltage.

<sup>\*2:</sup> The cooling fan rotation has two stages (OFF and ON) although the display of CONSULT-III has three stages (OFF,LOW and HI).

[YD25DDTi]

# TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

Description INFOID:000000003759334

Intermittent incidents may occur. In many cases, the incident resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st/2nd trip) DTC visits. Realize also that the most frequent cause of intermittent incidents occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific malfunctioning area.

#### COMMON INTERMITTENT INCIDENTS REPORT SITUATIONS

STEP in Work Flow	Situation		
II	The CONSULT-III is used. The SELF-DIAG RESULTS screen shows time data other than "0".		
III	The symptom described by the customer does not recur.		
IV	(1st/2nd trip) DTC does not appear during the DTC Confirmation Procedure.		
VI	The Diagnostic Procedure for XXXX does not indicate the malfunctioning area.		

# **Diagnosis Procedure**

INFOID:0000000003759335

## 1.INSPECTION START

Erase (1st/2nd trip) DTCs. Refer to EC-32, "Emission-Related Diagnostic Information".

>> GO TO 2.

# 2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection. Refer to EC-81, "Ground Inspection".

#### OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

# 3. SEARCH FOR ELECTRICAL INCIDENT

Perform "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" in GI section, "INCIDENT SIMULATION TESTS".

#### OK or NG

OK >> INSPECTION END

NG >> Repair or replace.

[YD25DDTi]

Α

EC

D

Е

F

Н


K


M

# POWER SUPPLY AND GROUND CIRCUIT

Wiring Diagram

LHD MODELS





Specification data are reference values and are measured between each terminal and ground.

# < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)
+	_	Signal name	1	(дрргох.)
105 114 (G) (B)	114 (B)	ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V
	(В)		[Ignition switch OFF]  • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)
107 (L) 108 (L)	114 (B)	Ignition switch	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)
113 114 (G) (B)		ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V
	(B)		[Ignition switch OFF]  • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)
121 (L)	114 (B)	Power supply for ECM (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14 V)

Α

EC

C

D

Е

Н

K

M


Ν


0

Ρ

LHD MODELS







GEC598A

Specification data are reference values and are measured between each terminal and ground.

http://probadordemodulos.wix.com/probadorautomotriz


## **POWER SUPPLY AND GROUND CIRCUIT**

< SERVICE INFORMATION >

[YD25DDTi]

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)
+	_	Signal name		(другох.)
1 (B) 2 (B) 3 (B)	_	ECM ground	_	_
114 (B)	_	ECM ground	_	_

**RHD MODELS** 



Specification data are reference values and are measured between each terminal and ground.

GEC599A


Ρ

## < SERVICE INFORMATION >

	NAL NO. color)	Description	Condition	Value (Approx.)
+	_	Signal name		(дргох.)
105	114 (B)	ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V
(G) (B)			[Ignition switch OFF]  • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)
107 (L) 108 (L)	114 (B)	Ignition switch	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)
113	114 (B)	ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V
(G) (B)			[Ignition switch OFF]  • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)
121 (L)	114 (B)	Power supply for ECM (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14 V)

**RHD MODELS** 





Specification data are reference values and are measured between each terminal and ground.

http://probadordemodulos.wix.com/probadorautomotriz

GEC600A

С

D

Α

EC

Е

G

Н

ı

K

-

M

Ν

0

## < SERVICE INFORMATION >

	TERMINAL NO. (Wire color) Description		Condition	Value (Approx.)
+	_	Signal name		(Approx.)
1 (B) 2 (B) 3 (B)	_	ECM ground	_	_
114 (B)	_	ECM ground	_	_

## Diagnosis Procedure

INFOID:0000000003759337


# 1. CHECK GROUND CONNECTIONS

- 1. Turn ignition switch OFF.
- 2. Loosen and retighten ground screws on the body. Refer to EC-82, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.



# $2.\mathsf{CHECK}$ ECM GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Disconnect ECM harness connector.
- 2. Check the continuity between ECM harness connector and ground.

E	СМ	Ground	Continuity	
Connector	Connector Terminal		Continuity	
	1		Existed	
M32	2	Ground		
	3	Ground		
M33	114			

3. Also check harness for short to power.

### OK or NG

OK >> GO TO 3.

NG >> Repair open or short to power in harness or connectors.

# 3. CHECK ECM POWER SUPPLY CIRCUIT-I

- 1. Reconnect ECM harness connector.
- 2. Turn ignition switch ON.
- 3. Check voltage between ECM connector terminal as follows.

## POWER SUPPLY AND GROUND CIRCUIT

### < SERVICE INFORMATION >

[YD25DDTi]

	+	-	_	Voltage
Connector	Terminal	Connector	Terminal	
			1	
	107	M32	2	Battery voltage
			3	
M33		M33	114	
WIJJ	400		1	
		M32	2	
	108		3	
		M33	114	

OK or NG

OK >> GO TO 5. NG >> GO TO 4.

## 4. DETECT MALFUNCTIONING PART

Check the following.

- 10A fuse (No.21)
- 40A fusible link (letter f)
- Harness connectors E101, M5
- Fuse block harness connector M12
- Ignition switch
- Ignition switch harness connector M20
- Harness for open or short between ECM and fusible link

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 5. CHECK ECM POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.

Check the voltage between ECM connector terminal as follows.

	E			
	+	Voltage		
Connector	Terminal	Connector	Terminal	
			1	
M33	121	M32	2	Pottory voltage
WISS			3	Battery voltage
		M33	114	

## OK or NG

OK >> GO TO 7. NG >> GO TO 6.

## 6. DETECT MALFUNCTIONING PART

Check the following.

- 20A fuse (No.36)
- Harness connectors E102, M13
- · Harness for open or short between Battery and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

## 7. CHECK ECM POWER SUPPLY CIRCUIT-III

http://www.idiorclevin.cid.oldps.anix..ooim/pleasadosectoriostriz

probadordemodulos@gmail.com

**EC-79** 

EC

Α

D

Е

Н

M

Ν

## < SERVICE INFORMATION >

- 2. Turn ignition switch ON and then turn OFF.
- 3. Check the voltage between ECM harness connector.

	ECM			
-	+		-	Voltage
Connector	Terminal	Connector	Terminal	
			1	
	119	M32	2	
			3	
M33		M33	114	After turning ignition switch OFF, battery voltage will
IVI33		M32	1	exist for a few seconds, then drop approximately 0 V.
			2	
			3	
		M33	114	

### OK or NG

OK >> GO TO 16.

NG >> GO TO 8.

## 8. CHECK ECM POWER SUPPLY CIRCUIT-IV

Check the voltage between ECM relay harness connector and ground.

ECM	relay	Ground	Voltage	
Connector	Connector Terminal		voltage	
E55	2	Ground	Battery voltage	
L33	3	Ground	Battery voltage	

### OK or NG

OK >> GO TO 10. NG >> GO TO 9.

# 9. DETECT MALFUNCTIONING PART

Check the following.

- 20A fuse (No.36)
- Harness for open or short between Battery and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 10. CHECK ECM POWER SUPPLY CIRCUIT-V

Check the voltage between ECM harness connector.

ECM

ī	+	_	-	Voltage
Connector	Terminal	Connector	Terminal	
			1	
	405	M32	2	
	105		3	
M33		M33	114	D-#
IVISS			1	Battery voltage
	440	M32	2	
	113		3	

http://probadordemodulos.wix.com/probadordutomotriz

probadordemodulos@gmail.com

## POWER SUPPLY AND GROUND CIRCUIT

### [YD25DDTi] < SERVICE INFORMATION >

OK or NG

OK >> GO TO 13.

NG >> GO TO 11.

# 11. CHECK ECM POWER SUPPLY CIRCUIT-VI

- Disconnect ECM harness connector.
- Disconnect ECM relay.
- Check the continuity between ECM harness connector and ECM relay harness connector.

ECM		ECM	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
M33	105	E55	1	Existed
IVISS	113	E33	ı	Existed

Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 13.

NG >> GO TO 12.

# 12.detect malfunctioning part

Check the following.

- Harness connectors E102, M13
- Harness for open or short between ECM and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 13. CHECK ECM POWER SUPPLY CIRCUIT-VII

- 1. Disconnect ECM harness connector.
- Disconnect ECM relay harness connector.
- 3. Check the continuity between ECM harness connector and ECM relay harness connector.

ECM		ECM	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
M33	119	E55	F	Existed
IVISS	120	£33	5	LXISted

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 15. >> GO TO 14. NG

14. DETECT MALFUNCTIONING PART

## Check the following.

- Harness connectors E91, M241 (LHD models)
- Harness connectors E102, M13 (RHD models)
- Harness for open or short between ECM and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 15. CHECK ECM RELAY

Refer to EC-82

OK >> GO TO 16.

NG >> Replace ECM relay.

## 16. CHECK INTERMITTENT INCIDENT

http://wobadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

EC

Α

F

Н

M

Ν

### >> INSPECTION END


## Component Inspection


### INFOID:0000000003855839


### **ECM RELAY**

- Disconnect ECM relay.
- Check continuity between ECM relay terminals under the following conditions.

Terminals	Conditions	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Existed
o ana o	No current supply	Not existed







PRIRO098F

## **Ground Inspection**

INFOID:0000000003759338

Ground connections are very important to the proper operation of electrical and electronic circuits. Ground connections are often exposed to moisture, dirt and other corrosive elements. The corrosion (rust) can become an unwanted resistance. This unwanted resistance can change the way a circuit works.

Electronically controlled circuits are very sensitive to proper grounding. A loose or corroded ground can drastically affect an electronically controlled circuit. A poor or corroded ground can easily affect the circuit. Even when the ground connection looks clean, there can be a thin film of rust on the surface.

When inspecting a ground connection follow these rules:

- · Remove the ground bolt or screw.
- Inspect all mating surfaces for tarnish, dirt, rust, etc.
- Clean as required to assure good contact.
- Reinstall bolt or screw securely.
- Inspect for "add-on" accessories which may be interfering with the ground circuit.
- If several wires are crimped into one ground eyelet terminal, check for proper crimps. Make sure all of the wires are clean, securely fastened and providing a good ground path. If multiple wires are cased in one eyelet make sure no ground wires have excess wire insulation.

For detailed ground distribution information, refer to GROUND DISTRIBUTION in EL section.

# **Ground Inspection** Remove bolt (screw). Inspect mating surfaces Reinstall bolt (screw) for tarnish, dirt, rust, etc. securely. Clean as required to assure good contact.

PBIB1870E

## DTC U1000 CAN COMMUNICATION LINE

< SERVICE INFORMATION >

[YD25DDTi]

## DTC U1000 CAN COMMUNICATION LINE

Description INFOID:0000000003759339

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

EC

C

D

Е

G

Н

Α

On Board Diagnosis Logic

INFOID:0000000003759340

This self-diagnosis has the one trip detection logic. The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) for 2 seconds or more.	Harness or connectors     (CAN communication line is open or shorted)

### DTC Confirmation Procedure

INFOID:0000000003759341

- Turn ignition switch ON and wait at least 3 seconds. 1.
- Check DTC. 2.
- If DTC is detected, go to EC-84, "Diagnosis Procedure".

K

M


Ν


Wiring Diagram

INFOID:0000000003759342

## EC-CAN-01







GEC601A

INFOID:0000000003759343

Diagnosis Procedure

Go to EL-110, "CAN System Specification Chart".

http://probadordemodulos.wix.com/probadorautomotriz

## DTC P0016 CKP - CMP CORRELATION

## On Board Diagnosis Logic

INFOID:0000000003759344

NOTE:

If DTC P0016 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to EC-214.

Е

M

Ν

0

Р

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0016 0016	Crankshaft position - camshaft position cor- relation	The correlation between crankshaft position sensor signal and camshaft position sensor signal is out of the normal range.	( 'rankehatt noeition concor

### **DTC Confirmation Procedure**

INFOID:0000000003759345

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and let it idle for at least 5 seconds.
- 2. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-85, "Diagnosis Procedure".</u>

## Diagnosis Procedure

INFOID:0000000003759346

## 1. CHECK CAMSHAFT POSITION SENSOR

Refer to EC-166, "Component Inspection".

OK or NG

OK >> GO TO 2.

NG >> Replace camshaft position sensor.

2.CHECK SPROCKET

Visually check for chipping signal plate gear tooth.

OK or NG

OK >> GO TO 3.

NG >> Remove debris and clean the signal plate or replace sprocket.

3.CHECK CRANKSHAFT POSITION SENSOR

Refer to EC-156, "Component Inspection".

OK or NG

OK >> GO TO 4.

NG >> Replace crankshaft position sensor.

4.CHECK GEAR TOOTH

Visually check for chipping signal plate gear tooth.

OK or NG

OK >> GO TO 5.

NG >> Replace the signal plate.

5. CHECK TIMING CHAIN

Refer to EM-5.

OK or NG

OK >> GO TO 6.

NG >> Replace timing chain.

6. CHECK INTERMITTENT INCIDENT

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

## **DTC P0016 CKP - CMP CORRELATION**

< SERVICE INFORMATION > Refer to  $\underline{\text{CC-}70}$ .

[YD25DDTi]

>> INSPECTION END

## DTC P0088 FUEL SYSTEM

## On Board Diagnosis Logic

INFOID:0000000003759355

Α

EC

Е

Н

NOTE:

If DTC P0088 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to EC-214.

Possible cause	
n	

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0088 0088	Fuel rail pressure too high	Fuel pressure is too much higher than the specified value.	Fuel pump     Fuel injector     Fuel rail pressure sensor

## **DTC Confirmation Procedure**

INFOID:0000000003759356

NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and warm it up to normal operating temperature.
- 2. Keep engine speed more than 2,000 rpm for at least 20 seconds.
- 3. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-87, "Diagnosis Procedure"</u>.

## Diagnosis Procedure

INFOID:0000000003759357

1. CHECK FUEL RAIL PRESSURE SENSOR

Refer to EC-131, "Component Inspection".

OK or NG

OK >> GO TO 2.

NG >> Replace fuel rail.

2.CHECK FUEL INJECTOR

Refer to EC-137, "Component Inspection".

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.

3. REPLACE FUEL INJECOR

- 1. Replace fuel injector of malfunctioning cylinder.
- Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".

### >> INSPECTION END

## 4.CHECK FUEL PUMP

Ν

Refer to EC-208, "Component Inspection".

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

REPLACE FUEL PUMP

Replace fuel pump.

2. Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

### >> INSPECTION END

## 6. CHECK INTERMITTENT INCIDENT

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

## **DTC P0088 FUEL SYSTEM**

< SERVICE INFORMATION > [YD25DDTi]

Refer to EC-70.

## >> INSPECTION END

Removal and Installation

FUEL INJECTOR Refer to EM-8.

**FUEL PUMP** 

Refer to EC-24.

## DTC P0089 FUEL PUMP

## On Board Diagnosis Logic

INFOID:0000000003759359

Α

EC

D

L

 $\mathbb{N}/\mathbb{I}$ 

Ν

NOTE:

If DTC P0089 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to EC-214.

	_ C
Possible cause	_
oump	

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0089 0089	Fuel pump performance	Fuel pressure is too much higher than the target value.	Fuel pump     Air mixed with fuel     Lack of fuel     Fuel rail pressure sensor

## **DTC Confirmation Procedure**

INFOID:0000000003759360

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Start engine and warm it up to normal operating temperature.
- Let engine idle for at least 30 seconds.
- Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-89</u>, "<u>Diagnosis Procedure</u>".

## Diagnosis Procedure

INFOID:000000000375936

# 1. PERFORM FUEL PUMP LEARNING VALUE CLEARING

### NOTE:

If the DTC is detected because of air mixed with fuel (i.e.: caused by lack of fuel), it may become normal by performing following procedure.

### With CONSULT-III

- Turn ignition switch ON.
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
- Start engine and let it idle for at least 60 seconds.
- Select "SELF-DIAG RESULT" mode with CONSULT-III.
- Touch "ERASE".
- 6. Perform EC-89, "DTC Confirmation Procedure", again.
- 7. Is 1st trip DTC detected again?

## With GST

- 1. Turn ignition switch ON.
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
- Start engine and let it idle for at least 60 seconds.
- Select Service \$04 with GST.
- Perform EC-89, "DTC Confirmation Procedure", again.
- 6. Is 1st trip DTC detected again?

### Yes or No

Yes

No

>> GO TO 2. >> INSPECTION END

## 2. CHECK FUEL RAIL PRESSURE SENSOR

## Refer to EC-131, "Component Inspection".

## OK or NG

OK >> GO TO 3.

NG >> Replace fuel rail.

## 3.CHECK FUEL PUMP

Perform EC-205, "DTC Confirmation Procedure".

probadordemodulos@gmail.com

http://probadordemodulos.wix.com/probadorautomotriz

## **DTC P0089 FUEL PUMP**

< SERVICE INFORMATION > [YD25DDTi]

## OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

## 4. REPLACE FUEL PUMP

- 1. Replace Fuel pump.
- 2. Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

### >> INSPECTION END

# 5.CHECK INTERMITTENT INCIDENT

Refer to EC-70.

## >> INSPECTION END

## Removal and Installation

INFOID:0000000003759362

FUEL PUMP Refer to EC-24.

## DTC P0093 FUEL SYSTEM

## On Board Diagnosis Logic

INFOID:0000000003759363

NOTE:

If DTC P0093 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to **EC-214**.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0093 0093	Fuel system leak	ECM detects a fuel system leak. (The relation between the output voltage to the fuel pump and input voltage from the fuel rail pressure sensor is out of the normal range.)	Fuel pump     Fuel rail     Fuel pipe     Fuel rail pressure relief valve     Air mixed with fuel     Lack of fuel

## **Overall Function Check**

INFOID:0000000003759364

Use this procedure to check the overall function of the fuel system. During this check, a 1st trip DTC might not be confirmed.

### NOTE:

- Make sure that there is no fire hazard near the vehicle.
- Before performing the following procedure, cool down engine.

## (III) WITH CONSULT-III

- Open engine hood and check if there are any signs of fuel leakage or not. If there are any signs, go to EC-92, "Diagnosis Procedure". If there is no signs, go to next step.
- Check oil level.

If oil level is above the proper range, go to EC-92, "Diagnosis Procedure". If oil level is within the proper range, go to next step.

- Start engine and check fuel leakage in the engine room. If fuel leakage is found, go to EC-92, "Diagnosis Procedure". If fuel leakage is not found, go to next step.
- Select "DATA MONITOR" mode with CONSULT-III.
- 5. Check the fuel rail pressure at the idle speed.

### Fuel rail pressure: 25 - 35 MPa

If NG, go to EC-92, "Diagnosis Procedure".

## WITH GST

- Open engine hood and check if there are any signs of fuel leakage or not.
  - If there are any signs, go to EC-92, "Diagnosis Procedure".
  - If there is no signs, go to next step.

If oil level is above the proper range, go to EC-92, "Diagnosis Procedure". If oil level is within the proper range, go to next step.

- Start engine and check fuel leakage in the engine room.
  - If fuel leakage is found, go to EC-92, "Diagnosis Procedure". If fuel leakage is not found, go to next step.
- Select Service \$1 mode with GST.
- 5. Check the fuel rail pressure at the idle speed.

### Fuel rail pressure: 25 - 35 MPa

If NG, go to EC-92, "Diagnosis Procedure".

EC

Α

D

Н

K

M

Ν

## **Diagnosis Procedure**

INFOID:0000000003759365

## 1. PERFORM FUEL PUMP LEARNING VALUE CLEARING

If the DTC is detected because of air mixed with fuel (i.e.: caused by lack of fuel), it may become normal by performing following procedure.

## With CONSULT-III

- Turn ignition switch ON.
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
- Start engine and let it idle for at least 60 seconds.
- Select "SELF-DIAG RESULT" mode with CONSULT-III.
- Touch "ERASE".

  Perform <u>EC-91</u>, "<u>Overall Function Check"</u>, again.
- 7. Is the result NG again?

## With GST

- Turn ignition switch ON. 1.
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
- Start engine and let it idle for at least 60 seconds.
- Select Service \$04 with GST.
- Perform EC-91, "Overall Function Check", again.
- Is the result NG again?

### Yes or No

Yes >> GO TO 2.

No >> INSPECTION END

# 2.CHECK FUEL LINE FOR LEAK

- Start engine.
- Visually check the following for fuel leak.
- Fuel tube from fuel pump to fuel rail
- Fuel rail
- Fuel tube from fuel rail to fuel injector
- Also check for improper connection or pinches.

### OK or NG

OK >> GO TO 3.

NG >> Repair malfunctioning part.

## 3.CHECK FUEL RAIL PRESSURE RELIEF VALVE

Refer to EC-92, "Component Inspection".

### OK or NG

OK >> GO TO 4.

>> Replace fuel rail. NG

## 4.CHECK INTERMITTENT INCIDENT

Refer to EC-70.

### OK or NG

OK >> GO TO 5.

NG >> Repair or replace.

## 5. REPLACE FUEL PUMP

- Replace fuel pump.
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

### >> INSPECTION END

## Component Inspection

INFOID:0000000003759366

FUEL RAIL PRESSURE RELIEF VALVE

With CONSULT-III

### **WARNING:**

Confirm that the engine is cooled down and there are no fire hazards near the vehicle.

Prepare pans or saucers under the disconnected fuel line because the fuel may spill out.

1. Turn ignition switch OFF.

2. Remove fuel hose from fuel rail pressure relief valve (1).

: Vehicle front

- Fuel rail pressure sensor (2)
- 3. Attach a blind cap or plug to removed hose.
- 4. Turn ignition switch ON.
- Select "PRES REGULATOR" in "ACTIVE TEST" with CON-SULT-III.
- 6. Start engine and keep engine speed 2,000 rpm.
- 7. Raise fuel pressure to 180 MPa with touching "UP" or "Qu" on the CONSULT-III screen.
- Confirm that the fuel does not come out from the fuel rail pressure relief valve.



- Be careful not to allow leaked fuel to contaminate engine compartment. Especially, ensure to keep engine mount insulator clear of fuel.
- If the fuel comes out, stop the engine immediately.

## Without CONSULT-III

### **WARNING:**

- Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
- Prepare pans or saucers under the disconnected fuel line because the fuel may spill out.
- Turn ignition switch OFF.
- 2. Remove fuel hose from fuel rail pressure relief valve (1).

: Vehicle front

- Fuel rail pressure sensor (2)
- 3. Attach a blind cap or plug to removed hose.
- Start engine and keep engine speed more than 4,000 rpm for at least 5 seconds.
- Confirm that the fuel does not come out from the fuel rail pressure relief valve.

### **WARNING:**

- If the fuel comes out, stop the engine immediately.

### Removal and Installation

FUEL RAIL Refer to EM-8.

**FUEL PUMP** 

Refer to EC-24.

Е

D

Α

EC

F

Н

K

L

M

Ν

INFOID:0000000003759367


INFOID:0000000003759368

## DTC P0101 MAF SENSOR

## Component Description

The mass air flow sensor (1) is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. The mass air flow sensor controls the temperature of the hot wire to a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the electric current supplied to hot wire is changed to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



## CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759369

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
		Ignition switch: ON (Engine stopped)	Approximately 0.4 V
	Engine: After warming up     Air conditioner switch: OFF	Idle	1.3 - 1.8 V
MAS AIR/FL SE*	Shift lever: Neutral position     No load	Engine is revving from idle to about 4,000 rpm.	1.3 - 1.8 V to Approximately 4.0 V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)

<sup>\*:</sup> This signal is converted by ECM internally. Thus this differs from ECM terminal voltage.

## On Board Diagnosis Logic

INFOID:0000000003759370

If DTC P0101 is displayed with DTC P0403, first perform trouble diagnosis for DTC P0403. Refer to EC-177.

If DTC P0101 is displayed with DTC P0409, first perform trouble diagnosis for DTC P0409. Refer to EC-

If DTC P0101 is displayed with DTC P0488, first perform trouble diagnosis for DTC P0488. Refer to EC-196.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0101 0101	Mass air flow sensor cir- cuit range/performance	Improper voltage from the sensor is sent to ECM compared with the driving condition.	Harness or connectors     (The sensor circuit is open or shorted.)     Mass air flow sensor     Intake air leaks     Air cleaner     Intake air temperature sensor     EGR volume control valve

## **DTC Confirmation Procedure**

INFOID:0000000003759371

### **CAUTION:**

Always drive vehicle at a safe speed.

NOTÉ:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

## (III) WITH CONSULT-III

1. Turn ignition switch ON.

2. Select "DATA MONITOR" mode with CONSULT-III http://probadordemodulos.wix.com/probadorautomotriz http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com probadordemodulos@gmail.com

## **DTC P0101 MAF SENSOR**

## < SERVICE INFORMATION > [YD25DDTi]

3. Start engine and let it idle for at least 40 seconds.

4. Drive vehicle under the following condition.

CKPS-RPM	Approx. 2800 rpm	
VHCL SPEED SE	70 - 100 km/h (43 - 62 MPH)	
Shift lever	4th position	

5. Release accelerator pedal for at least 10 seconds. Do not depress brake pedal during this procedure.

- 6. Check 1st trip DTC.
- 7. If 1st trip DTC is detected, go to EC-99, "Diagnosis Procedure".

## **WITH GST**

Follow the procedure "WITH CONSULT-III" above.

EC

Α

С

D

Е

F

G

Н


K

M

Ν

Wiring Diagram

### **LHD MODELS**



GEC602A

Specification data are reference values, and are measured between each terminal and ground.

## < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description Condition		Value (Approx.)	
+	_	Signal name		(,,,priox.)	
			[Ignition switch ON]	Approximately 0.4 V	
54	73	Mass air flow sensor	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	1.3 - 1.8 V	
(G) (B)	(B)		<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Engine is revving from idle to about 4,000 rpm.</li> </ul>	1.3 - 1.8 V to Approximately 4.0 V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	
73 (B)	_	Mass air flow sensor ground	_	_	
105 (G) 114 113 (B) (G)		FCM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V	
	(Б)		[Ignition switch OFF]  • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)	
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)	

<sup>▼:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

EC

Α

С

D

Е

1

G

Н

Κ


.

M

Ν

0

RHD MODELS



Specification data are reference values, and are measured between each terminal and ground.

## < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)	
+	_	Signal name		(Αρριολ.)	
-		Mass air flow sensor	[Ignition switch ON]	Approximately 0.4 V	
	73 (B)		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	1.3 - 1.7 V	
			<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine is revving from idle to about 4,000 rpm.</li></ul>	1.3 - 1.7 V to Approximately 4.0 V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	
73 (B)	_	Mass air flow sensor ground	_	_	
` '	114	ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V	
	(B)		[Ignition switch OFF] • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)	
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)	

<sup>▼:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# Diagnosis Procedure

# 1. CHECK INTAKE SYSTEM

- Check air cleaner for clogging.
- Check the following for connection and cracks.
- Air duct
- Vacuum hoses
- Intake air passage between air duct and intake manifold

## OK or NG

OK >> GO TO 2.

NG >> Reconnect or repair the parts.

# 2. CHECK GROUND CONNECTIONS


- 1. Turn ignition switch OFF.
- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2) ECM (3)

## OK or NG

OK >> GO TO 3.

NG >> Repair or replace ground connections.

# 3.CHECK MAF SENSOR POWER SUPPLY CIRCUIT



Α

EC

D

Е

Н

INFOID:0000000003759373

K

M

Ν

0


http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

1. Disconnect mass air flow sensor (1) harness connector.

: Vehicle front

2. Turn ignition switch ON.




3. Check voltage between mass air flow sensor terminal 2 and ground with CONSULT-III or tester.

### Voltage: Battery voltage

### OK or NG

OK >> GO TO 5. NG >> GO TO 4.



## 4. DETECT MALFUNCTIONING PART

Check the following.

- · Harness for open or short between mass air flow sensor and ECM relay
- · Harness for open or short between mass air flow sensor and ECM
- Harness connectors E91,M241 (LHD models)
- Harness connectors E102,M13 (RHD models)

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 5. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check harness continuity between mass air flow sensor terminal 3 and ECM terminal 73. Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 7. NG >> GO TO 6.

## 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E101,M5
- Harness for open or short between mass air flow sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## .CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between mass air flow sensor terminal 4 and ECM terminal 54. Refer to Wiring Diagram.

### Continuity should exist.

### DTC P0101 MAF SENSOR

[YD25DDTi] < SERVICE INFORMATION > 2. Also check harness for short to ground and short to power. Α OK or NG OK >> GO TO 9. >> GO TO 8. NG  $oldsymbol{8}.$ DETECT MALFUNCTIONING PART Check the following. Harness connectors E101,M5 Harness for open or short between mass air flow sensor and ECM >> Repair open circuit or short to ground or short to power in harness or connectors. D 9.CHECK INTAKE AIR TEMPERATURE SENSOR Refer to EC-114, "Component Inspection". Е OK or NG OK >> GO TO 10. NG >> Replace mass sir flow sensor (with intake air temperature sensor). 10. CHECK MASS AIR FLOW SENSOR Refer to EC-101, "Component Inspection". OK or NG OK >> GO TO 11. NG >> Replace mass air flow sensor. 11. CHECK INTERMITTENT INCIDENT Refer to EC-70. OK or NG OK >> GO TO 12. NG >> Repair or replace. 12. REPLACE EGR VOLUME CONTROL VALVE Replace the EGR volume control valve. Perform EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear". Perform EC-24, "EGR Volume Control Valve Closed Position Learning". >> INSPECTION END Component Inspection INFOID:0000000003759374 MASS AIR FLOW SENSOR (III) With CONSULT-III 1. Reconnect all harness connectors disconnected. Ν 2. Start engine and warm it up to normal operating temperature. Connect CONSULT-III and select "DATA MONITOR" mode. 4. Select "MAS AIR/FL SE" and check indication under the following conditions. Р

Condition	MAS AIR/FL SE (V)
Ignition switch ON (Engine stopped.)	Approx. 0.4
Idle (Engine is warmed-up to normal operating temperature.)	1.3 - 1.8
Idle to about 4,000 rpm	1.3 - 1.8 to Approx. 4.0*

<sup>\*:</sup> Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

http://brok.fordback.cause.nfuncyer.airflow.through.mass.airiflow.sensorpRefer.do.followingulos@gmail.com http://probadordemodulos.wix.com/probadorautomotriz probadordemodulos@gmail.com

If the voltage is out of specification, proceed the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system parts
- b. If NG, repair or replace malfunctioning part and perform step 2 to 4 again. If OK, go to next step.
- 6. Turn ignition switch OFF.
- 7. Disconnect mass air flow sensor harness connector and reconnect it again.
- 8. Perform step 2 to 4 again.
- 9. If NG, clean or replace mass air flow sensor.
- Without CONSULT-III
- Reconnect all harness connectors disconnected.
- Start engine and warm it up to normal operating temperature.
- 3. Check voltage between ECM harness connectors as follows.

ECM				
Connector	+	_	Condition	Voltage
	Terminal	Terminal		
M32	54 (MAF sensor signal)	73 (Sensor ground)	Ignition switch ON (Engine stopped.)	Approx. 0.4 V
			Idle (Engine is warmed-up to normal operating temperature.)	1.3 - 1.8 V
			Idle to about 4,000 rpm	1.3 - 1.8 V to Ap- prox. 4.0 V*

<sup>\*:</sup> Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

- 4. If the voltage is out of specification, proceed the following.
- a. Check for the cause of uneven air flow through mass air flow sensor. Refer to following.
  - · Crushed air ducts
  - · Malfunctioning seal of air cleaner element
  - Uneven dirt of air cleaner element
  - Improper specification of intake air system parts
- b. If NG, repair or replace malfunctioning part and perform step 2 and 3 again.
  - If OK, go to next step.
- 5. Turn ignition switch OFF.
- 6. Disconnect mass air flow sensor harness connector and reconnect it again.
- 7. Perform step 2 and 3 again.
- 8. If NG, clean or replace mass air flow sensor.

## Removal and Installation

INFOID:0000000003759375

MASS AIR FLOW SENSOR Refer to EM-6.

INFOID:0000000003759376


INFOID:0000000003759377

## DTC P0102, P0103 MAF SENSOR

## Component Description

The mass air flow sensor (1) is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. The mass air flow sensor controls the temperature of the hot wire to a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater

Therefore, the electric current supplied to hot wire is changed to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



## CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONE	DITION	SPECIFICATION
	Engine: After warming up     Air conditioner switch: OFF	Ignition switch: ON (Engine stopped)	Approximately 0.4 V
		Idle	1.3 - 1.8 V
MAS AIR/FL SE*	Shift lever: Neutral position     No load	Engine is revving from idle to about 4,000 rpm.	1.3 - 1.8 V to Approximately 4.0 V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)

<sup>\*:</sup> This signal is converted by ECM internally. Thus this differs from ECM terminal voltage.

## On Board Diagnosis Logic

INFOID:0000000003759378

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors     (The sensor circuit is open or short-
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	ed.) • Mass air flow sensor

## **DTC Confirmation Procedure**

INFOID:0000000003759379

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- Check 1st trip DTC.
- If 1st trip DTC is detected, go to EC-107, "Diagnosis Procedure".

P

http://probadordemodulos.wix.com/probadorautomotriz

EC

Α

Е

D


Н

M

Ν

Wiring Diagram

## LHD MODELS



GEC602A

Specification data are reference values, and are measured between each terminal and ground.

# DTC P0102, P0103 MAF SENSOR

## < SERVICE INFORMATION >

[YD25DDTi]

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)	
+	_	Signal name		(Approx.)	
54 73 (G) (B)		[Ignition switch ON]	Approximately 0.4 V		
	_	Mass air flow sensor	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	1.3 - 1.8 V	
	(B)		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine is revving from idle to about 4,000 rpm.</li></ul>	1.3 - 1.8 V to Approximately 4.0 V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	
73 (B)	_	Mass air flow sensor ground	_	_	
105 (G)		L(`M relay (selt shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V	
_			<ul><li>[Ignition switch OFF]</li><li>More than a few seconds after turning ignition switch OFF</li></ul>	BATTERY VOLTAGE (11 - 14 V)	
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)	

С

Α

Е

D

F

G

Н

1

Κ


L

M

Ν

0

## RHD MODELS



Specification data are reference values, and are measured between each terminal and ground.

## < SERVICE INFORMATION >

	NAL NO. color)	Description	Condition	Value (Approx.)	
+	_	Signal name		(Approx.)	
		Mass air flow sensor	[Ignition switch ON]	Approximately 0.4 V	
54	73		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	1.3 - 1.8 V	
(G)	(B)		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine is revving from idle to about 4,000 rpm.</li></ul>	1.3 - 1.8 V to Approximately 4.0 V (Check for liner voltage rise in response to engine being increased to about 4,000 rpm)	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	
73 (B)	_	Mass air flow sensor ground	_	_	
105 (G)	114 (B)	ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V	
113 (BR)	(Б)		<ul><li>[Ignition switch OFF]</li><li>More than a few seconds after turning ignition switch OFF</li></ul>	BATTERY VOLTAGE (11 - 14 V)	
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)	

## Diagnosis Procedure

# 1.CHECK GROUND CONNECTIONS

- Turn ignition switch OFF.
- Loosen and retighten ground screws on the body. Refer to <u>EC-81</u>, "<u>Ground Inspection</u>". Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

## OK or NG

OK >> GO TO 2.


NG >> Repair or replace ground connections.


# 2.CHECK MAF SENSOR POWER SUPPLY CIRCUIT

Disconnect mass air flow sensor (1) harness connector.

: Vehicle front

Turn ignition switch ON.





Α

EC

D

Е

Н

INFOID:0000000003759381

M


Ν

Check voltage between mass air flow sensor terminal 2 and ground with CONSULT-III or tester.

## Voltage: Battery voltage

### OK or NG

OK >> GO TO 4. NG >> GO TO 3.



# 3. DETECT MALFUNCTIONING PART

Check the following.

- · Harness for open or short between mass air flow sensor and ECM relay
- · Harness for open or short between mass air flow sensor and ECM
- Harness connectors E91,M241 (LHD models)
- Harness connectors E102,M13 (RHD models)
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- Disconnect ECM harness connector.
- 3. Check harness continuity between mass air flow sensor terminal 3 and ECM terminal 73. Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 6. NG >> GO TO 5.

# 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E101,M5
- Harness for open or short between mass air flow sensor and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between mass air flow sensor terminal 4 and ECM terminal 54. Refer to Wiring Diagram.

### Continuity should exist.

Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 8. NG >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E101,M5
- Harness for open or short between mass air flow sensor and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

# DTC P0102, P0103 MAF SENSOR

< SERVICE INFORMATION >	DIC PUIUZ, PUIUS MAF SENSOR	[YD25DDTi]
8.CHECK MASS AIR FLOW SE	NSOR	_
Refer to EC-109, "Component Ins		
OK or NG OK >> GO TO 9. NG >> Replace mass air flor  9.CHECK INTERMITTENT INC.		
Refer to EC-70.	IDENT	
>> INSPECTION END		
Component Inspection		INFOID:0000000003759382
MASS AIR FLOW SENSOR		
(II) With CONSULT-III		
Reconnect all harness connect		
	to normal operating temperature. elect "DATA MONITOR" mode.	
	d check indication under the following conditions.	
	<u> </u>	
Condition	MAS AIR/FL SE (V)	
Ignition switch ON (Engine stopped.)  Idle (Engine is warmed-up to normal	Approx. 0.4	
operating temperature.)	1.3 - 1.8	
Idle to about 4,000 rpm	1.3 - 1.8 to Approx. 4.0*	
*: Check for linear voltage rise in re	sponse to engine being increased to about 4,000 rpm.	
5. If the voltage is out of specifi		
<ul><li>a. Check for the cause of unever</li><li>Crushed air ducts</li></ul>	en air flow through mass air flow sensor. Refer to following.	
Malfunctioning seal of air control of air cont		
<ul><li>Uneven dirt of air cleaner e</li><li>Improper specification of in</li></ul>	ntake air system parts	
	nctioning part and perform step 2 to 4 again.	
If OK, go to next step.  6. Turn ignition switch OFF.		
•	nsor harness connector and reconnect it again.	
8. Perform step 2 to 4 again.	·	
9. If NG, clean or replace mass	air flow sensor.	
Without CONSULT-III		
1. Reconnect all harness conne	ectors disconnected.	
<del>-</del>	to normal operating temperature.	
3. Check voltage between ECN	I harness connectors as follows.	

Ρ

#### < SERVICE INFORMATION >

	ECM				
Connector	+	_	Condition	Voltage	
Connector	Terminal	Terminal			
M32	54 73 (MAF sensor signal) (Sensor ground)		Ignition switch ON (Engine stopped.)	Approx. 0.4 V	
			Idle (Engine is warmed-up to normal operating temperature.)	1.3 - 1.8 V	
		Idle to about 4,000 rpm	1.3 - 1.8 V to Approx. 4.0 V*		

- \*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.
- 4. If the voltage is out of specification, proceed the following.
- a. Check for the cause of uneven air flow through mass air flow sensor. Refer to following.
  - Crushed air ducts
  - Malfunctioning seal of air cleaner elementUneven dirt of air cleaner element

  - · Improper specification of intake air system parts
- b. If NG, repair or replace malfunctioning part and perform step 2 and 3 again. If OK, go to next step.
- 5. Turn ignition switch OFF.
- 6. Disconnect mass air flow sensor harness connector and reconnect it again.
- 7. Perform step 2 and 3 again.
- If NG, clean or replace mass air flow sensor.

## Removal and Installation

INFOID:0000000003759383

MASS AIR FLOW SENSOR Refer to EM-6.


INFOID:0000000003759384

# DTC P0112, P0113 IAT SENSOR

## Component Description

The intake air temperature sensor is built into mass air flow sensor (1). The sensor detects intake air temperature and transmits a signal to the ECM.


The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



#### <Reference data>

Intake air temperature [°C (°F)]	Voltage* (V)	Resistance (kΩ)
25 (77)	2.4	1.800 - 2.200
80 (176)	0.8	0.283 - 0.359

<sup>\*:</sup> This data is reference values and is measured between ECM terminal 55 (Intake air temperature sensor) and 74 (sensor ground).



## On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112 0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors     (The sensor circuit is open or short-
P0113 0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	ed.) • Intake air temperature sensor

## **DTC Confirmation Procedure**

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- Check 1st trip DTC.
- If 1st trip DTC is detected, go to EC-112, "Diagnosis Procedure".

Е

D

Α

INFOID:0000000003759386

INFOID:0000000003759385

Ν

M


()


Р


Wiring Diagram

INFOID:0000000003759387

## EC-IATS-01







Diagnosis Procedure

INFOID:0000000003759388

GEC604A

- 1. CHECK GROUND CONNECTIONS
- 1. Turn ignition switch OFF.

## **DTC P0112, P0113 IAT SENSOR**

## < SERVICE INFORMATION >

[YD25DDTi]

- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

### OK or NG

OK >> GO TO 2.


NG >> Repair or replace ground connections.



Disconnect mass air flow sensor (intake air temperature sensor is built-into) (1) harness connector.

: Vehicle front

Turn ignition switch ON.



(3)


Check voltage between mass air flow sensor terminal 5 and ground with CONSULT-III or tester.

## Voltage: Approximately 5 V

#### OK or NG

OK NG

>> GO TO 4. >> GO TO 3.



# 3.DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E101,M5
- Harness for open or short between mass air flow sensor (with intake air temperature sensor) and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

**EC-113** 

# 4.CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector. 2.
- Check harness continuity between mass air flow sensor terminal 6 and ECM terminal 74. Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 6.


NG >> GO TO 5.

## DETECT MALFUNCTIONING PART

http://phobadordemodulos.wix.com/probadorautomotriz

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com probadordemodulos@gmail.com



PRIR1169F

M

EC

D

Е

Н

IMBIA1299ZZ

Ν

 $\bigcirc$ 

Ρ

#### < SERVICE INFORMATION >

- · Harness connectors E101,M5
- · Harness for open or short between mass air flow sensor (with intake air temperature sensor) and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to EC-114, "Component Inspection".

OK or NG

OK >> GO TO 7.

NG >> Replace mass air flow sensor (with intake air temperature sensor).

7. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

## Component Inspection


INFOID:0000000003759389

#### INTAKE AIR TEMPERATURE SENSOR

1. Check resistance between mass air flow sensor (1) terminals 5 and 6 under the following conditions.

Intake air temperature [°C (°F)] 25 (77) Resistance (kΩ) 1.800 - 2.200

If NG, replace mass air flow sensor (with intake air temperature sensor).



20 - Acceptable

10 - Acceptable

2 - Acceptable

0.4 - 0.2 - 20 0 20 40 60 80 100 (-4) (32) (68) (104) (140) (176) (212) Temperature °C (°F)

SEF012P

Removal and Installation

INFOID:0000000003759390

MASS AIR FLOW SENSOR Refer to EM-6.

Α

EC

D

Е


Н

K

# DTC P0117, P0118 ECT SENSOR

Description NFOID:000000003759391

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



#### <Reference data>

E	ngine coolant tempera- ture [°C (°F)]	Voltage* (V)	Resistance (kΩ)
	-10 (14)	4.7	7.0 - 11.4
	20 (68)	3.8	2.1 - 2.9
	50 (122)	2.6	0.68 - 1.00
*· T	90 (194)	1.3	0.236 - 0.260 en FCM terminal 51 (Engine

\*: This data is reférence values and is measured between FCM terminal 51 (Engine

coolant temperature sensor) and 70 (sensor ground).

# On Board Diagnosis Logic

Acceptable

2

0.4

0.2

0.1

-20 0 20 40 60 80 100

(-4) (32) (68) (104) (140) (176) (212)

Temperature °C (°F)

SEF012P

INFOID:0000000003759392

	DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
•	P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors     (The sensor circuit is open or short-
	P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	ed.) • Engine coolant temperature sensor

## **DTC Confirmation Procedure**

Confirmation Procedure

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- 3. Check 1st trip DTC.
- 4. If 1st trip DTC is detected, go to EC-116, "Diagnosis Procedure".

Ν


M


Ρ


Wiring Diagram

INFOID:0000000003759394

## EC-ECTS-01







GEC605A

INFOID:0000000003759395

# **Diagnosis Procedure**

- 1. CHECK GROUND CONNECTIONS
- 1. Turn ignition switch OFF.

- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)


#### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.



- Disconnect engine coolant temperature (ECT) sensor (1) harness connector.
  - ⟨⊐ : Vehicle front
- Turn ignition switch ON.




(3)

Check voltage between ECT sensor terminal 1 and ground with CONSULT-III or tester.

## Voltage: Approximately 5 V

## OK or NG

OK >> GO TO 4. NG >> GO TO 3.



# 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E351,E255
- Harness connectors E237,M279
- Harness for open or short between ECT sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 4. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check harness continuity between ECT sensor terminal 2 and ECM terminal 70. Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 6. NG >> GO TO 5.

DETECT MALFUNCTIONING PART

http://probadordemodulos.wix.com/probadorautomotriz-

probadordemodulos@gmail.com

http://probadordemodulos.wix.com/probadorautomotriz

EC

D

IMBIA1299ZZ

Н

M

P

probadordemodulos@gmail.com

#### < SERVICE INFORMATION >

Check the following.

- Harness connectors E351,E255
- Harness connectors E237,M279
- Harness for open or short between ECT sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 6. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to EC-118, "Component Inspection".

## OK or NG

OK >> GO TO 7.

NG >> Replace engine coolant temperature sensor.

## 7. CHECK INTERMITTENT INCIDENT

Refer to EC-70.


#### >> INSPECTION END

# Component Inspection

INFOID:0000000003759396


#### ENGINE COOLANT TEMPERATURE SENSOR

1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



Engine coolant temperature [°C (°F)]	Resistance (k $\Omega$ )
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

<sup>2.</sup> If NG, replace engine coolant temperature sensor.



## Removal and Installation

INFOID:0000000003759397

ENGINE COOLANT TEMPERATURE SENSOR Refer to "CYLINDER HEAD" in EM section.


INFOID:0000000003759399

INFOID:0000000003759400

# DTC P0122, P0123 APP SENSOR

**Description** 

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensors detect the accelerator pedal position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.



## CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM CONDITION **SPECIFICATION** 0.5 - 1.0 V Accelerator pedal: Fully released Ignition switch: ON **ACCEL POS SEN\*** (Engine stopped) Accelerator pedal: Fully depressed 4.0 - 4.8 V 0.3 - 1.2 V Accelerator pedal: Fully released · Ignition switch: ON ACCEL SEN 2\* (Engine stopped) Accelerator pedal: Fully depressed 3.7 - 4.8 V

## On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

MI will not light up for these self-diagnoses.

NOTE:

If DTC P0122 or P0123 is displayed with DTC P0642 or P0643, first perform trouble diagnosis for DTC P0642 or P0643. Refer to EC-210.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122 0122	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	Harness or connectors     (The APP sensor 1 circuit is open or
P0123 0123	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	shorted.)  • Accelerator pedal position sensor (Accelerator pedal position sensor 1)

## **DTC Confirmation Procedure**

INFOID:0000000003759401

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- 3. Check DTC.
- 4. If DTC is detected, go to EC-121, "Diagnosis Procedure".

EC

Α

D

Е

F

Н

K

M

Ν


C


Р


<sup>\*:</sup> This signal is converted by ECM internally. Thus, this differs from ECM terminals voltage.

Wiring Diagram

EC-APPS1-01







GEC606A

Specification data are reference values and are measured between each terminal and ground.

## < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description	Condition	Value	
+	_	Signal name		(Approx.)	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	
82 (W)	84 (R)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V	
83	83 84 Accelerator pedal position senso	83 84	Accelerator pedal position sensor	<ul><li>[Ignition switch ON]</li><li>Engine: Stopped</li><li>Accelerator pedal: Fully released</li></ul>	0.5 - 1.0 V
(B) (R) 1	1	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully depressed	3.7 - 4.7 V		
84 (R)	_	Accelerator pedal position sensor 1 ground	_	_	
90 (L)	92 (Y)	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5 V	
91 92	Accelerator pedal position sensor	[Ignition switch ON] • Engine: Stopped • Accelerator pedal position sensor  92 Accelerator pedal: Fully release		0.15 - 0.6 V	
(G)	(G) (Y) 2		[Ignition switch ON]     Engine: Stopped     Accelerator pedal: Fully depressed	1.85 - 2.4 V	
92 (Y)	_	Accelerator pedal position sensor 2 ground	_	_	

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# Diagnosis Procedure

# 1. CHECK GROUND CONNECTIONS


- 1. Turn ignition switch OFF.
- 2. Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.

# 2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT



Α

EC

D

Е

G

Н

INFOID:0000000003759403

L


K

M

Ν

Р

- Disconnect accelerator pedal position (APP) sensor (1) harness connector.
- 2. Turn ignition switch ON.



3. Check voltage between APP sensor terminal 4 and ground with CONSULT-III or tester.




#### Voltage: Approximately 5 V

### OK or NG

OK >> GO TO 3.

NG >> Repair of

>> Repair open circuit or short to ground or short to power in harness or connectors.



JMBIA1300ZZ

# $3.\mathsf{CHECK}$ APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- 3. Check harness continuity between APP sensor terminal 1 and ECM terminal 84. Refer to Wiring Diagram.

## Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK APP SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between APP sensor terminal 5 and ECM terminal 83. Refer to Wiring Diagram.

#### Continuity should exist.

2. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK APP SENSOR

Refer to EC-123, "Component Inspection".

## OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

## **6.**CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

# **DTC P0122, P0123 APP SENSOR**

## < SERVICE INFORMATION >

[YD25DDTi]

# **Component Inspection**

INFOID:0000000003759404

Α

C

D

Е

## ACCELERATOR PEDAL POSITION SENSOR

- 1. Reconnect all harness connectors disconnected.
- 2. Turn ignition switch ON.
- 3. Check voltage between ECM harness connector terminal as follows.

ECM						
+ – Condition		lition	Voltage			
Connector	Terminal	Terminal				
M33	83	84 (Sensor ground)	84 Accelerator pedal	Fully released	0.5 - 1.0 V	
	(APP sensor 1 signal)		Accelerator pedar	Fully depressed	3.7 - 4.7 V	
IVIOO	91 92	Fully released	0.15 - 0.6 V			
	(APP sensor 2 signal)	(Sensor ground)	Accelerator pedal	Fully depressed	1.85 - 2.4 V	

<sup>4.</sup> If NG, replace accelerator pedal assembly.

## Removal and Installation

INFOID:0000000003759405

**ACCELERATOR PEDAL** 

Refer to "ACCELERATOR CONTROL SYSTEM" in FE section.

Н

Κ

L

M


Ν

Р

# DTC P0182, P0183 FUEL PUMP TEMPERATURE SENSOR

Description INFOID:000000003759442

Fuel pump temperature sensor (1) is built in the fuel pump (2). The sensor detects the fuel temperature in the fuel pump and calibrates the fuel injection amount change by fuel temperature.



## CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759443

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL TEMP SEN • Engine: After warming up		More than 40°C (104°F)

# On Board Diagnosis Logic

INFOID:0000000003759444

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0182 0182	Fuel pump temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors     (The sensor circuit is open or short-
P0183 0183	Fuel pump temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	ed.) • Fuel pump temperature sensor


## **DTC Confirmation Procedure**

INFOID:0000000003759445

#### NOTE

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- 3. Check 1st trip DTC.
- 4. If 1st trip DTC is detected, go to <a href="EC-125">EC-125</a>, "Diagnosis Procedure".



1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.

## DTC P0182, P0183 FUEL PUMP TEMPERATURE SENSOR

## < SERVICE INFORMATION >


[YD25DDTi]

- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

### OK or NG


OK >> GO TO 2.

NG >> Repair or replace ground connections.



# 2.CHECK FUEL PUMP TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

- Disconnect fuel pump temperature sensor (1) harness connector.
- Fuel pump (2)
- 2. Turn ignition switch ON.




Check voltage between fuel pump temperature sensor terminal 1 and ground with CONSULT-III or tester.

## **Voltage: Approximately 5V**

## OK or NG

OK >> GO TO 4. NG >> GO TO 3.



# 3. DETECT MALFUNCTIONING PART

Check the following

- Harness connectors E237, M279
- Harness for open or short between fuel pump temperature sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 4. CHECK FUEL PUMP TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check harness continuity between fuel pump temperature sensor terminal 2 and ECM terminal 69. Refer to Wiring Diagram.

## Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 6. NG >> GO TO 5.

## 5.DETECT MALFUNCTIONING PART

Fifther the fallowing modulos. wix.com/probadorautomotriz

probadordemodulos@gmail.com

## DTC P0182, P0183 FUEL PUMP TEMPERATURE SENSOR

< SERVICE INFORMATION > [YD25DDTi]

• Harness connectors E237, M279

Harness for open or short between fuel pump temperature sensor and ECM

Α

EC

6. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

OK or NG

OK >> GO TO 7.

NG >> Repair or replace.

7. REPLACE FUEL PUMP

1. Replace fuel pump.

2. Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

>> Repair open circuit or short to ground or short to power in harness or connectors.

D

Е

>> INSPECTION END

Removal and Installation

**FUEL PUMP** 

Refer to EC-24, "FUEL PUMP".

Н

J

K

L

M

Ν

 $\cap$ 

Р


# DTC P0192, P0193 FRP SENSOR

Description INFOID:0000000003759450

The fuel rail pressure (FRP) sensor (2) is placed to the fuel rail. It measures the fuel pressure in the fuel rail. The sensor sends voltage signal to the ECM. As the pressure increases, the voltage rises. The ECM controls the fuel pressure in the fuel rail by the inlet throttling device. The ECM uses the signal from fuel rail pressure sensor as a feedback signal.

: Vehicle front

Fuel rail pressure relief valve (1)



## CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR	CONDITION		SPECIFICATION
	Engine: After warming up	Idle	25 - 35 MPa
ACT CR PRESS	Air conditioner switch: OFF     Shift lever: Neutral     No load	2,000 rpm	40 - 50 MPa

## On Board Diagnosis Logic

INFOID:0000000003759452

#### NOTE:

If DTC P0192 or P0193 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to EC-214.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0192 0192	Fuel rail pressure sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors     (The sensor circuit is open or short-
P0193 0193	Fuel rail temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	ed.) • Fuel rail temperature sensor

## **DTC Confirmation Procedure**

INFOID:0000000003759453

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-130, "Diagnosis Procedure"</u>.

Α

EC

C

D

Е

Н

K

M

Ν


0

Ρ

Wiring Diagram

EC-FRP®=>000000003759454

: Detectable line for DTC



4 5 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 3 43 42 41 40 39 38 37 36 35 34 33 32 31 30 29 28 27 26 25 3 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 61 62 61 62 61 62 61 62 61 61 61 61 61 61 61 61 61 61 61 61 61	M32 B H.S.	3 2 1 M242	
[	)		

Specification data are reference values and are measured between each terminal and ground.

	NAL NO. e color)	Description	Condition	Value (Approx.)	
+	-	Signal name		(Αρρίοχ.)	
48 (W)	68	Fuel rail proceure copeer	[Engine is running]  • Warm-up condition  • Idle speed	1.4 - 1.7 V	
49 (W)	- (-)	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	1.7 - 2.0 V		
63 (R)	68 (B)	Fuel rail pressure sensor power supply	[Ignition switch ON]	Approximately 5 V	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	
68 (B)	_	Fuel rail pressure sensor ground	_	_	

# Diagnosis Procedure

INFOID:0000000003759455


# 1. CHECK GROUND CONNECTIONS

- 1. Turn ignition switch OFF.
- Loosen and retighten ground screws on the body. Refer to <u>EC-81</u>, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

#### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.




# 2. CHECK FUEL RAIL PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect fuel rail pressure sensor (2) harness connector.

: Vehicle front

Fuel rail pressure relief valve (1)

2. Turn ignition switch ON.



3. Check voltage between fuel rail pressure sensor terminal 1 and ground with CONSULT-III or tester.




## **Voltage: Approximately 5 V**

#### OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



MBIB1292E

http://probadordemodulos.wix.com/probadorautomotriz

## **DTC P0192, P0193 FRP SENSOR**

#### < SERVICE INFORMATION >

[YD25DDTi]

# 3. CHECK FUEL RAIL PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check harness continuity between fuel rail pressure sensor terminal 3 and ECM terminal 68. Refer to Wiring Diagram.

## EC

Е

Н

M

Ν

## Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

# 4.CHECK FUEL RAIL PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminals 48, 49 and fuel rail pressure sensor terminal 2. Refer to Wiring Diagram.

## Continuity should exist.

Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness connectors.

## 5. CHECK FUEL RAIL PRESSURE SENSOR

Refer to EC-131, "Component Inspection".

#### OK or NG

OK >> GO TO 6.

NG >> Replace fuel rail.

## 6.CHECK INTERMITTENT INCIDENT

>> INSPECTION END

Refer to EC-70.

# Component Inspection

#### INFOID:00000000003759456

#### FUEL RAIL PRESSURE SENSOR

- Reconnect harness connector disconnected.
- Start engine and warm it up to normal operating temperature.
- 3. Check voltage between ECM harness connector terminals as follows.

+					
		_	Condition	Voltage	
Connector	Terminal	Terminal			
M32	48	68	Idle	1.4 - 1.7 V	
IVIOZ	49	00	2,000 rpm	1.7- 2.0 V	

- 4. If the voltage is out of specification, disconnect fuel rail pressure sensor harness connector and connect it again. Then repeat above check.
- 5. If NG, replace fuel rail.

#### Removal and Installation

INFOID:0000000003759457

**FUEL RAIL** 

Refer to EM-8.

## DTC P0200 FUEL INJECTOR

## On Board Diagnosis Logic

INFOID:0000000003759458

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0200 0200	Fuel injector power supply circuit	ECM detects a voltage of power source for the fuel injector is excessively high or low.	• ECM

## **DTC Confirmation Procedure**

INFOID:0000000003759459

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Start engine and let it idle for at least 5 seconds.
- 2. Check 1st trip DTC.
- If 1st trip DTC is detected, go to EC-132, "Diagnosis Procedure".

## Diagnosis Procedure

INFOID:0000000003759460

## 1.INSPECTION START

# With CONSULT-III

- Turn ignition switch ON. 1.
- Select "SELF DIAG RESULTS" mode with CONSULT-III.
- 3. Touch "ERASE".
- Perform EC-132, "DTC Confirmation Procedure", again.
- Is 1st trip DTC P0200 displayed again?

## **With GST**

- 1. Turn ignition switch ON.
- Select Service \$04 with GST.
- Perform EC-132, "DTC Confirmation Procedure", again.
- Is 1st trip DTC P0200 displayed again?

## Yes or No

Yes >> GO TO 2.

No >> INSPECTION END

# 2.REPLACE ECM

- Replace ECM.
- Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to EL-96, "ECM Re-communicating Function".
- 3. Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

  Perform EGR Volume Control Valve Closed Position Learning Value Clear. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear ...
- Perform EGR Volume Control Valve Closed Position Learning. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning".

#### >> INSPECTION END


# DTC P0201 - P0204 FUEL INJECTOR

## **Component Description**

INFOID:0000000003759461

Α

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759462

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	Engine: After warming up	No load	0.68 - 0.78 msec
MAIN INJ WID	Shift lever: Neutral position     Idle speed	Blower fan switch: ON	0.78 - 0.88 msec

## On Board Diagnosis Logic

INFOID:0000000003759463

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0201 0201	No. 1 cylinder fuel injector circuit open	An improper voltage signal is sent to ECM through No. 1 cylinder fuel injector.	
P0202 0202	No. 2 cylinder fuel injector circuit open	An improper voltage signal is sent to ECM through No. 2 cylinder fuel injector.	Harness or connectors     (The fuel injector circuit is open.)
P0203 0203	No. 3 cylinder fuel injector circuit open	An improper voltage signal is sent to ECM through No. 3 cylinder fuel injector.	Fuel injector
P0204 0204	No. 4 cylinder fuel injector circuit open	An improper voltage signal is sent to ECM through No. 4 cylinder fuel injector.	

## **DTC Confirmation Procedure**

INFOID:0000000003759464

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

**TESTING CONDITION** 


Before performing the following procedure, confirm the ambient temperature is more than -20°C (-4°F).

- 1. Start engine and let it idle for at least 5 seconds.
- 2. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-136</u>, "<u>Diagnosis Procedure</u>".

Р

Ν

http://probadordemodulos.wix.com/probadorautomotriz



GEC610A

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

ERMINAL (Wire col		Description	Condition	Value
+	_	Signal name		(Approx.)
4 (L)	114	Fuel injector power supply (For cylinder No. 1 and 3)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 7.5 V ★  10.0 V/Div 20 ms/Div 1  MBIB1295E
5 (P)	(B)	Fuel injector power supply (For cylinder No. 2 and 4)	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 8.0 V ★  10.0 V/Div 20 ms/Div T  MBIB1296E
21 (Y)		Fuel injector No. 4	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	Approximately 7.5 V ★
22 (R)	114	Fuel injector No. 4	NOTE:  The pulse cycle changes depending on rpm at idle	≫ 10.0 V/DIV 20 ms/DIV T
	(B)	Fuel injector No. 2		Approximately 8.0 V ★
24 (OR)		Fuel injector No. 2	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	≥ 10.0 V/Div 20 ms/Div T MBIB1298E
40 (G)		Fuel injector No. 3	[Engine is running]  • Warm-up condition  • Idle speed	Approximately 7.5 V ★
	114 (D)	Fuel injector No. 3	NOTE: The pulse cycle changes depending on rpm at idle	≥ 10.0 V/Div 20 ms/Div T MBIB1297E
42 (PU)	(B)	Fuel injector No. 1		Approximately 8.0 V ★
43 (SB)		Fuel injector No. 1	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	≥ 10.0 V/Div 20 ms/Div T

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## **Diagnosis Procedure**

INFOID:0000000003759467


# 1. CHECK FUEL INJECTOR POWER SUPPLY CIRCUIT FOR OPEN

- 1. Turn ignition switch OFF.
- 2. Disconnect fuel injector (1) harness connector.

: Vehicle front

- Disconnect ECM harness connector.
- Check harness continuity between the following terminals corresponding to the malfunctioning cylinder.
   Refer to Wiring Diagram.

DTC	Terminal		Culindor
DIC	ECM	Fuel injector	Cylinder
P0201	4	1	No.1
P0202	5	1	No.2
P0203	4	1	No.3
P0204	5	1	No.4



### Continuity should exist.

## OK or NG

OK >> GO TO 2.

NG >> Repair open circuit in harness or connectors.

# 2.CHECK FUEL INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN

Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

DTC	Terr	Cylinder	
ыс	ECM	Fuel injector	Cyllildei
P0201	42, 43	2	No.1
P0202	23, 24	2	No.2
P0203	40, 41	2	No.3
P0204	21, 22	2	No.4

### Continuity should exist.

#### OK or NG

OK >> GO TO 3.

NG >> Repair open circuit in harness or connectors.

# 3.CHECK FUEL INJECTOR-I

Refer to EC-137, "Component Inspection".

#### OK or NG

OK >> GO TO 4. NG >> GO TO 5.

4. CHECK FUEL INJECTOR-II

# (III) With CONSULT-III

1. Remove two fuel injectors.

## NOTE:

One is from malfunctioning cylinder and the other is from any cylinder other than the malfunctioning cylinder.

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com


#### DTC P0201 - P0204 FUEL INJECTOR [YD25DDTi] < SERVICE INFORMATION > 2. Swap the two fuel injectors to the other cylinder. 3. Reconnect ECM harness connector and fuel injector harness connectors. Α 4. Turn ignition switch ON. 5. Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration". Select "SELF DIAG RESULTS" mode with CONSULT-III. 6. Touch "ERASE". 7. 8. Perform EC-133, "DTC Confirmation Procedure". Is DTC displayed for the other cylinder? ₩ith GST Remove two fuel injectors. NOTE: One is from malfunctioning cylinder and the other is from any cylinder other than the malfunctioning cylinder. Swap the two fuel injectors to the other cylinder. Reconnect ECM harness connector and fuel injector harness connector. 4. Turn ignition switch ON. Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration". Select Service \$04 with GST. Perform EC-133, "DTC Confirmation Procedure". 7. Is DTC displayed for the other cylinder? Yes or No Yes >> GO TO 5. No >> GO TO 6. REPLACE FUEL INJECTOR Н Replace fuel injector of malfunctioning cylinder. Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration". >> INSPECTION END 6.CHECK INTERMITTENT INCIDENT Refer to EC-70. >> INSPECTION END K Component Inspection INFOID:0000000003759468


#### FUEL INJECTOR

- Disconnect fuel injector harness connector.
- 2. Check resistance between terminals as shown in the figure.

Resistance: 0.2 - 0.8  $\Omega$  [at 10 - 60°C (50 - 140°F)]

If NG, replace fuel injector.





MBIB1735E

INFOID:0000000003759469

Removal and Installation

**FUEL INJECTOR** Refer to EM-8.

EC

 $\vdash$ 

M

Ν

# DTC P0217 ENGINE OVER TEMPERATURE

Description INFOID:000000003759470

#### SYSTEM DESCRIPTION

**NOTE** 

If DTC P0217 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to <u>EC-83</u>.


Cooling Fan Control

Sensor	Input Signal to ECM	ECM function	Actuator
Wheel sensor	Vehicle speed*		
Engine coolant temperature sensor	Engine coolant temperature	Cooling fan control	Cooling fan relay
Air conditioner switch	Air conditioner ON signal*		

<sup>\*:</sup> This signal is sent to ECM through CAN communication line.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, and air conditioner ON signal. The control system has 2-step control [ON/OFF].

#### Cooling Fan Operation



#### CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759471

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
AIR COND SIG	Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates)	ON
COOLING FAN*	When cooling fan is stopped		OFF
	When cooling fan operate low speed		LOW
	When cooling fan operate low speed		Н

<sup>\*:</sup> The cooling fan rotation has two stages (OFF and ON) although the display of CONSULT-III has three stages (OFF,LOW and HI).

# On Board Diagnosis Logic

INFOID:0000000003759472

# This self-diagnosis has the one trip detection logic. MI will not light up for this self-diagnosis.

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

## DTC P0217 ENGINE OVER TEMPERATURE

### < SERVICE INFORMATION >

[YD25DDTi]

Α

EC

D

Н

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0217 0217	Engine over temperature (Overheat)	<ul> <li>Cooling fan does not operate properly (Overheat).</li> <li>Cooling fan system does not operate properly (Overheat).</li> <li>Engine coolant was not added to the system using the proper filling method.</li> <li>Engine coolant is not within the specified range.</li> </ul>	Harness or connectors (The cooling fan circuit is open or shorted.) Cooling fan Cooling fan Cooling fan (Crankshaft driven) Radiator hose Radiator Radiator cap Reservoir tank Water pump Thermostat For more information, refer to EC-145, "Main 12 Causes of Overheating".

### **CAUTION:**

When a malfunction is indicated, be sure to replace the coolant. Refer to "ENGINE MAINTENANCE" in MA section. Also, replace the engine oil. Refer to "ENGINE MAINTENANCE" in MA section.

- Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to "RECOMMENDE FLUIDS AND LUBRICANTS" in MA section.
- 2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

### Overall Function Check

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

#### **WARNING:**

- Never remove a radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator and/or the reservoir tank.
- Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.


# WITH CONSULT-III

- Check the coolant level in the reservoir tank and radiator. Allow engine to cool before checking coolant level. If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to EC-141, "Diagnosis Procedure".
- Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to EC-141, "Diagnosis Procedure".
- 3. Start engine and make sure that cooling fan (crankshaft driven) operates normally.
  - If NG, refer to "ENGINE COOLING SYSTEM" in LC section. If OK, go to the following step.

#### Be careful not to overheat engine.

- Stop engine and turn ignition switch ON.
- Select "COOLANT TEMP" in "ACTIVE TEST" mode with CONSULT-III.
- Set "ENG COOLANT TEMP" to 100°C (212°F) by touching "Qu" and "UP" on CONSULT-III screen.
- Make sure that cooling fan operates. If the results are NG, go to EC-141, "Diagnosis Procedure".

### WITHOUT CONSULT-III



SFF621W

INFOID:0000000003759473

M

D

http://probadordemodulos.wix.com/probadorautomotriz

## DTC P0217 ENGINE OVER TEMPERATURE

#### < SERVICE INFORMATION >


[YD25DDTi]


- Check the coolant level in the reservoir tank and radiator. Allow engine to cool before checking coolant level. If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to EC-141, "Diagnosis Procedure".
- Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to EC-141, "Diagnosis Procedure".
- 3. Start engine and make sure that cooling fan (crankshaft driven) operates normally. If NG, refer to "ENGINE COOLING SYSTEM" in LC section.

If OK, go to the following step.

Be careful not to overheat engine.

- Turn ignition switch OFF.
- 5. Disconnect engine coolant temperature sensor harness connector.
- 6. Connect 150  $\Omega$  resistor to engine coolant temperature sensor harness connector.
- 7. Start engine and make sure that cooling fan operates. Be careful not to overheat engine.
- If NG, go to EC-141, "Diagnosis Procedure".





# **Diagnosis Procedure**

1. CHECK COOLING FAN (CRANKSHAFT DRIVEN) OPERATION

- 1. Start engine and let it idle.
- 2. Make sure that cooling fan (crankshaft driven) operates normally. https://doi.org/10.1016/j.j.com/probadorautomotriz

INFOID:0000000003759475

## DTC P0217 ENGINE OVER TEMPERATURE

#### < SERVICE INFORMATION >

[YD25DDTi]

OK (With CONSULT-III)>>GO TO 2.

OK (Without CONSULT-III)>>GO TO 3.

>> Check cooling fan (crankshaft driven). Refer to "ENGINE COOLING SYSTEM" in LC section.

# 2.CHECK COOLING FAN OPERATION

## (III) With CONSULT-III

- Start engine and let it idle.
- Select "ENG COOLANT TEMP" in "ACTIVE TEST" mode with CONSULT-III. Set "ENG COOLANT TEMP" to 95°C (203°by "Qu" and "UP" on CONSULT-III screen.
- Make sure that cooling fan operate.

#### OK or NG

OK >> GO TO 4.

>> Check cooling fan control circuit. (Go to "PROCEDURE A".) NG

# 3.CHECK COOLING FAN OPERATION

## **Without CONSULT-III**

- 1. Turn ignition switch OFF
- Disconnect engine coolant temperature sensor harness connector.
- Connect 150  $\Omega$  resistor to engine coolant temperature sensor harness connector.
- Start engine and make sure that cooling fan operates.

### OK or NG

OK >> GO TO 4.

NG >> Check cooling fan control circuit. (Go to "PROCEDURE A".)

## 4. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops. Refer to "ENGINE COOL-ING SYSTEM" in LC section.

#### **CAUTION:**

Higher than the specified pressure may cause radiator damage.

Pressure should not drop.

#### OK or NG

NG

OK >> GO TO 5.

>> Check the following for leak. Refer to "ENGINE COOLING SYSTEM" in LC section.

- Hose
- Radiator
- Radiator cap
- Water pump
- Reservoir tank

## 5. CHECK COMPONENT PARTS

#### Check the following.

- Thermostat. Refer to "ENGINE COOLING SYSTEM" in LC section.
- Engine coolant temperature sensor. Refer to EC-118, "Component Inspection".

## OK or NG

OK >> GO TO 6.

NG >> Replace malfunctioning component.

#### **6.**CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to EC-145, "Main 12 Causes of Overheating".

#### >> INSPECTION END

#### PROCEDURE A

# 1 . CHECK COOLING FAN POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect cooling fan relay E51.

3. Turn ignition switch ON. http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

## DTC P0217 ENGINE OVER TEMPERATURE

#### < SERVICE INFORMATION >


[YD25DDTi]

Check voltage between cooling fan relay terminals 1, 5 and ground with CONSULT-III or tester.

## **Voltage: Battery voltage**

#### OK or NG

OK >> GO TO 3. NG >> GO TO 2.



# 2 . DETECT MALFUNCTIONING PART

Check the following.

- 10A fuse (No.13)
- 30A fusible link (letter d)
- Harness connectors M5, E101
- Harness for open or short between cooling fan relay and fuse
- Harness for open or short between cooling fan relay and battery

>> Repair open circuit or short to ground in harness or connectors.

# 3.check cooling fan motor circuit for open and short

- Disconnect cooling fan motor (1) harness connector (2).
  - : Vehicle front
- Check harness continuity between the following. cooling fan relay terminal 3 and cooling fan motor terminal 1. cooling fan motor terminal 2 and ground. Refer to Wiring Diagram.

## Continuity should exist.

3. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## f 4 .CHECK COOLING FAN MOTOR SIGNAL CIRCUIT FOR OPEN OR SHORT

- Disconnect triple-pressure switch harness connector.
- Check harness continuity between cooling fan relay terminal 2 and triple-pressure switch terminal 2. Check harness continuity between triple-pressure switch terminal 3 and ground. Refer to Wiring Diagram.

#### Continuity should exist.

3. Also check harness for short to ground and short to power.

## OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

# 5.CHECK COOLING FAN MOTOR SIGNAL CIRCUIT FOR OPEN OR SHORT-II

- Disconnect combination meter harness connector.
- Check harness continuity between cooling fan relay terminal 2 and combination meter terminal 73. Check harness continuity between triple-pressure switch terminal 2 and combination meter terminal 73. Refer to Wiring Diagram.

Continuity should exist.

Pattp: Also characteristic messitions havint to a group of the adenocition power.

probadordemodulos@gmail.com

.IMBIA143377

EC

Α

K

# < SERVICE INFORMATION >

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

# 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E101, M5
- Harness connectors M6, N1
- · Harness for open or short between cooling fan relay and combination meter
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

## 7.CHECK COOLING FAN MOTOR SIGNAL CIRCUIT FOR OPEN OR SHORT-III

Check harness continuity between Combination Meter and ECM.

Refer to EL-117, "Main Line Between ECM and Combination Meter".

## OK or NG

OK >> GO TO 8

NG >> Repair the main line between the ECM and combination meter.

## 8. CHECK COOLING FAN RELAY

Refer to EC-145, "Component Inspection".

#### OK or NG

OK >> GO TO 9.

NG >> Replace cooling fan relay.

## 9. CHECK TRIPLE-PRESSURE SWITCH

Refer to "Electrical Components Inspection" in HA section.

#### OK or NG

OK >> GO TO 10.

NG >> Replace cooling fan relay.

# 10. CHECK COOLING FAN MOTOR

Refer to EC-145, "Component Inspection".

#### OK or NG

OK >> GO TO 11.

NG >> Replace cooling fan motors.

# 11. CHECK COMBINATION METER

Refer to EL-54, "Self-Diagnosis Mode of Combination meter".

#### OK or NG

OK >> GO TO 12.

NG >> Replace cooling fan motors.

# 12. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

[YD25DDTi]

## Main 12 Causes of Overheating

INFOID:0000000003759476

Α

C

D

Е

Н

K

M

Ν

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	Blocked radiator     Blocked condenser     Blocked radiator grille     Blocked bumper	Visual	No blocking	_
	2	Coolant mixture	Coolant tester	50 - 50% coolant mixture	See "RECOMMENDED AND LUBRICANTS" in MA section.
	3	Coolant level	• Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See "ENGINE MAINTE- NANCE" in MA section.
	4	Radiator cap	Pressure tester	See "ENGINE COOLING S	YSTEM" in LC section.
ON* <sup>2</sup>	5	Coolant leaks	• Visual	No leaks	See "ENGINE COOLING SYSTEM" in LC section.
ON* <sup>2</sup>	6	Thermostat	Touch the upper and lower radiator hoses	Both hoses should be hot	See "ENGINE COOLING SYSTEM" in LC section.
ON* <sup>1</sup>	7	Cooling fan	CONSULT-III	Operating	See trouble diagnosis for DTC P0217 (EC-138).
ON* <sup>2</sup>	7	Cooling fan (Crankshaft driven)	• Visual	Operating	See "ENGINE COOLING SYSTEM" in LC section.
OFF	8	Combustion gas leak	Color checker chemical tester 4 Gas analyzer	Negative	_
ON* <sup>3</sup>	9	Coolant temperature gauge	Visual	Gauge less than 3/4 when driving	_
		Coolant overflow to reservoir tank	Visual	No overflow during driving and idling	See "ENGINE MAINTE- NANCE" in MA section.
OFF* <sup>4</sup>	10	Coolant return from reservoir tank to radiator	• Visual	Should be initial level in reservoir tank	See "ENGINE MAINTE- NANCE" in MA section.
OFF	11	Cylinder head	Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See "CYLINDER HEAD" in EM section.
	12	Cylinder block and pistons	Visual	No scuffing on cylinder walls or piston	See "CYLINDER BLOCK" in EM section.

<sup>\*1:</sup> Turn the ignition switch ON.

For more information, refer to "OVERHEATING ANALYSIS" in LC section.


## Component Inspection

## **COOLING FAN RELAY**

- 1. Disconnect cooling fan relay harness connectors.
- Supply cooling fan motor terminals with battery voltage and check operation.

Terminals	Conditions	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Existed
	No current supply	Not existed

If NG, replace cooling fan relay.



PBIB0098E

INFOID:0000000003759477

<sup>\*2:</sup> Engine running at 3,000 rpm for 10 minutes.


<sup>\*3:</sup> Drive at 90 km/h (56 MPH) for 30 minutes and then let idle for 10 minutes.

<sup>\*4:</sup> After 60 minutes of cool down time.

### **COOLING FAN MOTOR**

- Disconnect cooling fan motor harness connectors.
- 2. Supply cooling fan motor terminals with battery voltage and check operation.

	terminals		
Cooling fan motor	+	_	
	1	2	



Cooling fan motor should operate.

If NG, replace cooling fan motor.

Α

F

Н

K


M

Ν

## DTC P0222, P0223 APP SENSOR

Description INFOID:0000000003759478

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensors detect the accelerator pedal position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.



### CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759479

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL POS SEN*	Ignition switch: ON	Accelerator pedal: Fully released	0.5 - 1.0 V
ACCEL FOO SEN	(Engine stopped)	Accelerator pedal: Fully depressed	4.0 - 4.8 V
ACCEL SEN 2*	Ignition switch: ON	Accelerator pedal: Fully released	0.3 - 1.2 V
ACCLL SEN 2	(Engine stopped)	Accelerator pedal: Fully depressed	3.7 - 4.8 V

<sup>\*:</sup> This signal is converted by ECM internally. Thus, this differs from ECM terminals voltage.

## On Board Diagnosis Logic

INFOID:0000000003759480

These self-diagnoses have the one trip detection logic.

MI will not light up for these self-diagnoses.

NOTE:

If DTC P0222 or P0223 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to <u>EC-214</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	Harness or connectors     (The APP sensor 2 circuit is open or
P0223 0223	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	shorted.)  • Accelerator pedal position sensor (Accelerator pedal position sensor 2)

### **DTC Confirmation Procedure**

INFOID:0000000003759481

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- Check DTC.
- If DTC is detected, go to EC-149, "Diagnosis Procedure".


P


http://probadordemodulos.wix.com/probadorautomotriz

Wiring Diagram

EC-APPS2-01







مر المحادث

Specification data are reference values and are measured between each terminal and ground.

Α

D

Е

## < SERVICE INFORMATION >

	NAL NO. e color)	Description	Condition	Value (Approx.)
+	-	Signal name		(Approx.)
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_
82 (W)	84 (R)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V
83	84	Accelerator pedal position sensor	[Ignition switch ON]  • Engine: Stopped  • Accelerator pedal: Fully released	0.5 - 1.0 V
(B)	· · ·	1	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully depressed	3.7 - 4.7 V
84 (R)	_	Accelerator pedal position sensor 1 ground	_	_
90 (L)	92 (Y)	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5 V
91	92	Accelerator pedal position sensor	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully released	0.15 - 0.6 V
(G)	(G) (Y)	2	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully depressed	1.85 - 2.4 V
92 (Y)	_	Accelerator pedal position sensor 2 ground	_	_

## **Diagnosis Procedure**

# 1. CHECK GROUND CONNECTIONS

Turn ignition switch OFF.

- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2) ECM (3)


### OK or NG

OK >> GO TO 2.


NG >> Repair or replace ground connections.

# 2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT

- Disconnect accelerator pedal position (APP) sensor (1) harness connector.
- Turn ignition switch ON.



INFOID:0000000003759483



http://probadordemodulos.wix.com/probadorautomotriz

## DTC P0222, P0223 APP SENSOR

#### < SERVICE INFORMATION >

[YD25DDTi]

3. Check voltage between APP sensor terminal 6 and ground with CONSULT-III or tester.




#### Voltage: Approximately 5 V

#### OK or NG

OK >> GO TO 3.

NG >> R

>> Repair open circuit or short to ground or short to power in harness or connectors.



JMBIA1368ZZ

# ${f 3.}$ CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check harness continuity between APP sensor terminal 3 and ECM terminal 92. Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminal 91 and APP sensor terminal 2. Refer to Wiring Diagram.

### Continuity should exist.

2. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 5

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK APP SENSOR

Refer to EC-150, "Component Inspection".

### OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

#### 6. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

## Component Inspection

INFOID:0000000003759484

#### ACCELERATOR PEDAL POSITION SENSOR

- 1. Reconnect all harness connectors disconnected.
- 2. Turn ignition switch ON.
- Check voltage between ECM harness connector terminals as follows.

## DTC P0222, P0223 APP SENSOR

### < SERVICE INFORMATION >

[YD25DDTi]

ECM			Condition			
+ -					Voltage	
Connector	Terminal	Terminal				
M33	83 84 (APP sensor 1 signal) (Sensor ground)	Accelerator pedal	Fully released	0.5 - 1.0 V		
		(Sensor ground)	r ground)	Fully depressed	3.7 - 4.7 V	
	91	91 92	Accelerator podal	Fully released	0.15 - 0.6 V	
	(APP sensor 2 signal) (Sensor ground)	Accelerator pedal	Fully depressed	1.85 - 2.4 V		

<sup>4.</sup> If NG, replace accelerator pedal assembly.

## Removal and Installation

INFOID:0000000003759485

ACCELERATOR PEDAL

Refer to "ACCELERATOR CONTROL SYSTEM" in FE section.

F

Α

С

D

Е

Н

. 1

Κ

L

M

Ν

0

Ρ


## DTC P0335 CKP SENSOR

## Description

The crankshaft position (CKP) sensor is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet and Hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change. The changing gap causes the magnetic field near the sensor to change. Due to the changing magnetic field, the voltage from the sensor changes. The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



### CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759501

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (TDC)	Run engine and compare CONSULT-III value with the tachometer indication.	Almost the same speed as the ta- chometer indication

## On Board Diagnosis Logic

INFOID:0000000003759502

#### NOTE:

If DTC P0335 is displayed with DTC P0642 or P0643, first perform trouble diagnosis for DTC P0642 or P0643. Refer to EC-210.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor circuit	Crankshaft position sensor signal is not detect by the ECM when engine is running.	Harness or connectors     (The sensor circuit is open or shorted.)     Crankshaft position sensor

#### **DTC Confirmation Procedure**

INFOID:0000000003759503

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and let it idle for at least 5 seconds.


  If engine could not start, keep ignition switch at START position for 5 seconds.
- 2. Check 1st trip DTC.
- 3. If 1st trip DTC is detected, go to EC-154, "Diagnosis Procedure".

Α

Ρ

Wiring Diagram

EC-CKP9=000000003759504



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

probadordemodulos@gmail.com

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)
+	_	Signal name		(,
46	65	Crankshaft position sensor	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 3.5 V ★  2.0 V/Div 2 ms/Div  MBIB0879E
(G)	(Y)		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 3.5 V ★  2.0 V/Div 2 ms/Div  MBIB0880E
65 (Y)	_	Crankshaft position sensor ground	_	_
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_
82 (W)	65 (Y)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V

## Diagnosis Procedure

INFOID:0000000003759506

# 1. CHECK GROUND CONNECTIONS

- 1. Turn ignition switch OFF.
- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1) Body ground M99 (2)
- ECM (3)

### OK or NG

OK >> GO TO 2.


NG >> Repair or replace ground connections.


# $2. {\sf CHECK\ CKP\ SENSOR\ POWER\ SUPPLY\ CIRCUIT}$

Disconnect crankshaft position (CKP) sensor (1) harness connector.

: Vehicle front

2. Turn ignition switch ON.





http://probadordemodulos.wix.com/probadorautomotriz


Check voltage between CKP sensor terminal 3 and ground with CONSULT-III or tester.



### Voltage: Approximately 5 V

#### OK or NG

OK >> GO TO 4. NG >> GO TO 3.



# 3.DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- Harness for open or short between CKP sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

# f 4.CHECK CKP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 65 and CKP sensor terminal 2. Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 6. NG >> GO TO 5.

## 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- Harness for open or short between CKP sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 6.CHECK CKP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

Check harness continuity between ECM terminal 46 and CKP sensor terminal 1. Refer to Wiring Diagram.

#### Continuity should exist.

2. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 8. >> GO TO 7. NG

## 7.DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- · Harness for open or short between CKP sensor and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK CRANKSHAFT POSITION SENSOR

EC

F

Н

M

Ν

Ρ

## < SERVICE INFORMATION >

Refer to EC-156, "Component Inspection".

OK or NG

OK >> GO TO 9.

NG >> Replace crankshaft position sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to EC-70.


### >> INSPECTION END

## Component Inspection

INFOID:0000000003759507

### **CRANKSHAFT POSITION SENSOR**

- 1. Loosen the fixing bolt of the sensor.
- 2. Disconnect crankshaft position sensor harness connector.
- 3. Remove the sensor.
- 4. Visually check the sensor for chipping.




MBIB0647E

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]	
1 (+) - 2 (-)	Except 0 or ∞	
1 (+) - 3 (-)	Except 0	
2 (+) - 3 (-)	Except 0	

6. If NG, replace crankshaft position sensor.



INFOID:0000000003759508

### Removal and Installation

CRANKSHAFT POSITION SENSOR Refer to MT-3.

Α


## DTC P0336 CKP SENSOR

Description NFOID:000000003759509

The crankshaft position (CKP) sensor is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet and Hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change. The changing gap causes the magnetic field near the sensor to change. Due to the changing magnetic field, the voltage from the sensor changes. The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



INFOID:0000000003759510

#### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	
CKPS-RPM (TDC)	Tachometer: Connect     Run engine and compare CONSULT-III value with the tachometer indication.	Almost the same speed as the ta- chometer indication.	(

## On Board Diagnosis Logic

INFOID:0000000003759511

#### NOTE:

If DTC P0336 is displayed with DTC P0642 or P0643, first perform trouble diagnosis for DTC P0642 or P0643. Refer to EC-210.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0336 0336	Crankshaft position sensor circuit range/performance	Crankshaft position sensor signal is not in the normal pattern when engine is running.	Harness or connectors     (The sensor circuit is open or shorted.)     Crankshaft position sensor     Signal plate

### **DTC Confirmation Procedure**

INFOID:0000000003759512

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Start engine and let it idle for at least 5 seconds.
   If engine could not start, keep ignition switch at START position for 5 seconds.
- Check 1st trip DTC.

If 1st trip DTC is detected, go to <u>EC-159</u>, "<u>Diagnosis Procedure</u>".

Ν


M

K

Р

Wiring Diagram

EC-CKPS-01



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

## < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)	
+	_	Signal name		(πρριολ.)	
46	65	Crankshaft position sensor	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 3.5 V ★  2.0 V/Div 2 ms/Div  MBIB0879E	
(G)	(Y)	Crankshait position sensor	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 3.5 V ★  2.0 V/Div 2 ms/Div  MBIB0880E	
65 (Y)	_	Crankshaft position sensor ground	_	_	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	
82 (W)	65 (Y)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V	

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# Diagnosis Procedure

INFOID:0000000003759515

# 1.CHECK GROUND CONNECTIONS


- Turn ignition switch OFF.
- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2) ECM (3)

### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.

# 2. CHECK CKP SENSOR POWER SUPPLY CIRCUIT



Α

EC

D

Е

K

M

Ν 0


Ρ

#### < SERVICE INFORMATION >

 Disconnect crankshaft position (CKP) sensor (1) harness connector.

: Vehicle front

2. Turn ignition switch ON.




3. Check voltage between CKP sensor terminal 3 and ground with CONSULT-III or tester.



### **Voltage: Approximately 5 V**

#### OK or NG

OK >> GO TO 4. NG >> GO TO 3.



## 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- · Harness for open or short between CKP sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 4. CHECK CKP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 65 and CKP sensor terminal 2. Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 6. NG >> GO TO 5.

## 5.DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- Harness for open or short between CKP sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK CKP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminal 46 and CKP sensor terminal 1. Refer to Wiring Diagram.

### Continuity should exist.

2. Also check harness for short to ground and short to power.

Attp://prebadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

### DTC P0336 CKP SENSOR

#### [YD25DDTi] < SERVICE INFORMATION >

OK >> GO TO 8.

NG >> GO TO 7.

## 7. DETECT MALFUNCTIONING PART

Check the following.

- · Harness connectors E237, M279
- Harness for open or short between CKP sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 8. CHECK CRANKSHAFT POSITION SENSOR

Refer to EC-161, "Component Inspection".

### OK or NG

OK >> GO TO 9.

NG >> Replace crankshaft position sensor.

## 9.CHECK GEAR TOOTH

Visually check for chipping signal plate gear tooth.

## OK or NG

OK >> GO TO 10.

NG >> Replace the signal plate.

## 10. CHECK INTERMITTENT INCIDENT


Refer to EC-70.

#### >> INSPECTION END

## Component Inspection

#### CRANKSHAFT POSITION SENSOR


- 1. Loosen the fixing bolt of the sensor.
- 2. Disconnect crankshaft position sensor harness connector.
- 3. Remove the sensor.
- 4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]	
1 (+) - 2 (-)	Except 0 or ∞	
1 (+) - 3 (-)	Except 0	
2 (+) - 3 (-)	Εχεθρί σ	

If NG, replace crankshaft position sensor.



http://probadordemodulos.wix.com/probadorautomotriz

Α

EC

D

Е

Н

INFOID:0000000003759516

K

M

Ν

MBIB0647E

## **DTC P0336 CKP SENSOR**

< SERVICE INFORMATION >

[YD25DDTi]

Removal and Installation

INFOID:0000000003759517

CRANKSHAFT POSITION SENSOR Refer to  $\underline{\mathsf{MT-3}}$ .

Α

## DTC P0340 CMP SENSOR

Description NFOID:000000003759518

The camshaft position (CMP) sensor senses the retraction with camshaft (left side) to identify a particular cylinder. The camshaft position (CMP) sensor senses the piston position.


When the crankshaft position (CKP) sensor system becomes inoperative, the camshaft position (CMP) sensor provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.



INFOID:0000000003759519

## On Board Diagnosis Logic

#### NOTE:

If DTC P0340 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to EC-214.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340 0340	Camshaft position sensor circuit	Camshaft position sensor signal is not detect by the ECM when engine is running.	Harness or connectors     (The sensor circuit is open or shorted.)     Camshaft position sensor

### **DTC Confirmation Procedure**

INFOID:0000000003759520

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Start engine and let it idle for at least 5 seconds.
   If engine could not start, keep ignition switch at START position for 5 seconds.
- 2. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-165</u>, "<u>Diagnosis Procedure</u>".

M

K


Н


Ν

Р

Wiring Diagram







GEC614A

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

### < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)	
+	_	Signal name		(Αρρίολ.)	
45 (W)	66 (B)	Camshaft position sensor power supply	[Ignition switch ON]	Approximately 5 V	
47	66		[Engine is running]  • Warm-up condition  • Idle speed NOTE: The pulse cycle changes depending or rpm at idle		Approximately 4.7 V ★  2.0 V/Div 20 ms/Div  MBIB0877E
(R)	(B)	Camshaft position sensor	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 4.7 V ★  2.0 V/Div 20 ms/Div  MBIB0878E	
66 (B)	_	Camshaft position sensor ground	_	_	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# Diagnosis Procedure

## 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.

- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

### OK or NG

OK >> GO TO 2.


NG >> Repair or replace ground connections.


# 2.CHECK CMP SENSOR POWER SUPPLY CIRCUIT

Disconnect camshaft position (CMP) sensor (1) harness connector.

: Vehicle front

Turn ignition switch ON.





Α

D

Е

Н

K

INFOID:0000000003759523

Ν

#### < SERVICE INFORMATION >

[YD25DDTi]

Check voltage between CMP sensor terminal 3 and ground with CONSULT-III or tester.




### **Voltage: Approximately 5 V**

#### OK or NG

OK >> GO TO 3.

NG

>> Repair open circuit or short to ground or short to power in harness or connectors.



# 3.CHECK CMP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 66 and CMP sensor terminal 2.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK CMP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

Check harness continuity between ECM terminal 47 and CMP sensor terminal 1. Refer to Wiring Diagram.

### Continuity should exist.

2. Also check harness for short to ground and short to power.

### OK or NG

OK

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## ${f 5.}$ CHECK CAMSHAFT POSITION SENSOR

Refer to EC-166, "Component Inspection".

#### OK or NG

OK >> GO TO 6.

NG >> Replace camshaft position sensor.

## 6.CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

## Component Inspection

INFOID:0000000003759524

#### CAMSHAFT POSITION SENSOR


- 1. Loosen the fixing bolt of the sensor.
- 2. Disconnect camshaft position sensor harness connector.
- Remove the sensor.

## **DTC P0340 CMP SENSOR**

## < SERVICE INFORMATION >

[YD25DDTi]

4. Visually check the sensor for chipping.



EC

C

Н

K

M

Ν

0

Ρ


Α

MBIB0647E

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
1 (+) - 2 (-)	
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	

6. If NG, replace camshaft position sensor.



INFOID:0000000003759525

## Removal and Installation

CAMSHAFT POSITION SENSOR Refer to "CYLINDER HEAD" in EM section.

http://probadordemodulos.wix.com/probadorautomotriz

INFOID:0000000003759526

## DTC P0341 CMP SENSOR

## Description

The camshaft position (CMP) sensor senses the retraction with camshaft (left side) to identify a particular cylinder. The camshaft position (CMP) sensor senses the piston position.


When the crankshaft position (CKP) sensor system becomes inoperative, the camshaft position (CMP) sensor provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.



INFOID:0000000003759527

## On Board Diagnosis Logic

#### NOTE:

If DTC P0341 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to <u>EC-214</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0341 0341	Camshaft position sensor circuit range/performance	Camshaft position sensor signal is not in the normal pattern when engine is running.	Harness connectors     (The sensor circuit is opener shorted.)     Camshaft position sensor     Starter motor     Starting system circuit     Signal plate

## **DTC Confirmation Procedure**

INFOID:0000000003759528

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Start engine and let it idle for at least 5 seconds.
   If engine could not start, keep ignition switch at START position for 5 seconds.
- 2. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-170</u>, "<u>Diagnosis Procedure</u>".

Α

EC

C

D

Е

F

Н

K

M

Ν


0

Ρ

Wiring Diagram

EC-CMP®=000000003759529

: Detectable line for DTC



4 5 24 23 22 21 20 19 18 17 16 15 14 13 12 17 43 42 41 40 39 38 37 36 35 34 33 32 31 30	1 10 9 8 7 6 0 29 28 27 26 25	<b></b>
1 2 62 61 60 59 58 57 56 55 54 53 52 51 50 48 81 80 79 78 77 76 75 74 73 72 71 70 69 68	9 48 47 46 45 44 B 67 66 65 64 63	(3 2 1) (M243) B

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

EC614A

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)
+	_	Signal name		(Αρριολ.)
45 (W)	66 (B)	Camshaft position sensor power supply	[Ignition switch ON]	Approximately 5 V
47	66	Camshaft position sensor	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 4.7 V ★  2.0 V/Div 20 ms/Div  MBIB0877E
(R)	(B)	·	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 4.7 V ★  → 2.0 V/Div 20 ms/Div MBIB0878E
66 (B)	_	Camshaft position sensor ground	_	_
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnosis Procedure

INFOID:0000000003759531

## 1. CHECK STARTING SYSTEM

Turn ignition switch to START position.

Does the engine turn over?

Does the starter motor operate?

### Yes or No

Yes >> GO TO 2.

No >> Check starting system. (Refer to "STARTING SYSTEM in EL section.)

# 2. CHECK GROUND CONNECTIONS


- 1. Turn ignition switch OFF.
- Loosen and retighten ground screws on the body. Refer to <u>EC-81</u>, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

#### OK or NG

OK >> GO TO 3.

NG >> Repair or replace ground connections.

# 3. CHECK CMP SENSOR POWER SUPPLY CIRCUIT




 Disconnect camshaft position (CMP) sensor (1) harness connector.

: Vehicle front

< SERVICE INFORMATION >

2. Turn ignition switch ON.



Check voltage between CMP sensor terminal 3 and ground with CONSULT-III or tester.




**Voltage: Approximately 5 V** 

#### OK or NG

OK >> GO TO 4.

NG >> Repair op

>> Repair open circuit or short to ground or short to power in harness or connectors.



MBIB1736E

4. CHECK CMP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

Turn ignition switch OFF.

2. Disconnect ECM harness connector.

3. Check harness continuity between ECM terminal 66 and CMP sensor terminal 2.

## Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK CMP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminal 47 and CMP sensor terminal 1. Refer to Wiring Diagram.

### Continuity should exist.

2. Also check harness for short to ground and short to power.

## OK or NG

OK >> GO TO 6

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### **6.**CHECK CAMSHAFT POSITION SENSOR

Refer to EC-172, "Component Inspection".

### OK or NG

OK >> GO TO 7.

NG >> Replace camshaft position sensor.

.CHECK CAMSHAFT (EXHAUST)

J

M

Ν

EC

Е

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

**EC-171** 

## < SERVICE INFORMATION >

Check the following.


- Accumulation of debris to the signal plate of camshaft (left side) (1)
- · Chipping signal plate of camshaft (left side) rear end

#### OK or NG

OK >> GO TO 8.

NG

>> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



## 8. CHECK INTERMITTENT INCIDENT

Refer to EC-70.


#### >> INSPECTION END

## Component Inspection

INFOID:0000000003759532

### **CAMSHAFT POSITION SENSOR**

- Loosen the fixing bolt of the sensor.
- Disconnect camshaft position sensor harness connector.
- 3. Remove the sensor.
- Visually check the sensor for chipping.




MBIB0647E

Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
1 (+) - 2 (-)	
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	

If NG, replace camshaft position sensor.



## Removal and Installation

**CAMSHAFT POSITION SENSOR** Refer to "CYLINDER HEAD" in EM section. INFOID:0000000003759533

# DTC P0380 GLOW RELAY

## On Board Diagnosis Logic

INFOID:0000000003759534

Α

EC

C

D

Е

F

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0380	Clow rolay aircuit	An excessively low voltage is sent to ECM through glow relay.	Harness or connectors     (The glow relay circuit is open or shorted.)     Glow relay
0380		An excessively high voltage is sent to ECM through glow relay.	Harness or connectors     (The glow relay circuit is shorted.)     Glow relay

## **DTC Confirmation Procedure**

INFOID:0000000003759535

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- 3. Check 1st trip DTC.
- 4. If 1st trip DTC is detected, go to EC-174, "Diagnosis Procedure".

Н

K

M

Ν


0


Ρ


Wiring Diagram

INFOID:0000000003759536

## EC-GLORLY-01







GEC615A

INFOID:0000000003759537

## Diagnosis Procedure


1. CHECK GLOW RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect glow relay (1).

http://probadordemodulos.wix.com/probadorautomotriz

 $\langle \neg$ : Vehicle front

< SERVICE INFORMATION >




Check voltage between ECM relay terminals 1, 3 and ground with CONSULT-III or tester.

### Voltage: Battery voltage

## OK or NG

>> GO TO 3. OK NG >> GO TO 2.



PBIB1413E

## 2 . DETECT MALFUNCTIONING PART

Check the following.

- 60A fusible link (letter b)
- Harness for open and short between glow relay and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 3.check glow relay output signal circuit for short to ground

- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 37 and glow relay terminal 2. Refer to Wiring Diagram.

#### Continuity should exist.

3. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 5. >> GO TO 4. NG

## 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E101, M5
- Harness for open and short between glow relay and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK GLOW RELAY

Refer to EC-176, "Component Inspection".

#### OK or NG

OK >> GO TO 6.

NG >> Replace glow relay.

### 6.CHECK INTERMITTENT INCIDENT

Refer to EC-70.

Н

EC

D

Е

K

M

Ν

Ρ

probadordemodulos@gmail.com

## **DTC P0380 GLOW RELAY**

### < SERVICE INFORMATION >

[YD25DDTi]

#### >> INSPECTION END


## Component Inspection

INFOID:0000000003759538

## **GLOW RELAY**

Check continuity between glow relay terminals 3 and 5 under the following conditions.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



Operation takes less than 1 second.

PBIB0428E

Α

EC

D

Н

## DTC P0403 EGR SYSTEM

Description NFOID:000000003759539

#### SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator	
Crankshaft position sensor	Engine speed			
Engine coolant temperature sensor	Engine coolant temperature			
Mass air flow sensor	Amount of intake air			
Accelerator pedal position sensor	Accelerator pedal position		EGR volume control valve	
Vehicle speed sensor	Vehicle speed*			
Ignition switch	Start signal	EGR volume control		
Air conditioner switch	Air conditioner operation*			
Intake air temperature sensor	Intake air temperature			
Barometric pressure sensor	Barometric pressure	-		
EGR volume control valve control position sensor	EGR volume control valve control position			


<sup>\*:</sup> This signal is sent to the ECM through CAN communication line.

This system controls the flow rate of EGR led from exhaust manifold to intake manifold. The opening of the EGR passage in the EGR volume control valve changes to control the EGR flow rate. A built-in DC motor moves the valve continuously corresponding to the ECM output signal. The EGR volume control valve control position sensor detects the valve position and sends the voltage signals to the ECM. The ECM judges the current opening angle of the valve from this signals and the ECM controls the DC motor to make the valve opening angle properly.

The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions.

The EGR volume control valve remains close under the following conditions.

- · Engine stopped
- Engine starting
- Low engine coolant temperature
- Excessively high engine coolant temperature
- High engine speed
- · Accelerator pedal fully depressed



EGR Volume Control Valve

F


Ν

http://probadordemodulos.wix.com/probadorautomotriz

#### < SERVICE INFORMATION >

The EGR volume control valve consists of valve, actuator and position sensor, etc. The valve is installed in EGR passage, and operated by the actuator according to the output signal of the ECM. The actuator used DC motor and it opens or closes the valve to change the EGR flow rate.

The EGR volume control valve control position sensor consists of a permanent magnet and Hall IC. It senses the valve shaft movement and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the valve from this signals, and controls the DC motor to make the valve opening angle in response to driving conditions.



INFOID:0000000003759540

### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EGR/V ANGLE	Ignition switch: ON (Engine stopped)	Approx. 0°
EGR V/POS SEN • Ignition switch: ON (Engine stopped)		1,050 - 1,350 mV

## On Board Diagnosis Logic

INFOID:0000000003759541

#### NOTE:

If DTC P0403 is displayed with DTC P0642 or P0643, first perform trouble diagnosis for DTC P0642 or P0643. Refer to EC-210.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0403 0403	EGR volume control valve stuck	Excessively high duty voltage signal is sent to the valve for the specified time.	Harness or connectors     (The EGR volume control valve circuit is open or shorted.)     EGR volume control valve stuck closed     EGR passage clogged

### **DTC Confirmation Procedure**

INFOID:0000000003759542

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


- 1. Start engine and warm it up to normal operating temperature.
- 2. Stop engine and wait at least 10 seconds.
- Restart engine and let it idle for 5 seconds.
- 4. Check 1st trip DTC.
- 5. If 1st trip DTC is detected, go to EC-180, "Diagnosis Procedure".

Α

Wiring Diagram

EC-EGRC 1 F- 10 0 000000003759543

: Detectable line for DTC : Non-detectable line for DTC



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

Ρ

	NAL NO. e color)	Description	Condition	Value (Approx.)
+	_	Signal name		(дрыск.)
7 (OR)	114 (B)	EGR volume control valve (Close)	[Ignition switch OFF]  • Warm-up condition  • For a few seconds after turning ignition switch OFF.	1.0 - 2.0 V★  ↑↓ (Periodically changes)  BATTERY VOLTAGE  (11 - 14 V)  MBIB1783E
8 (Y)	114 (B)	EGR volume control valve (Open)	[Ignition switch OFF]  • Warm-up condition  • For a few seconds after turning ignition switch OFF.	1.0 - 2.0 V★  ↑↓ (Periodically changes)  BATTERY VOLTAGE  (11 - 14 V)  MBIB1783E
77 (SB)	_	EGR volume control valve control position sensor ground	_	_
81 (P)	77 (SB)	EGR volume control valve control position sensor	<ul> <li>[Ignition switch OFF]</li> <li>Warm-up condition</li> <li>For a few seconds after turning ignition switch OFF.</li> </ul>	Voltage should fluctuates between 0.5 and 2.5 V, then drop to 0 V.
82 (W)	77 (SB)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnosis Procedure

INFOID:0000000003759544


# 1. CHECK GROUND CONNECTIONS

- 1. Turn ignition switch OFF.
- Loosen and retighten ground screws on the body. Refer to <u>EC-81</u>, "<u>Ground Inspection</u>".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

#### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.




2.CHECK EGR VOLUME CONTROL VALVE CONTROL POSITION SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.

Disconnect EGR volume control valve (1) harness connector.

: Vehicle front

Turn ignition switch ON.



Check voltage between EGR volume control valve terminal 3 and ground with CONSULT-III or tester.




EC

Е

### Voltage: Approximately 5 V

#### OK or NG

OK >> GO TO 4. NG >> GO TO 3.



JMBIA1444ZZ

### 3.DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E254, M285
- · Harness for open or short between EGR volume control valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4.check egr volume control valve control position sensor ground circuit for **OPEN AND SHORT** 

- Turn ignition switch OFF.
- Disconnect ECM harness connector.

Check harness continuity between ECM terminal 77 and EGR volume control valve terminal 4. Refer to Wiring Diagram.

M

Ν

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

### DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E254, M285
- Harness for open or short between EGR volume control valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 6.CHECK EGR VOLUME CONTROL VALVE CONTROL POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 81 and EGR volume control valve terminal 5. Refer to Wiring Diagram.

#### Continuity should exist.

http://probadordemodulos.wix.com/probadorautomotriz

#### < SERVICE INFORMATION >

2. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 8. NG >> GO TO 7.

### 7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E254, M285
- · Harness for open or short between EGR volume control valve and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

### 8. CHECK EGR VOLUME CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminals and EGR volume control valve terminals as follows. Refer to Wiring Diagram.

ECM terminal	EGR volume control valve terminal
7	2
8	1

### Continuity should exist.

2. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 10. NG >> GO TO 9.

### 9. DETECT MALFUNCTIONING PART

Check the following.

- · Harness connectors E254, M285
- · Harness for open or short between EGR volume control valve and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

### 10. CHECK EGR PASSAGE

Check the following for clogging and cracks.

- EGR tube
- EGR hose
- EGR cooler

#### OK or NG

OK >> GO TO 11.

NG >> Repair or replace EGR passage.

### 11. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### OK or NG

OK >> GO TO 12.

NG >> Repair or replace.

### 12. REPLACE EGR VOLUME CONTROL VALVE

- 1. Replace the EGR volume control valve.
- 2. Perform EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear".
- Perform EC-24, "EGR Volume Control Valve Closed Position Learning".

#### >> INSPECTION END

### **DTC P0403 EGR SYSTEM**

# < SERVICE INFORMATION >

[YD25DDTi]

Removal and Installation

INFOID:0000000003759545

EGR VOLUME CONTROL VALVE Refer to  $\underline{\mathsf{EM-6}}$ .

EC

Α

С

D

Е

F

G

Н

Κ

L

M

Ν

0

Ρ

### DTC P0405, P0406 EGR SENSOR

Description INFOID:000000003759546

#### SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator	
Crankshaft position sensor	Engine speed			
Engine coolant temperature sensor	Engine coolant temperature		EGR volume control valve	
Mass air flow sensor	Amount of intake air			
Accelerator pedal position sensor	Accelerator pedal position			
Vehicle speed sensor	Vehicle speed*			
Ignition switch	Start signal	EGR volume control		
Air conditioner switch	Air conditioner operation*			
Intake air temperature sensor	Intake air temperature			
Barometric pressure sensor	Barometric pressure			
EGR volume control valve control position sensor	EGR volume control valve control position			


<sup>\*:</sup> This signal is sent to the ECM through CAN communication line.

This system controls the flow rate of EGR led from exhaust manifold to intake manifold. The opening of the EGR passage in the EGR volume control valve changes to control the EGR flow rate. A built-in DC motor moves the valve continuously corresponding to the ECM output signal. The EGR volume control valve control position sensor detects the valve position and sends the voltage signals to the ECM. The ECM judges the current opening angle of the valve from this signals and the ECM controls the DC motor to make the valve opening angle properly.

The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions.

The EGR volume control valve remains close under the following conditions.

- · Engine stopped
- Engine starting
- · Low engine coolant temperature
- Excessively high engine coolant temperature
- High engine speed
- Accelerator pedal fully depressed




COMPONENT DESCRIPTION

EGR Volume Control Valve

The EGR volume control valve consists of valve, actuator and position sensor, etc. The valve is installed in EGR passage, and operated by the actuator according to the output signal of the ECM. The actuator used DC motor and it opens or closes the valve to change the EGR flow rate.

The EGR volume control valve control position sensor consists of a permanent magnet and Hall IC. It senses the valve shaft movement and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the valve from this signals, and controls the DC motor to make the valve opening angle in response to driving conditions.



INFOID:0000000003759547

EC

Е

F

Н

### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EGR/V ANGLE	Ignition switch: ON (Engine stopped)	Approx. 0°
EGR V/POS SEN	Ignition switch: ON (Engine stopped)	1,050 - 1,350 mV

### On Board Diagnosis Logic

INFOID:0000000003759548

#### NOTE:

If DTC P0405, P0406 is displayed with DTC P0642 or P0643, first perform trouble diagnosis for DTC P0642 or P0643. Refer to <u>EC-210</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0405 0405	EGR volume control valve control position sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	Harness or connectors     (The sensor circuit is open or shorted.)
P0406 0406	EGR volume control valve control position sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	EGR volume control valve control position sensor

### **DTC Confirmation Procedure**

INFOID:0000000003759549

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and warm it up to normal operating temperature.
- 2. Stop engine and wait at least 10 seconds.
- Restart engine and let it idle for 5 seconds.
- Check 1st trip DTC.
- 5. If 1st trip DTC is detected, go to <a href="EC-187"><u>EC-187</u></a>, "Diagnosis Procedure".

M


Ν

Ρ

http://probadordemodulos.wix.com/probadorautomotriz

Wiring Diagram





Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

Α

D E

Н

M

	NAL NO. color)	Description	Condition	Value (Approx.)
+	-	Signal name		
7 (OR)	114 (B)	EGR volume control valve (Close)	[Ignition switch OFF]  • Warm-up condition  • For a few seconds after turning ignition switch OFF.	1.0 - 2.0 V★ ↑↓ (Periodically changes) BATTERY VOLTAGE (11 - 14 V)  MBIB1783E
8 (Y)	114 (B)	EGR volume control valve (Open)	[Ignition switch OFF]  • Warm-up condition  • For a few seconds after turning ignition switch OFF.	1.0 - 2.0 V ↑↓ (Periodically changes) BATTERY VOLTAGE (11 - 14 V)
77 (SB)	-	EGR volume control valve control position sensor ground	_	<u>→ 5.0 V/DV 2 ms/Div [T]</u>
81 (P)	77 (SB)	EGR volume control valve control position sensor	<ul> <li>[Ignition switch OFF]</li> <li>Warm-up condition</li> <li>For a few seconds after turning ignition switch OFF.</li> </ul>	Voltage should fluctuates between 0.5 and 2.5 V, then drop to 0 V.
82 (W)	77 (SB)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# Diagnosis Procedure

INFOID:0000000003759551


# 1. CHECK GROUND CONNECTIONS

- 1. Turn ignition switch OFF.
- Loosen and retighten ground screws on the body. Refer to <u>EC-81</u>, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

#### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.



# $2. {\sf CHECK\ EGR\ VOLUME\ CONTROL\ VALVE\ CONTROL\ POSITION\ SENSOR\ POWER\ SUPPLY\ CIRCUIT}$


1. Turn ignition switch OFF.

http://probadordemodulos.wix.com/probadorautomotriz


2. Disconnect EGR volume control valve (1) harness connector.

: Vehicle front

3. Turn ignition switch ON.




4. Check voltage between EGR volume control valve terminal 3 and ground with CONSULT-III or tester.



### Voltage: Approximately 5 V

#### OK or NG

OK >> GO TO 4. NG >> GO TO 3.



### 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E254, M285
- · Harness for open or short between EGR volume control valve and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK EGR VOLUME CONTROL VALVE CONTROL POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 77 and EGR volume control valve terminal 4. Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 6. NG >> GO TO 5.

### 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E254, M285
- · Harness for open or short between EGR volume control valve and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

# **6.**CHECK EGR VOLUME CONTROL VALVE CONTROL POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminal 81 and EGR volume control valve terminal 5. Refer to Wiring Diagram.

### Continuity should exist.

### DTC P0405, P0406 EGR SENSOR

[YD25DDTi] < SERVICE INFORMATION > 2. Also check harness for short to ground and short to power. Α OK or NG OK >> GO TO 8. >> GO TO 7. NG 7. DETECT MALFUNCTIONING PART Check the following. Harness connectors E254, M285 · Harness for open or short between EGR volume control valve and ECM >> Repair open circuit or short to ground or short to power in harness or connectors. D 8. CHECK INTERMITTENT INCIDENT Refer to EC-70. Е OK or NG OK >> GO TO 9. NG >> Repair or replace. 9. REPLACE EGR VOLUME CONTROL VALVE Replace the EGR volume control valve. Perform <u>EC-24</u>, "<u>EGR Volume Control Valve Closed Position Learning Value Clear</u>". Perform <u>EC-24</u>, "<u>EGR Volume Control Valve Closed Position Learning</u>". 2. >> INSPECTION END Н Removal and Installation INFOID:0000000003759552 EGR VOLUME CONTROL VALVE Refer to EM-6. M

Р

### DTC P0409 EGR SYSTEM

Description INFOID:000000003759553

#### SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator	
Crankshaft position sensor	Engine speed			
Engine coolant temperature sensor	Engine coolant temperature			
Mass air flow sensor	Amount of intake air			
Accelerator pedal position sensor	Accelerator pedal position		EGR volume control valve	
Vehicle speed sensor	Vehicle speed*	=		
Ignition switch	Start signal	EGR volume control		
Air conditioner switch	Air conditioner operation*			
Intake air temperature sensor	Intake air temperature			
Barometric pressure sensor	Barometric pressure			
EGR volume control valve control position sensor	EGR volume control valve control position			


<sup>\*:</sup> This signal is sent to the ECM through CAN communication line.

This system controls the flow rate of EGR led from exhaust manifold to intake manifold. The opening of the EGR passage in the EGR volume control valve changes to control the EGR flow rate. A built-in DC motor moves the valve continuously corresponding to the ECM output signal. The EGR volume control valve control position sensor detects the valve position and sends the voltage signals to the ECM. The ECM judges the current opening angle of the valve from this signals and the ECM controls the DC motor to make the valve opening angle properly.

The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions.

The EGR volume control valve remains close under the following conditions.

- · Engine stopped
- Engine starting
- Low engine coolant temperature
- Excessively high engine coolant temperature
- High engine speed
- Accelerator pedal fully depressed




COMPONENT DESCRIPTION

EGR Volume Control Valve

The EGR volume control valve consists of valve, actuator and position sensor, etc. The valve is installed in EGR passage, and operated by the actuator according to the output signal of the ECM. The actuator used DC motor and it opens or closes the valve to change the EGR flow rate.

The EGR volume control valve control position sensor consists of a permanent magnet and Hall IC. It senses the valve shaft movement and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the valve from this signals, and controls the DC motor to make the valve opening angle in response to driving conditions.



INFOID:0000000003759554

### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EGR/V ANGLE	Ignition switch: ON (Engine stopped)	Approx. 0°
EGR V/POS SEN	Ignition switch: ON (Engine stopped)	1,050 - 1,350 mV

### On Board Diagnosis Logic

INFOID:0000000003759555

#### NOTE:

If DTC P0409 is displayed with DTC P0642 or P0643, first perform trouble diagnosis for DTC P0642 or P0643. Refer to EC-210.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0409 0409	EGR volume control valve does not operate properly.	The characteristic of EGR volume control valve is not in the specified range.	Harness or connectors     (EGR volume control valve circuit is open or shorted.)     EGR volume control valve

### **DTC Confirmation Procedure**

INFOID:0000000003759556

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### (P) WITH CONSULT-III

- 1. Start engine and warm it up to normal operating temperature.
- 2. Select "DATA MONITOR" mode with CONSULT-III.
- Confirm that engine coolant temperature is more than 81°C (178°F).
- 4. Stop engine and wait at least 10 seconds.
- 5. Restart engine and let it idle for 5 seconds.
- 6. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-193, "Diagnosis Procedure"</u>.

#### WITH GST

Follow the procedure "WITH CONSULT-III" above.

http://probadordemodulos.wix.com/probadorautomotriz

EC

Е

F

G

Н

J

M


Ν

0

Р

Wiring Diagram





Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

Α

D E

Н

M

Ν

### < SERVICE INFORMATION >

	NAL NO. color)	Description	Condition	Value (Approx.)
+	_	Signal name		(Арргох.)
7 (OR)	114 (B)	EGR volume control valve (Close)	[Ignition switch OFF]  • Warm-up condition  • For a few seconds after turning ignition switch OFF.	1.0 - 2.0 V★ ↑↓ (Periodically changes) BATTERY VOLTAGE (11 - 14 V)  MBIB1783E
8 (Y)	114 (B)	EGR volume control valve (Open)	[Ignition switch OFF]  • Warm-up condition  • For a few seconds after turning ignition switch OFF.	1.0 - 2.0 V  ↑↓ (Periodically changes)  BATTERY VOLTAGE  (11 - 14 V)
77 (SB)	_	EGR volume control valve control position sensor ground	_	
81 (P)	77 (SB)	EGR volume control valve control position sensor	<ul> <li>[Ignition switch OFF]</li> <li>Warm-up condition</li> <li>For a few seconds after turning ignition switch OFF.</li> </ul>	Voltage should fluctuates between 0.5 and 2.5 V, then drop to 0 V.
82 (W)	77 (SB)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# 1.CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.


Diagnosis Procedure

- 2. Loosen and retighten ground screws on the body. Refer to <u>EC-81</u>, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

#### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.



INFOID:0000000003759558

# $2. {\sf CHECK\ EGR\ VOLUME\ CONTROL\ VALVE\ CONTROL\ POSITION\ SENSOR\ POWER\ SUPPLY\ CIRCUIT}$

1. Turn ignition switch OFF.

http://probadordemodulos.wix.com/probadorautomotriz


probadordemodulos@gmail.com

### < SERVICE INFORMATION >

2. Disconnect EGR volume control valve (1) harness connector.

: Vehicle front

3. Turn ignition switch ON.



[YD25DDTi]


4. Check voltage between EGR volume control valve terminal 3 and ground with CONSULT-III or tester.



### Voltage: Approximately 5 V

#### OK or NG

OK >> GO TO 4. NG >> GO TO 3.



### 3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E254, M285
- · Harness for open or short between EGR volume control valve and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK EGR VOLUME CONTROL VALVE CONTROL POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 77 and EGR volume control valve terminal 4. Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 6. NG >> GO TO 5.

### 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E254, M285
- · Harness for open or short between EGR volume control valve and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

# **6.**CHECK EGR VOLUME CONTROL VALVE CONTROL POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 81 and EGR volume control valve terminal 5. Refer to Wiring Diagram.

### Continuity should exist.

#### DTC P0409 EGR SYSTEM

[YD25DDTi] < SERVICE INFORMATION > 2. Also check harness for short to ground and short to power. Α OK or NG OK >> GO TO 8. >> GO TO 7. NG EC . DETECT MALFUNCTIONING PART Check the following. Harness connectors E254, M285 Harness for open or short between EGR volume control valve and ECM >> Repair open circuit or short to ground or short to power in harness or connectors. D 8.CHECK EGR VOLUME CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT Check harness continuity between ECM terminals and EGR volume control valve terminals as follows. Е Refer to Wiring Diagram. ECM terminal EGR volume control valve terminal 7 2 8 Continuity should exist. 2. Also check harness for short to ground and short to power. Н OK or NG OK >> GO TO 10. NG >> GO TO 9. 9. DETECT MALFUNCTIONING PART Check the following. Harness connectors E254, M285 Harness for open or short between EGR volume control valve and ECM >> Repair open circuit or short to ground or short to power in harness or connectors. 10. CHECK INTERMITTENT INCIDENT Refer to EC-70. OK or NG OK >> GO TO 11. NG >> Repair or replace. M 11. REPLACE EGR VOLUME CONTROL VALVE Replace the EGR volume control valve. Perform EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear". Ν Perform EC-24, "EGR Volume Control Valve Closed Position Learning". >> INSPECTION END Removal and Installation INFOID:0000000003759559 Р EGR VOLUME CONTROL VALVE Refer to EM-6.

### DTC P0488 EGR SYSTEM

Description INFOID:000000003759601

#### SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator	
Crankshaft position sensor	Engine speed			
Engine coolant temperature sensor	Engine coolant temperature		EGR volume control valve	
Mass air flow sensor	Amount of intake air			
Accelerator pedal position sensor	Accelerator pedal position			
Vehicle speed sensor	Vehicle speed*			
Ignition switch	Start signal	EGR volume control		
Air conditioner switch	Air conditioner operation*			
Intake air temperature sensor	Intake air temperature			
Barometric pressure sensor	Barometric pressure			
EGR volume control valve control position sensor	EGR volume control valve control position			


<sup>\*:</sup> This signal is sent to the ECM through CAN communication line.

This system controls the flow rate of EGR led from exhaust manifold to intake manifold. The opening of the EGR passage in the EGR volume control valve changes to control the EGR flow rate. A built-in DC motor moves the valve continuously corresponding to the ECM output signal. The EGR volume control valve control position sensor detects the valve position and sends the voltage signals to the ECM. The ECM judges the current opening angle of the valve from this signals and the ECM controls the DC motor to make the valve opening angle properly.

The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions.

The EGR volume control valve remains close under the following conditions.

- · Engine stopped
- Engine starting
- · Low engine coolant temperature
- Excessively high engine coolant temperature
- High engine speed
- Accelerator pedal fully depressed




COMPONENT DESCRIPTION

EGR Volume Control Valve

The EGR volume control valve consists of valve, actuator and position sensor, etc. The valve is installed in EGR passage, and operated by the actuator according to the output signal of the ECM. The actuator used DC motor and it opens or closes the valve to change the EGR flow rate.

The EGR volume control valve control position sensor consists of a permanent magnet and Hall IC. It senses the valve shaft movement and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the valve from this signals, and controls the DC motor to make the valve opening angle in response to driving conditions.



INFOID:0000000003759602

Е

F

Н

### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
EGR/V ANGLE	Ignition switch: ON (Engine stopped)		Approx. 0°
EGR V/POS SEN	Ignition switch: ON (Engine stopped)		1,050 - 1,350 mV

### On Board Diagnosis Logic

INFOID:0000000003759603

#### NOTE:

If DTC P0488 is displayed with DTC P0642 or P0643, first perform trouble diagnosis for DTC P0642 or P0643. Refer to EC-210.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0488 0488	EGR driving circuit does not function properly.	The ECM internal circuit for driving the EGR volume control valve does not function properly due to high temperature or excessive current.	Harness or connectors     (The EGR volume control valve circuit is shorted.)     EGR volume control valve     ECM

### **DTC Confirmation Procedure**

INFOID:0000000003759604

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and warm it up to normal operating temperature.
- 2. Stop engine and wait at least 10 seconds.
- 3. Restart engine and let it idle for 5 seconds.
- 4. Check 1st trip DTC.
- 5. If 1st trip DTC is detected, go to EC-199, "Diagnosis Procedure".

M

N


 $\cap$ 

Ρ

http://probadordemodulos.wix.com/probadorautomotriz

Wiring Diagram

# EC-EGRC2-01 : Detectable line for DTC : Non-detectable line for DTC



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

	NAL NO. e color)	Description	Condition	Value (Approx.)
+	_	Signal name		(Арргох.)
7 (OR)	114 (B)	EGR volume control valve (Close)	[Ignition switch OFF]  • Warm-up condition  • For a few seconds after turning ignition switch OFF.	1.0 - 2.0 V★  ↑↓ (Periodically changes)  BATTERY VOLTAGE  (11 - 14 V)  MBIB1783E
8 (Y)	114 (B)	EGR volume control valve (Open)	[Ignition switch OFF]  • Warm-up condition  • For a few seconds after turning ignition switch OFF.	1.0 - 2.0 V  ↑↓ (Periodically changes)  BATTERY VOLTAGE  (11 - 14 V)
77 (SB)	_	EGR volume control valve control position sensor ground	_	
81 (P)	77 (SB)	EGR volume control valve control position sensor	<ul> <li>[Ignition switch OFF]</li> <li>Warm-up condition</li> <li>For a few seconds after turning ignition switch OFF.</li> </ul>	Voltage should fluctuates between 0.5 and 2.5 V, then drop to 0 V.
82 (W)	77 (SB)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# 1. CHECK GROUND CONNECTIONS

1. Turn ignition switch OFF.

Diagnosis Procedure

- Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

#### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.

JMBIA1299ZZ 2.CHECK EGR VOLUME CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR  $\delta$ PEN AND SHORT

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

Α

D Е

Н

G

INFOID:0000000003759606

M

Ν

#### DTC P0488 EGR SYSTEM


#### < SERVICE INFORMATION >

1. Disconnect EGR volume control valve (1) harness connector.



- 2. Disconnect ECM harness connector.
- Check harness continuity between ECM terminals and EGR volume control valve terminals as follows. Refer to Wiring Diagram.

ECM terminal	EGR volume control valve terminal
7	2
8	1



### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 3. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### OK or NG

OK >> GO TO 4.

NG >> Repair or replace.

### 4. REPLACE EGR VOLUME CONTROL VALVE

- 1. Replace the EGR volume control valve.
- 2. Perform EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear".
- 3. Perform EC-24, "EGR Volume Control Valve Closed Position Learning".

#### >> INSPECTION END

### Removal and Installation

INFOID:0000000003759607

EGR VOLUME CONTROL VALVE Refer to EM-6.

### DTC P0563 BATTERY VOLTAGE

### On Board Diagnosis Logic

INFOID:0000000003759627

Α

EC

D

F

M

Ν

This self-diagnosis has the one trip detection logic. MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0563 0563	Battery voltage high	An excessively high voltage from the battery is sent to ECM.	Battery     Battery terminal     Alternator     Incorrect jump starting

### **DTC Confirmation Procedure**

INFOID:0000000003759628

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and let it idle for at least 35 seconds.
- 2. Check DTC.
- 3. If DTC is detected, go to EC-201, "Diagnosis Procedure".

### Diagnosis Procedure

INFOID:0000000003759629

### 1.INSPECTION START

Are jumper cables connected for the jump starting?

#### Yes or No

Yes >> GO TO 3. No >> GO TO 2.

### 2. CHECK BATTERY AND ALTERNATOR

Check that the proper type of battery and type of alternator are installed.

Refer to "BATTERY" and "CHARGING SYSTEM" in EL section.


### OK or NG

OK >> GO TO 5.

NG >> Replace with a proper one.

### 3.CHECK JUMPER CABLES INSTALLATION

Check that the jumper cables are connected in the correct sequence.



### OK or NG

OK >> GO TO 4.

NG >> Reconnect jumper cables properly.

### 4. CHECK BATTERY FOR BOOSTER

Check that the battery for the booster is a 12 V battery.

#### OK or NG

OK >> GO TO 5.

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

#### < SERVICE INFORMATION >

NG >> Change the vehicle for booster.

### ${f 5.}$ PERFORM DTC CONFIRMATION PROCEDURE AGAIN

### With CONSULT-III

- 1. Turn ignition switch ON.
- Select "SELF DIAG RESULTS" mode with CONSULT-III.
- Touch "ERASE".
- Perform EC-201, "DTC Confirmation Procedure", again.
- Is DTC P0563 displayed again?

### With GST

- 1. Turn ignition switch ON.
- 2. Select Service \$04 with GST.
- Perform EC-201, "DTC Confirmation Procedure", again.
- Is DTC P0563 displayed again?

#### Yes or No

>> GO TO 6. Yes No >> GO TO 7.

### 6.REPLACE ECM

- 1. Replace ECM.
- Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to EL-96, "ECM Re-communicating Function".
- Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
   Perform EGR Volume Control Valve Closed Position Learning Value Clear. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear.".
- 6. Perform EGR Volume Control Valve Closed Position Learning. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning".

#### >> INSPECTION END

### 7. CHECK ELECTRICAL PARTS DAMAGE

Check the following for damage.

- Wiring harness and harness connectors for burn
- Fuses for short

#### OK or NG


OK >> INSPECTION END

NG >> Repair or replace malfunctioning part. [YD25DDTi]

### DTC P0606 ECM

Description INFOID:0000000003759644

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



MBIB0625E

### On Board Diagnosis Logic

INFOID:0000000003759645

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0606 0606	Engine control module (Processor)	ECM calculation function is malfunctioning.	• ECM

### **DTC Confirmation Procedure**

INFOID:0000000003759646

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Turn ignition switch ON.
- Wait at least 5 seconds.
- Check 1st trip DTC.
- If 1st trip DTC is detected, go to EC-203, "Diagnosis Procedure".

### Diagnosis Procedure

INFOID:0000000003759647

### 1.INSPECTION START

### **With CONSULT-III**

- Turn ignition switch ON.
- Select "SELF DIAG RESULTS" mode with CONSULT-III. 2.
- Touch "ERASE".
- Perform EC-203, "DTC Confirmation Procedure", again.
- Is 1st trip DTC P0606 displayed again?

### **With GST**

- 1. Turn ignition switch ON.
- Select Service \$04 with GST.
- Perform EC-203, "DTC Confirmation Procedure", again.
- Is 1st trip DTC P0606 displayed again?

### Yes or No

Yes >> GO TO 2.

No >> INSPECTION END

### 2.REPLACE ECM

- 1 Replace ECM.
- Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to EL-96, "ECM Re-communicating Function".
- Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

EC

Α

M

Р

### DTC P0606 ECM

< SERVICE INFORMATION > [YD25DDTi]

5. Perform EGR Volume Control Valve Closed Position Learning Value Clear. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear".

6. Perform EGR Volume Control Valve Closed Position Learning. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning".

>> INSPECTION END

Α

EC

Е

Н

### DTC P0628, P0629 FUEL PUMP

Description NFOID:000000003759648

To control the amount of the fuel inhalation of the fuel pump, a plunger is built into the fuel pump. When the amount of the fuel inhalation of fuel increases, the fuel pump raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to the fuel pump to raise the injection pressure.

### CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759649

Specification data are reference values.

MONITOR ITEM	CONDITIO	ON	SPECIFICATION
	Engine: After warming up	Idle	1,600 - 2,000 mA
PUMP CURRENT	<ul><li> Air conditioner switch: OFF</li><li> Shift lever: Neutral</li><li> No load</li></ul>	2,000 rpm	1,500 - 1,900 mA

### On Board Diagnosis Logic

INFOID:0000000003759650

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0628 0628	Fuel pump control circuit low input	ECM detects a control circuit for the fuel pump is open or short to ground.	Harness or connectors     (The fuel pump circuit is open or
P0629 0629	Fuel pump control circuit high input	ECM detects a control circuit for the fuel pump is short to power.	shorted.) • Fuel pump

### **DTC Confirmation Procedure**

INFOID:0000000003759651

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Start engine and warm it up to normal operating temperature.
- 2. Let engine idle for at least 5 seconds.
- 3. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-207</u>, "<u>Diagnosis Procedure</u>".

K

M

Ν

U

Р

SERVICE INFORMATION >

Wiring Diagram

EC-F/PUMP-01


EC-F/PUMP

EC-F/PUMP

EC-F/PUMP

EDetectable line for DTC

Non-detectable line for DTC



10

ECM (M32)

GEC621A

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

### < SERVICE INFORMATION >

	NAL NO. e color)	Description	Condition	Value (Approx.)	Α
+	-	Signal name		(//pp/6x.)	
10 114 (G) (B)		[Engine is running]  • Warm-up condition  • Idle speed	≫ 5 0 V/Div 5 ms/Div	C	
		Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>		E
29	114	Fuel numn	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>		G H
(B)	(B)	(B) Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>		J K

### Diagnosis Procedure

- 1. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
- 1. Turn ignition switch OFF.
- 2. Disconnect fuel pump (2) harness connector.
- Fuel pump temperature sensor (1)
- 3. Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 10 and fuel pump terminal 1. Refer to Wiring Diagram.

#### Continuity should exist.

5. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 3. NG >> GO TO 2.

### 2. DETECT MALFUNCTIONING PART

Check the following.

Harness connectors E237, M279

MBIB1751E

INFOID:0000000003759653

M

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

- · Harness for open or short between fuel pump and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

### 3.CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminal 29 and fuel pump terminal 2. Refer to Wiring Diagram.

### Continuity should exist.

2. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 5. NG >> GO TO 4.

### 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- Harness for open or short between fuel pump and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK FUEL PUMP

Refer to EC-208, "Component Inspection".

#### OK or NG

OK >> GO TO 7. NG >> GO TO 6.

### 6. REPLACE FUEL PUMP

- Replace fuel pump.
- 2. Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

#### >> INSPECTION END

### 7. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

### Component Inspection

**FUEL PUMP** 

- 1. Disconnect fuel pump harness connector.
- Check resistance between fuel pump terminals 1 and 2.

Resistance: 1.5 - 3.0  $\Omega$  [at 10 - 60°C (50 - 140°F)]

If NG, replace fuel pump.





JMBIA1445ZZ

INFOID:0000000003759654

### DTC P0628, P0629 FUEL PUMP

# < SERVICE INFORMATION >

Removal and Installation

[YD25DDTi] INFOID:0000000003759655

FUEL PUMP Refer to <u>EC-24</u>.

EC

Α

С

D

Е

F

G

Н

Κ

L

M

Ν

0

D

### DTC P0642, P0643 SENSOR POWER SUPPLY

### On Board Diagnosis Logic

INFOID:0000000003759660

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0642 0642	Sensor power supply circuit low	ECM detects a voltage of power source for sensor is excessively low.	Harness or connectors     (The APP sensor 1 power supply cir-
P0643 0643	Sensor power supply circuit high	ECM detects a voltage of power source for Sensor is excessively high.	cuit is shorted.) (Crankshaft position sensor circuit is shorted.) (EGR volume control valve control position sensor circuit is shorted.)  • Accelerator pedal position sensor (Accelerator pedal position sensor 1)  • Crankshaft position sensor  • EGR volume control valve control position sensor

### **DTC Confirmation Procedure**

INFOID:0000000003759661

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- 3. Check 1st trip DTC.
- 4. If 1st trip DTC is detected, go to EC-212, "Diagnosis Procedure".

Α

EC

C

D

Е

Н

K

M


Ν


0


Ρ

Wiring Diagram

EC-APP1PW 000000003759662







1 2 3 4 5 6 GY

Specification data are reference values and are measured between each terminal and ground.

-C622A

INFOID:0000000003759663

### < SERVICE INFORMATION >

	NAL NO. e color)	Description Condition		Value (Approx.)
+	_	Signal name		(Αρρίολ.)
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_
82 (W)	84 (R)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V
83	84	Accelerator pedal position sensor 1	<ul><li>[Ignition switch ON]</li><li>Engine: Stopped</li><li>Accelerator pedal: Fully released</li></ul>	0.5 - 1.0 V
(B)	(R)		[Ignition switch ON]     Engine: Stopped     Accelerator pedal: Fully depressed	3.9 - 4.7 V
84 (R)	_	Accelerator pedal position sensor 1 ground	_	_
90 (L)	92 (Y)	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5 V
91	92	Accelerator pedal position sensor 2	[Ignition switch ON]     Engine: Stopped     Accelerator pedal: Fully released	0.15 - 0.6 V
(G)	(Y)		[Ignition switch ON]     Engine: Stopped     Accelerator pedal: Fully depressed	1.85 - 2.4 V
92 (Y)	_	Accelerator pedal position sensor 2 ground	_	_

### Diagnosis Procedure

1. CHECK GROUND CONNECTIONS

Turn ignition switch OFF.

- Loosen and retighten ground screws on the body. Refer to <u>EC-81</u>, "<u>Ground Inspection</u>". Body ground M97 (1)
- Body ground M99 (2) ECM (3)


### OK or NG


OK >> GO TO 2.

NG >> Repair or replace ground connections.

# $2.\mathsf{CHECK}$ APP SENSOR 1 POWER SUPPLY CIRCUIT

- Disconnect accelerator pedal position (APP) sensor (1) harness connector.
- Turn ignition switch ON.





http://probadordemodulos.wix.com/probadorautomotriz


3. Check voltage between APP sensor terminal 4 and ground with CONSULT-III or tester.



### Voltage: Approximately 5 V

### OK or NG

OK >> GO TO 5. NG >> GO TO 3.



### 3. CHECK SENSOR POWER SUPPLY CIRCUITS

Check harness for short to power and short to ground, between the following terminals.

ECM terminal	ECM terminal Sensor terminal	
	APP sensor terminal 4	EC-211
82	Crankshaft position sensor terminal 3	EC-153
	EGR volume control valve terminal 3	<u>EC-186</u>

#### OK or NG

OK >> GO TO 4.

NG >> Repair short to ground or short to power in harness or connectors.

### 4. CHECK CRANKSHAFT POSITION SENSOR

Refer to EC-156, "Component Inspection".

#### OK or NG

OK >> GO TO 5.

NG >> Replace crankshaft position sensor.

### 5. CHECK APP SENSOR

Refer to EC-123, "Component Inspection".

#### OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

### 6.CHECK INTERMITTENT INCIDENT

Refer to EC-70.

### OK or NG

OK >> GO TO 7.

NG >> Repair or replace.

### .REPLACE EGR VOLUME CONTROL VALVE

- 1. Replace the EGR volume control valve.
- 2. Perform EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear".
- 3. Perform EC-24, "EGR Volume Control Valve Closed Position Learning".

#### >> INSPECTION END

Р

http://probadordemodulos.wix.com/probadorautomotriz

EC

D

Е

F

G

Н

1

M

.

0

### DTC P0652, P0653 SENSOR POWER SUPPLY

### On Board Diagnosis Logic

INFOID:0000000003759664

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P0652 0652	Sensor power supply circuit low	ECM detects a voltage of power source for sensor is excessively low.	Harness or connectors     (APP sensor 2 power supply circuit is shorted.)	
P0653 0653	Sensor power supply circuit high	ECM detects a voltage of power source for Sensor is excessively high.	<ul> <li>(Camshaft position sensor circuit is shorted.)</li> <li>(Fuel rail pressure sensor circuit is shorted.)</li> <li>Accelerator pedal position sensor</li> <li>(Accelerator pedal position sensor 2)</li> <li>Camshaft position sensor</li> <li>Fuel rail pressure sensor</li> </ul>	

### **DTC Confirmation Procedure**

INFOID:0000000003759665

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- 3. Check 1st trip DTC.
- 4. If 1st trip DTC is detected, go to EC-216, "Diagnosis Procedure".

Α

EC

C

D

Е

Н

K

M


Ν


0

Ρ

Wiring Diagram

EC-APP2PW=00000003759666





Specification data are reference values and are measured between each terminal and ground.

EC623A

### < SERVICE INFORMATION >

	NAL NO.	Description	Condition	Value (Approx.)
+	_	Signal name		(/ .pp. = //.)
45 (W)	66 (B)	Camshaft position sensor power supply	[Ignition switch ON]	Approximately 5 V
63 (R)	68 (B)	Fuel rail pressure sensor power supply	[Ignition switch ON]	Approximately 5 V
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_
82 (W)	84 (R)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V
83	84	Accelerator pedal position sensor 1	<ul><li>[Ignition switch ON]</li><li>Engine: Stopped</li><li>Accelerator pedal: Fully released</li></ul>	0.5 - 1.0 V
(B)	(R)		[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully depressed	3.7 - 4.7 V
84 (R)	_	Accelerator pedal position sensor 1 ground	_	_
90 (L)	92 (Y)	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5 V
91	92	Accelerator pedal position sensor	<ul><li>[Ignition switch ON]</li><li>Engine: Stopped</li><li>Accelerator pedal: Fully released</li></ul>	0.15 - 0.6 V
(G)	(Y)	2	<ul><li>[Ignition switch ON]</li><li>Engine: Stopped</li><li>Accelerator pedal: Fully depressed</li></ul>	1.85 - 2.4
92 (Y)	_	Accelerator pedal position sensor 2 ground	_	_

### **Diagnosis Procedure**

1. CHECK GROUND CONNECTIONS

Turn ignition switch OFF.


- Loosen and retighten ground screws on the body. Refer to <u>EC-81</u>, "<u>Ground Inspection</u>". Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.

### $2. {\sf CHECK\ APP\ SENSOR\ 2\ POWER\ SUPPLY\ CIRCUIT}$




INFOID:0000000003759667

### DTC P0652, P0653 SENSOR POWER SUPPLY

### < SERVICE INFORMATION >

[YD25DDTi]

- 1. Disconnect accelerator pedal position (APP) sensor (1) harness connector.
- Turn ignition switch ON.




3. Check voltage between APP sensor terminal 6 and ground with CONSULT-III or tester.



**Voltage: Approximately 5 V** 

#### OK or NG

OK >> GO TO 5. NG >> GO TO 3.



JMBIA1368ZZ

# 3. CHECK SENSOR POWER SUPPLY CIRCUITS

Check the following.

Harness for short to power and short to ground, between the following terminals.

ECM terminal	Sensor terminal	Reference Wiring Diagram
90	APP sensor terminal 6	EC-215
45	Camshaft position sensor terminal 3	EC-164
63	Fuel rail pressure sensor terminal 1	EC-129

#### OK or NG

OK >> GO TO 4.

NG >> Repair short to ground or short to power in harness or connectors.

### 4. CHECK COMPONENTS

Check the following.

- Camshaft position sensor (Refer to EC-166, "Component Inspection".)
- Fuel rail pressure sensor (Refer to EC-131, "Component Inspection".)

#### OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning component.

### 5. CHECK APP SENSOR

Refer to EC-150, "Component Inspection".

#### OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

### 6. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

EC

Е

F

r

M

Ν

0


Р

utomotriz probadordemodulos@gmail.com

### DTC P0668, P0669 ECM

Description INFOID:000000003759668

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



MBIB0625E

### On Board Diagnosis Logic

INFOID:0000000003759669

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0668 0668	ECM internal temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	• FCM
P0669 0669	ECM internal temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	LOW

### **DTC Confirmation Procedure**

INFOID:0000000003759670

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- Wait at least 5 seconds.
- 3. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-218, "Diagnosis Procedure"</u>.

### Diagnosis Procedure

INFOID:0000000003759671

### 1.INSPECTION START

### (III) With CONSULT-III

- 1. Turn ignition switch ON.
- Select "SELF DIAG RESULTS" mode with CONSULT-III.
- 3. Touch "ERASE".
- 4. Perform EC-218, "DTC Confirmation Procedure", again.
- 5. Is 1st trip DTC P0668 or P0669 displayed again?

### With GST

- Turn ignition switch ON.
- Select Service \$04 with GST.
- 3. Perform EC-218, "DTC Confirmation Procedure", again.
- 4. Is 1st trip DTC P0668 or P0669 displayed again?

#### Yes or No

Yes >> GO TO 2.

No >> INSPECTION END

# 2.REPLACE ECM

- 1. Replace ECM.
- Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to <u>EL-96</u>, "<u>ECM Re-communicating Function</u>".

Parto Balvi Per Adjusted M. 20 Pagistation and for the EC-22, "Injector adjustment and the Coginatation" in the Property of the Communication of the Communi

### **DTC P0668, P0669 ECM**

### < SERVICE INFORMATION >

[YD25DDTi]

- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
- Perform EGR Volume Control Valve Closed Position Learning Value Clear. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear".
- Perform EGR Volume Control Valve Closed Position Learning. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning".

>> INSPECTION END

EC

 $\mathbb{C}$ 

D

Е

F

G

Н

K

M

Ν

0

Ρ

### DTC P0686 ECM RELAY

### On Board Diagnosis Logic

INFOID:0000000003759672

This self-diagnosis has the one trip detection logic. The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0686 0686	ECM relay circuit	ECM detects ECM relay is stuck closed even if ignition switch OFF.	Harness or connectors     (The ECM relay circuit is shorted.)     ECM relay


### **DTC Confirmation Procedure**

INEOID:0000000003759673

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON and then turn OFF.
- 2. Wait at least 30 seconds.
- 3. Turn ignition switch ON.
- 4. Check DTC.
- 5. If DTC is detected, go to EC-224, "Diagnosis Procedure".



Specification data are reference values and are measured between each terminal and ground.

	NAL NO. color)	Description	Condition	Value (Approx.)
+	=	Signal name		(/ <b>(</b> PP10X1)
105 (G)	114 (P)	ECM relay (self shut-off)	[Ignition switch ON] [Ignition switch OFF] • For a few seconds after turning ignition switch OFF	0 - 1.0 V
113 (G)	(B)		[Ignition switch OFF]  • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)
107 (L) 108 (L)	114 (B)	Ignition switch	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)



Specification data are reference values and are measured between each terminal and ground.

	NAL NO. color)	Description	Condition	Value (Approx.)
+	_	Signal name		(/ (pprox.)
105 (G)	114 (B)	[Ignition switch ON] [Ignition switch OFF]  • For a few seconds after turning ignition switch OFF		0 - 1.0 V
113 (G)	(B) Economically (see struction)		[Ignition switch OFF]  • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)
107 (L) 108 (L)	114 (B)	Ignition switch	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)
119 (R) 120 (OR)	114 (B)	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14 V)

### Diagnosis Procedure

INFOID:0000000003759675

# 1. CHECK ECM RELAY INPUT SIGNAL CIRCUIT

- Turn ignition switch ON and then OFF. Check voltage between ECM harness connector terminals as follows.

	ECM				
+	-	-		Voltage	
Connector	Terminal	Connector	Terminal		
			1		
	440	M32	2		
	119		3		
M33		M33	114	After turning ignition switch OFF, battery voltage will	
IVI33			1	exist for a few seconds, then drop approximately 0 V.	
	420	M32	2		
	120		3		
		M33	114		

### OK or NG

>> GO TO 10. >> GO TO 2. OK NG

# 2. CHECK ECM RELAY SIGNAL CIRCUIT FOR SHORT TO GROUND

Check the voltage between ECM relay harness connector and ground.

ECM relay		Ground	Voltage	
Connector	Terminal	Ground	voltage	
E55	2	Ground	Battery voltage	
£55	3	Ground	Dattery voltage	

### OK or NG

>> GO TO 4. >> GO TO 3. OK NG

3. DETECT MALFUNCTIONING PART

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

Check the following.

- 20A fuse (No.36)
- Harness for open or short between Battery and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 4. CHECK ECM RELAY OUTPUT SIGNAL CIRCUIT

- 1. Turn ignition switch OFF, and wait at least 10 seconds.
- 2. Check voltage between ECM harness connector terminals as follows.

	ECM				
	+	-	_	Voltage	
Connector	Terminal	Connector	Terminal		
			1		
	105	M32	2		
			3	Pottory voltage	
M33		M33	114		
WISS			1	Battery voltage	
	113	M32	2		
	113		3		
		M33	114		

#### OK or NG

OK >> GO TO 7. NG >> GO TO 5.

### 5. CHECK ECM RELAY OUTPUT SIGNAL CIRCUIT FOR SHORT TO GROUND

- Disconnect ECM harness connector.
- 2. Disconnect ECM relay harness connector.
- 3. Check the continuity between ECM harness connector and ECM relay harness connector.

E	СМ	ECM	1 relay	Continuity
Connector	Terminal	Connector	Terminal	Continuity
M33	105	E55	1	Existed
IVISS	113	E33	ı	Existed

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 7. NG >> GO TO 6.

### 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E102, M13
- · Harness for open or short between ECM and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 7.CHECK ECM RELAY INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between ECM harness connector and ECM relay harness connector.

EC

Α

F

F

Н

K

L

. .

 $\mathbb{N}$ 

Ν

0

Р

E <sup>(</sup>	СМ	ECM relay		Continuity
Connector	Terminal	Connector	Terminal	Continuity
M33	119	E55	5	Existed
IVIOO	120	L00	5	LXISted

Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 9. NG >> GO TO 8.

## 8. DETECT MALFUNCTIONING PART

### Check the following.

- Harness connectors E91, M241 (LHD models)
- Harness connectors E102, M13 (RHD models)
- Harness for open or short between ECM and ÉCM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 9. CHECK ECM RELAY

Refer to EC-81

OK >> GO TO 10.

NG >> Replace ECM relay.

# 10. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### OK or NG

OK >> Replace ECM relay.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.


### Component Inspection

#### **ECM RELAY**

- Disconnect ECM relay.
- Check continuity between ECM relay terminals under the following conditions.

Terminals	Conditions	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Existed
	No current supply	Not existed

If NG, replace cooling fan relay.



PBIB0098E


INFOID:0000000003855862

INFOID:0000000003759684

### DTC P1268 - P1271 FUEL INJECTOR

### Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



INFOID:0000000003759685

INFOID:0000000003759686

### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	Engine: After warming up	No load	0.50 - 0.70 msec
MAIN INJ WID	Shift lever: Neutral     Idle speed	Blower fan switch: ON	0.50 - 0.80 msec

### On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic. The MI will not light up for these self-diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1268 1268	No. 1 cylinder fuel injector	The valve built into No. 1 cylinder fuel injector is not closed properly (stuck open) when the injector is not energized.	
P1269 1269	No. 2 cylinder fuel injector	The valve built into No. 2 cylinder fuel injector is not closed properly (stuck open) when the injector is not energized.	Harness or connectors     (The fuel pump circuit is open or shorted.)
P1270 1270	No. 3 cylinder fuel injector	The valve built into No. 3 cylinder fuel injector is not closed properly (stuck open) when the injector is not energized.	Fuel injector     Injector adjustment value
P1271 1271	No. 4 cylinder fuel injector	The valve built into No. 4 cylinder fuel injector is not closed properly (stuck open) when the injector is not energized.	

### **DTC Confirmation Procedure**

INFOID:0000000003759687

Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws when driving.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-III

- Start engine and let it idle for about 15 minutes.
- 2. Check DTC.
- If DTC is detected, go to EC-231, "Diagnosis Procedure". If DTC is not detected, go to next step.
- Drive vehicle and maintain the following conditions for at least 60 seconds.

EC

Α

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

M

Ν

0

CKPS-RPM	700 - 2,000 rpm (A constant rotation is maintained)
COOLAN TEMP/S	Less than 75°C (167°F)
Shift lever	Suitable position
Accelerator pedal	Hold the accelerator pedal as steady as possible.


### 5. Check DTC.

6. If DTC is detected, go to EC-231, "Diagnosis Procedure".

### **WITH GST**

Follow the procedure "WITH CONSULT-III" above.

Wiring Diagram



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

	NAL NO. color)	Description	Condition	Value (Approx.)
+	_	Signal name		(дрыск.)
4 (L)	114	Fuel injector power supply (For cylinder No. 1 and 3)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 7.5 V ★  10.0 V/Div 20 ms/Div T  MBIB1295E
5 (P)	(B)	Fuel injector power supply (For cylinder No. 2 and 4)	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 8.0 V ★  10.0 V/Div 20 mar/Div T  MBIB1296E
21 (Y) 22 (R)		Fuel injector No. 4  Fuel injector No. 4	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 7.5 V ★
23 (W)	114 (B)	Fuel injector No. 2		Approximately 8.0 V ★
24 (OR)	Fueli	Fuel injector No. 2	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	>> 10.0 V/Dlv 20 ms/Dlv T MBIB1298E
40 (G)		Fuel injector No. 3	[Engine is running]  • Warm-up condition  • Idle speed NOTE:	Approximately 7.5 V ★
41 (BR)	114 (B)	Fuel injector No. 3	The pulse cycle changes depending on rpm at idle	>> 10.0 V/Div 20 ms/Dw T MBIB1297E
42 (PU) 43 (SB)		Fuel injector No. 1  Fuel injector No. 1	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 8.0 V ★
				≫ 10.0 V/DIV 20 ms/DIV T MBIB1298E

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

### Diagnosis Procedure

INFOID:0000000003759690

### 1. CHECK INJECTOR ADJUSTMENT VALUE

- 1. Turn ignition switch ON.
- 2. Select "ENTER INJCTR CALIB DATA" in "WORK SUPPORT" mode with CONSULT-III.
- 3. Check injector adjustment values displayed on CONSULT-III screen.

The value displayed on CONSULT-III screen should be same as injector adjustment value printed on each fuel injector.

#### OK or NG

OK >> GO TO 2.


NG >> Perform Injector Adjustment Value Registration. Refer to <u>EC-22</u>, "Injector Adjustment Value Registration".

# 2.CHECK FUEL INJECTOR POWER SUPPLY CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect fuel injector (1) harness connector.

- 3. Disconnect ECM harness connector.
- Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

DTC	Terr	Cylinder			
510	ECM	Fuel injector	Cymraer		
P1268	4	1	No.1		
P1269	5	1	No.2		
P1270	4	1	No.3		
P1271	5	1	No.4		



### Continuity should exist.

5. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 3.CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

DTC	Terr	Cylinder	
510	ECM	Fuel injector	Cymraci
P1268	42, 43	2	No.1
P1269	23, 24	2	No.2
P1270	40, 41	2	No.3
P1271	21, 22	2	No.4

#### Continuity should exist.

2. Also check harness for short to ground and short to power. http://probadordemodulos.wix.com/probadorautomotriz http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com probadordemodulos@gmail.com

**EC-231** 

EC

Α

F

G

Н

J

\

N

M

Ν

C

Р

ŀ

### DTC P1268 - P1271 FUEL INJECTOR

#### < SERVICE INFORMATION >

[YD25DDTi]

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### 4.CHECK FUEL INJECTOR-I

Refer to EC-232, "Component Inspection".

#### OK or NG

OK >> GO TO 5. NG >> GO TO 6.

### 5. CHECK FUEL INJECTOR-II

# ® With CONSULT-III

1. Remove two fuel injectors.

#### NOTE:

One is from malfunctioning cylinder and the other is from any cylinder other than the malfunctioning cylinder.

- 2. Swap the two fuel injectors to the other cylinder.
- 3. Reconnect ECM harness connector and fuel injector harness connector.
- 4. Turn ignition switch ON.
- 5. Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".
- Select "SELF DIAG RESULTS" mode with CONSULT-III.
- 7. Touch "ERASE".
- 8. Perform EC-227, "DTC Confirmation Procedure".
- 9. Is DTC displayed for the other cylinder?

### **With GST**

1. Remove two fuel injectors.

#### NOTE:

One is from malfunctioning cylinder and the other is from any cylinder other than the malfunctioning cylinder.

- 2. Swap the two fuel injectors to the other cylinder.
- Reconnect ECM harness connector and fuel injector harness connector.
- 4. Turn ignition switch ON.
- 5. Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".
- Select Service \$04 with GST.
- 7. Perform EC-227, "DTC Confirmation Procedure".
- 8. Is DTC displayed for the other cylinder?

#### Yes or No

Yes >> GO TO 6. No >> GO TO 7.

### 6. REPLACE FUEL INJECTOR

- 1. Replace fuel injector of malfunctioning cylinder.
- Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".

#### >> INSPECTION END

### 7. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

### Component Inspection

INFOID:0000000003759691

#### **FUEL INJECTOR**

Disconnect fuel injector harness connector.

### DTC P1268 - P1271 FUEL INJECTOR

### < SERVICE INFORMATION >


[YD25DDTi]

2. Check resistance between terminals as shown in the figure.



Resistance: 0.2 - 0.8  $\Omega$  [at 10 - 60°C (50 - 140°F)]

3. If NG, replace fuel injector.



С

D

EC

Α

MBIB1735E

INFOID:0000000003759692

Removal and Installation

FUEL INJECTOR Refer to EM-8.

Е

G

F

Н

J

K

M

Ν

0

Ρ


### DTC P1272 FUEL PUMP

Description INFOID:0000000003759693

When the fuel pressure in fuel rail increases to excessively high, fuel pressure relief valve (1) opens to carry excess fuel to the return hose.

: Vehicle front

• Fuel rail pressure sensor (2)



### CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759694

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	Engine: After warming up	Idle	1,600 - 2,000 mA
PUMP CURRENT	<ul><li> Air conditioner switch: OFF</li><li> Shift lever: Neutral</li><li> No load</li></ul>	2,000 rpm	1,500 - 1,900 mA

### On Board Diagnosis Logic

INFOID:0000000003759695

#### NOTE:

If DTC P1272 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to EC-214.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1272 1272	Fuel rail pressure relief valve open	Fuel rail pressure relief valve is open because of fuel pressure control system malfunction.	Harness or connectors     (Fuel pump circuit is open or shorted.)     Fuel pump     Fuel rail pressure sensor     Air mixed with fuel     Lack of fuel

### DTC Confirmation Procedure

INFOID:0000000003759696


#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and keep engine speed more than 4,000 rpm for at least 5 seconds, then release the accelerator pedal.
- Check 1st trip DTC.
- 3. If 1st trip DTC is detected, go to <a href="EC-236">EC-236</a>, "Diagnosis Procedure".

Α

Wiring Diagram



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

	NAL NO. color)	Description	Condition	Value (Approx.)
+	_	Signal name		(,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
10 114			<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	Approximately 5.8 V ★
(G)	(B)	Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 5.5 V ★  → 5.0 V/Div 5 ms/Div T  MBIB0886E
29	114	Fuel aurae	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	Approximately 0.3 V ★  3.0 V/Div 5 ms/Div  MBIB0887E
(B)	(B)		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 0.3 V ★  1.0 V/Div 5 ms/Div  MBIB0888E

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnosis Procedure

INFOID:0000000003759698

### 1.PERFORM FUEL PUMP LEARNING VALUE CLEARING

#### NOTE:

If the DTC is detected because of air mixed with fuel (i.e.: caused by lack of fuel), it may become normal by performing following procedure.

### (III) With CONSULT-III

- 1. Turn ignition switch ON.
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
- Start engine and let it idle for at least 60 seconds.
- Select "SELF-DIAG RESULT" mode with CONSULT-III.
- 5. Touch "ERASE".
- 6. Perform EC-234, "DTC Confirmation Procedure", again.
- 7. Is 1st trip DTC detected again?

### **With GST**

- 1. Turn ignition switch ON.
- Perform Fuel Pump Learning Value Clearing. Refer to <u>EC-23, "Fuel Pump Learning Value Clearing".</u>
- 3. Start engine and let it idle for at least 60 seconds.
- Select Service \$04 with GST.

http://erfobadordemodulos.wikmano/probadorautagaotriz

probadordemodulos@gmail.com

6. Is 1st trip DTC detected again?

Yes or No

Yes >> GO TO 2.

>> INSPECTION END No

### 2.CHECK FUEL PUMP POWER SUPPLY CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector and fuel pump (2) harness connector.
- Fuel pump temperature sensor (1)
- 3. Check harness continuity between ECM terminal 10 and fuel pump terminal 1.

Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 4. >> GO TO 3. NG

# 3.DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- Harness for open or short between fuel pump temperature sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

### f 4.CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

Check harness continuity between ECM terminal 29 and fuel pump terminal 2. Refer to Wiring Diagram.

#### Continuity should exist.

2. Also check harness for short to ground and short to power.

#### OK or NG

>> GO TO 6. OK NG >> GO TO 5.

### DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- Harness for open or short between fuel pump temperature sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

### 6.CHECK FUEL PUMP

Refer to EC-238, "Component Inspection".

#### OK or NG

OK >> GO TO 8. NG >> GO TO 7.

#### / .REPLACE FUEL PUMP

- Replace fuel pump.
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

#### >> INSPECTION END

http://probadordemodulos.wix.com/probadorautomotriz

ↀ MBIB1751E

EC

Α

Е

Н

M

Ν

probadordemodulos@gmail.com

INFOID:0000000003759699

### < SERVICE INFORMATION >

### 8. CHECK FUEL RAIL PRESSURE SENSOR

Refer to EC-131, "Component Inspection".

OK or NG

OK >> GO TO 9.

NG >> Replace fuel rail.

9. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

### Component Inspection

### **FUEL PUMP**

- 1. Disconnect fuel pump harness connector.
- 2. Check resistance between fuel pump terminals 1 and 2.

Resistance: 1.5 - 3.0  $\Omega$  [at 10 - 60°C (50 - 140°F)]

3. If NG, replace fuel pump.





JMBIA1445ZZ

### Removal and Installation

FUEL RAIL Refer to EM-8.

**FUEL PUMP** 

Refer to EC-24.

INFOID:0000000003759700

INFOID:0000000003759702

### DTC P1273 FUEL PUMP

Description NFOID:000000003759701

To control the amount of the fuel inhalation of the fuel pump, a plunger is built into the fuel pump. When the amount of the fuel inhalation of fuel pump increases, the fuel raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to the fuel pump to raise the injection pressure.

# EC

Е

Н

Α

### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	Engine: After warming up	Idle	1,600 - 2,000 mA
PUMP CURRENT	<ul><li> Air conditioner switch: OFF</li><li> Shift lever: Neutral</li><li> No load</li></ul>	2,000 rpm	1,500 - 1,900 mA

### On Board Diagnosis Logic

#### INFOID:0000000003759703

#### NOTE:

 If DTC P1273 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to <u>EC-214</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1273 1273	Fuel pump insufficient flow	ECM detects the abnormal pulse of fuel pressure.	Harness or connectors     (The fuel pump circuit is open or shorted.)     Fuel pump     Injector adjustment value     Air mixed with fuel     Lack of fuel

### **DTC Confirmation Procedure**

INFOID:0000000003759704

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Start engine and warm it up to normal operating temperature.
- Keep engine speed more than 2,000 rpm for at least 10 seconds.
- Check 1st trip DTC.
- 4. If 1st trip DTC is detected, go to EC-241, "Diagnosis Procedure".

N


Ν


Р


Wiring Diagram

INFOID:0000000003759705

### EC-F/PUMP-01







GEC621A

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

INFOID:0000000003759706

M

Ν

0

	NAL NO. e color)	Description	Condition	Value (Approx.)	Α
+	_	Signal name			
			[Engine is running] • Warm-up condition • Idle speed	PARTONINATION OF THE PARTON OF	C
10	114	Fuel nump		MBIB0885E	D
(G)	(G) (B)	Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 5.5 V ★  S.0 V/Div 5 ms/Div T  MBIB0886E	E
29	114	Fuel nump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>		G H
(B)			[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	Approximately 0.3 V ★  >> 1.0 V/Div 5 ms/Div  MBIB0888E	J K

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# Diagnosis Procedure

1. CHECK INJECTOR ADJUSTMENT VALUE

1. Turn ignition switch ON.

- 2. Select "ENTER INJCTR CALIB DATA" in "WORK SUPPORT" mode with CONSULT-III.
- 3. Check injector adjustment values displayed on CONSULT-III screen.

The value displayed on CONSULT-III screen should be same as injector adjustment value printed on each fuel injector.

#### OK or NG

OK >> GO TO 2.

NG >> Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".

# 2.PERFORM FUEL PUMP LEARNING VALUE CLEARING

#### NOTE:

If the DTC is detected because of air mixed with fuel (i.e.: caused by lack of fuel), it may become normal by http://piibg.adowiegnords.com/probadorautomotriz probadordemodulos@gmail.com

### (III) With CONSULT-III

- 1. Turn ignition switch ON.
- Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
- 3. Start engine and let it idle for at least 60 seconds.
- 4. Select "SELF-DIAG RESULT" mode with CONSULT-III.
- 5. Touch "ERASE".
- 6. Perform EC-239, "DTC Confirmation Procedure", again.
- 7. Is 1st trip DTC detected again?

### With GST

- 1. Turn ignition switch ON.
- Perform Fuel Pump Learning Value Clearing. Refer to <u>EC-23, "Fuel Pump Learning Value Clearing"</u>.
- 3. Start engine and let it idle for at least 60 seconds.
- Select Service \$04 with GST.
- 5. Perform EC-239, "DTC Confirmation Procedure", again.
- 6. Is 1st trip DTC detected again?

### Yes or No

Yes >> GO TO 3.

No >> INSPECTION END

# 3.CHECK FUEL PUMP POWER SUPPLY CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- Disconnect ECM harness connector and fuel pump (2) harness connector.
- Fuel pump temperature sensor (1)
- 3. Check harness continuity between ECM terminal 10 and fuel pump terminal 1.

Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 5. NG >> GO TO 4.

### 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- Harness for open or short between fuel pump temperature sensor and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

# 5.CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminal 29 and fuel pump terminal 2. Refer to Wiring Diagram.

#### Continuity should exist.

2. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 7. NG >> GO TO 6.

### 6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- Harness for open or short between fuel pump temperature sensor and ECM

MRIR1751E

http://probadordemodulos.wx.com/probadorautomotriz probadordemodulos@gmail.com

### **DTC P1273 FUEL PUMP**

< SERVICE INFORMATION > [YD25DDTi]

### 7. CHECK FUEL PUMP

Refer to EC-243, "Component Inspection".

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.

8. REPLACE FUEL PUMP

- 1. Replace fuel pump.
- 2. Perform Fuel Pump Learning Valve Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

#### >> INSPECTION END

9. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

**Component Inspection** 

#### **FUEL PUMP**

- 1. Disconnect fuel pump harness connector.
- 2. Check resistance between fuel pump terminals 1 and 2.

Resistance: 1.5 - 3.0  $\Omega$  [at 10 - 60°C (50 - 140°F)]

3. If NG, replace fuel pump.





JMBIA1445ZZ

Removal and Installation

**FUEL PUMP** 

Refer to EC-24.

INFOID:0000000003759708

INFOID:0000000003759707

http://probadordemodulos.wix.com/probadorautomotriz

EC

С

D

Е

F

G

Н

J

1

M

L

Ν

0

P

### DTC P1274 FUEL PUMP

Description INFOID:000000003759709

To control the amount of the fuel inhalation of the fuel pump, a plunger is built into the fuel pump. When the amount of the fuel inhalation of fuel increases, the fuel pump raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to the fuel pump to raise the injection pressure.

### CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759710

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	Engine: After warming up	Idle	1,600 - 2,000 mA
PUMP CURRENT	<ul><li> Air conditioner switch: OFF</li><li> Shift lever: Neutral</li><li> No load</li></ul>	2,000 rpm	1,500 - 1,900 mA

### On Board Diagnosis Logic

INFOID:0000000003759711

This self-diagnosis has the one trip detection logic. NOTE:

If DTC P1274 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to EC-214.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1274 1274	Fuel pump protection	Fuel pressure is too much higher than the target value.	Harness or connectors     (The fuel pump circuit is open or shorted.)     Fuel pump     Fuel rail pressure sensor

### **DTC Confirmation Procedure**


INFOID:0000000003759712

#### NOTE

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Tuning ignition switch ON.
- 2. Start engine and let idle for at least 5 seconds.
- Check DTC.
- 4. If DTC is detected, go to <a href="EC-246">EC-246</a>, "Diagnosis Procedure".</a>

Wiring Diagram



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)
+	_	Signal name		(//pprox.)
10	10 114	Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	Approximately 5.8 V ★
(G) (B)	(B)	T del pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 5.5 V ★  → 5.0 V/Div 5 ms/Div T  MBIB0886E
	114	Fuel nump	[Engine is running]  • Warm-up condition  • Idle speed	Approximately 0.3 V ★  1.0 V/Div 5 ms/Div  MBIB0887E
	(B)	Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 0.3 V ★  → 1.0 V/Div 5 ms/Div  MBIB0888E

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# Diagnosis Procedure

INFOID:0000000003759714

# 1. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector and fuel pump (2) harness connector.
- Fuel pump temperature sensor (1)
- Check harness continuity between ECM terminal 10 and fuel pump terminal 1. Refer to Wiring Diagram.

#### Continuity should exist.


4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 3. NG >> GO TO 2.

2. DETECT MALFUNCTIONING PART

โห้โรรใช้ประชาชายีmodulos.wix.com/probadorautomotriz



probadordemodulos@gmail.com

>> INSPECTION END

Component Inspection

**FUEL PUMP** 

1. Disconnect fuel pump harness connector.

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

INFOID:0000000003759715

2. Check resistance between fuel pump terminals 1 and 2.



Resistance: 1.5 - 3.0  $\Omega$  [at 10 - 60°C (50 - 140°F)]

3. If NG, replace fuel pump.



JMBIA1445ZZ

INFOID:0000000003759716

Removal and Installation

FUEL PUMP Refer to <u>EC-24</u>.

INFOID:0000000003759718

### DTC P1275 FUEL PUMP

Description NFOID:000000003759717

To control the amount of the fuel inhalation of the fuel pump, a plunger is built into the fuel pump. When the amount of the fuel inhalation of fuel increases, the fuel pump raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to fuel pump to raise the injection pressure.

# EC

Е

F

Н

Α

### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITIO	ON	SPECIFICATION
	Engine: After warming up	Idle	1,600 - 2,000 mA
PUMP CURRENT	<ul><li> Air conditioner switch: OFF</li><li> Shift lever: Neutral</li><li> No load</li></ul>	2,000 rpm	1,500 - 1,900 mA

### On Board Diagnosis Logic

INFOID:0000000003759719

This self-diagnosis has the one trip detection logic.

NOTE:

If DTC P1275 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to <u>EC-214</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1275 1275	Fuel pump exchange	Fuel pressure is too much higher than the target value.	Harness or connectors     (The fuel pump circuit is open or shorted.)     Fuel pump     Fuel rail pressure sensor

### **DTC Confirmation Procedure**

INFOID:0000000003759720

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and warm it up to normal operating temperature.
- 2. Keep engine speed more than 2,000 rpm for at least 60 seconds.
- 3. Check DTC.
- If DTC is detected, go to <u>EC-251, "Diagnosis Procedure"</u>.

M

Ν

0


Р


http://probadordemodulos.wix.com/probadorautomotriz


Wiring Diagram

INFOID:0000000003759721

### EC-F/PUMP-01







GEC621A

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

	NAL NO. e color)	Description	Condition	Value (Approx.)
+		Signal name		
10 114 (G) (B)		<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	Approximately 5.8 V ★  Solution    MBIB0885E	
	(B)	Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 5.5 V ★  S.0 V/Div 5 ms/Div T  MBIB0886E
29 114 (B) (B)	Fuel nump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	Approximately 0.3 V ★  S  1.0 V/Div 5 ms/Div  MBIB0887E	
	(B)	Fuel pump	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 0.3 V ★    Solution   Solutio

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

### Diagnosis Procedure

1. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector and fuel pump (2) harness connector.
- Fuel pump temperature sensor (1)
- Check harness continuity between ECM terminal 10 and fuel pump terminal 1. Refer to Wiring Diagram.

#### Continuity should exist.


4. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 3. NG >> GO TO 2.

2. DETECT MALFUNCTIONING PART

The photograph of the probadorautomotriz of the probadorautomotriz of the probadorautomotriz of the probadorautomotriz of the probadorautomotriz



INFOID:0000000003759722

M

probadordemodulos@gmail.com probadordemodulos@gmail.com

- Harness connectors E237, M279
- · Harness for open or short between fuel pump temperature sensor and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

### 3.CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminal 29 and fuel pump terminal 2. Refer to Wiring Diagram.

### Continuity should exist.

2. Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 5. NG >> GO TO 4.

### 4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E237, M279
- · Harness for open or short between fuel pump temperature sensor and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

### 5. CHECK FUEL RAIL PRESSURE SENSOR

Refer to EC-131, "Component Inspection".

#### OK or NG

OK >> GO TO 6.

NG >> Replace fuel rail.

### 6.CHECK FUEL PUMP

Refer to EC-252, "Component Inspection".

#### OK or NG

OK >> GO TO 8. NG >> GO TO 7.

### 7. REPLACE FUEL PUMP

- 1. Replace fuel pump.
- 2. Perform Fuel Pump Learning Valve Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".

#### >> INSPECTION END

### 8.CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

### **Component Inspection**

INFOID:0000000003759723

#### **FUEL PUMP**

1. Disconnect fuel pump harness connector.

## **DTC P1275 FUEL PUMP**

## < SERVICE INFORMATION >

[YD25DDTi]

2. Check resistance between fuel pump terminals 1 and 2.



Resistance: 1.5 - 3.0  $\Omega$  [at 10 - 60°C (50 - 140°F)]

3. If NG, replace fuel pump.



С

D

EC

Α

JMBIA1445ZZ

JIVIDIA 1445ZZ

INFOID:0000000003759724

Removal and Installation

FUEL PUMP Refer to <u>EC-24</u>.

F

Е

G

Н

Κ

L

M

Ν

0


Р

# DTC P1622 INJECTOR ADJUSTMENT VALUE

Description INFOID:000000003759733

Injector adjustment value indicates manufacturing tolerance and the value is printed on the top of fuel injector. The injector adjustment value which is correctly stored in ECM is needed for precise fuel injection control. A performance of emission control and a drivability may effect when there is a mismatch between the following two values.

- The injector adjustment value stored in ECM
- The injector adjustment value of the fuel injector which is installed on the vehicle



Example: Injector adjustment value = D121ABCD1A061234000000000000E6

## On Board Diagnosis Logic

INFOID:0000000003759734

This self-diagnosis has the one trip detection logic. The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1622 1622	Injector adjustment value data uninput	Injector adjustment value is not stored in ECM.	Injector adjustment value     (Injector adjustment value has not     been written onto ECM memory yet,     or the value has been initialized.)

### **DTC Confirmation Procedure**

INFOID:0000000003759735

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Turn ignition switch ON.
- Wait at least 5 seconds.
- 3. Check DTC.
- 4. If DTC is detected, go to EC-254, "Diagnosis Procedure".

# Diagnosis Procedure

INFOID:0000000003759736

# 1.PERFORM INJECTOR ADJUSTMENT VALUE REGISTRATION

Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".


### >> INSPECTION END

# DTC P1623 INJECTOR ADJUSTMENT VALUE

Description NFOID:000000003759737

Injector adjustment value indicates manufacturing tolerance and the value is printed on the top of fuel injector. The injector adjustment value which is correctly stored in ECM is needed for precise fuel injection control. A performance of emission control and a drivability may effect when there is a mismatch between the following two values.

- The injector adjustment value stored in ECM
- The injector adjustment value of the fuel injector which is installed on the vehicle



Example: Injector adjustment value = D121ABCD1A06123400000000000E6

## On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic. The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1623 1623	Injector adjustment value data error	ECM detects the abnormal value of injector adjustment value.	CONSULT-III communication status     (The status of CONSULT-III communication becomes improper during Injector Adjustment Value Registration.)     ECM

#### NOTE:

This DTC is not detected when injector adjustment value (not correct but existent) is stored in ECM.

### **DTC Confirmation Procedure**

NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- Check DTC.
- If DTC is detected, go to <u>EC-255</u>, "<u>Diagnosis Procedure</u>".

# Diagnosis Procedure

1. CHECK INJECTOR ADJUSTMENT VALUE

- Turn ignition switch ON.
- 2. Select "ENTER INJCTR CALIB DATA" in "WORK SUPPORT" mode with CONSULT-III.
- 3. Check injector adjustment values displayed on CONSULT-III screen.

The value displayed on CONSULT-III screen should be same as injector adjustment value printed on each fuel injector.

Е

Α

EC

INFOID:0000000003759738

INFOID:0000000003759739

Ν

Р

M

INFOID:0000000003759740

each fuel injector.

### DTC P1623 INJECTOR ADJUSTMENT VALUE

[YD25DDTi] < SERVICE INFORMATION >

### OK or NG

OK >> GO TO 3. NG >> GO TO 2.

## 2.PERFORM INJECTOR ADJUSTMENT VALUE REGISTRATION

Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration". NOTE:

When two or more injector adjustment value are improper, it is useful to perform "INJ ADJ VAL CLR" in "WORK SUPPORT" mode with CONSULT-III. And then perform Injector Adjustment Value Registration.

>> GO TO 3.

# 3. PERFORM DTC CONFIRMATION PROCEDURE

# With CONSULT-III

- Select "SELF DIAG RESULTS" mode with CONSULT-III.
- Touch "ERASE".
- 3. Perform EC-255, "DTC Confirmation Procedure", again.
- 4. Is DTC P1623 displayed again?

## **With GST**

- 1. Select Service \$04 with GST.
- Perform EC-255, "DTC Confirmation Procedure", again.
- Is DTC P1623 displayed again?

### Yes or No

Yes >> GO TO 4.

>> INSPECTION END No

## 4.REPLACE ECM

- Replace ECM. 1.
- Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to EL-96, "ECM

- Re-communicating Function".

  Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".

  Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".


  Perform EGR Volume Control Valve Closed Position Learning Value Clear. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear".
- Perform EGR Volume Control Valve Closed Position Learning. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning".

### >> INSPECTION END

# DTC P2135 APP SENSOR

Description INFOID:0000000003759759

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensors detect the accelerator pedal position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.



### CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CON	DITION	SPECIFICATION
ACCEL POS SEN*	Ignition switch: ON	Accelerator pedal: Fully released	0.5 - 1.0 V
ACCEL FOO SEN	(Engine stopped)	Accelerator pedal: Fully depressed	4.0 - 4.8 V
ACCEL SEN 2*	Ignition switch: ON	Accelerator pedal: Fully released	0.3 - 1.2 V
ACCEL CENT	(Engine stopped)	Accelerator pedal: Fully depressed	3.7 - 4.8 V

<sup>\*:</sup> This signal is converted by ECM internally. Thus, it differs from ECM terminal voltage.

## On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

The MI will not light up for this self-diagnosis.

### NOTE:

- If DTC P2135 is displayed with DTC P0642 or P0643, first perform trouble diagnosis for DTC P0642 or P0643. Refer to <u>EC-210</u>.
- If DTC P2135 is displayed with DTC P0652 or P0653, first perform trouble diagnosis for DTC P0652 or P0653. Refer to <u>EC-214</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P2135 2135	Accelerator pedal position sensor 1, 2 signal correlation	The correlation between APP sensor 1 signal and APP sensor 2 signal is out of the normal range.	Harness or connectors (The APP sensor circuit is open or shorted.) Accelerator pedal position sensor (APP sensor 1 and 2)	M

### **DTC Confirmation Procedure**

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- Turn ignition switch ON.
- Wait at least 5 seconds.
- 3. Depress accelerator pedal slowly spending 5 seconds, and then release it slowly spending 5 seconds.
- Check DTC. 4.
- If DTC is detected, go to EC-259, "Diagnosis Procedure".

EC

INFOID:0000000003759760

INFOID:0000000003759761

INFOID:0000000003759762

http://probadordemodulos.wix.com/probadorautomotriz

Α

F


Н


Ν


Wiring Diagram

INFOID:0000000003759763

## EC-APPS3-01







GEC626A

Specification data are reference values and are measured between each terminal and ground.

## < SERVICE INFORMATION >

	NAL NO. e color)	Description	Condition	Value (Approx.)	
+	_	Signal name		(Арргох.)	
67 (B)	_	Sensor ground (Sensor shield circuit)	_	_	
82 (W)	84 (R)	Sensor power supply (Accelerator pedal position sensor 1 / Crankshaft position sensor / EGR volume control valve control position sensor)	[Ignition switch ON]	Approximately 5 V	
83	83 84 Accelerator pedal position sen (B) (R) 1	84	Accelerator pedal position sensor	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully released	0.5 - 1.0 V
(B)		1	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully depressed	3.7 - 4.7 V	
84 (R)	_	Accelerator pedal position sensor 1 ground	_	_	
90 (L)	92 (Y)	Accelerator pedal position sensor 2 power supply	[Ignition switch ON]	Approximately 5 V	
91	92	Accelerator pedal position sensor	[Ignition switch ON]  • Engine: Stopped  • Accelerator pedal: Fully released	0.15 - 0.6 V	
(G)	(Y)	2	[Ignition switch ON] • Engine: Stopped • Accelerator pedal: Fully depressed	1.85 - 2.4 V	
92 (Y)	_	Accelerator pedal position sensor 2 ground	_	_	

 $<sup>\</sup>bigstar$ : Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# Diagnosis Procedure

# 1. CHECK GROUND CONNECTIONS


- 1. Turn ignition switch OFF.
- 2. Loosen and retighten ground screws on the body. Refer to EC-81, "Ground Inspection".
- Body ground M97 (1)
- Body ground M99 (2)
- ECM (3)

### OK or NG

OK >> GO TO 2.

NG >> Repair or replace ground connections.

# 2. CHECK APP SENSOR POWER SUPPLY CIRCUIT



Α

EC

D

Е

G

Н

INFOID:0000000003759764

L


K

M

Ν

### < SERVICE INFORMATION >

- Disconnect accelerator pedal position (APP) sensor (1) harness connector.
- 2. Turn ignition switch ON.



3. Check voltage between APP sensor terminals 4, 6 and ground with CONSULT-III or tester.




### **Voltage: Approximately 5 V**

### OK or NG

OK >> GO TO 3.

NG >> Repair or

>> Repair open circuit or short to ground or short to power in harness or connectors.



# 3.check app sensor ground circuit for open and short

- 1. Turn ignition switch OFF.
- 2. Disconnect ECM harness connector.
- Check harness continuity between APP sensor terminals 1 and ECM terminal 84, APP sensor terminal 3 and ECM terminal 92.
   Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

# 4. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

 Check harness continuity between ECM terminal 83 and APP sensor terminal 5, ECM terminal 91 and APP sensor terminal 2. Refer to Wiring Diagram.

### Continuity should exist.

2. Also check harness for short to ground and short to power.

http://probadordemodulos.wix.com/probadorautomotriz

### OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK APP SENSOR

Refer to EC-261, "Component Inspection".

### OK or NG

OK >> GO TO 6.

NG >> Replace accelerator pedal assembly.

### 6.CHECK INTERMITTENT INCIDENT

Refer to EC-70.

## **DTC P2135 APP SENSOR**

## < SERVICE INFORMATION >

[YD25DDTi]

## >> INSPECTION END

## **Component Inspection**

### INFOID:0000000003759765

Α

EC

C

D

Е

F

### ACCELERATOR PEDAL POSITION SENSOR

- 1. Reconnect all harness connectors disconnected.
- 2. Turn ignition switch ON.
- 3. Check voltage between ECM harness connector terminal as follows.

ECM			Condition			
+ -		Voltage				
Connector	Terminal	Terminal				
	83	84	Accelerator pedal	Fully released	0.5 - 1.0 V	
M33	(APP sensor 1 signal) (Sensor	(Sensor ground)	Accelerator pedar	Fully depressed	3.7 - 4.7 V	
WISS -	91	92	A I I - I	Fully released	0.15 - 0.6 V	
	(APP sensor 2 signal) (Sensor ground)	Accelerator pedal	Fully depressed	1.85 - 2.4 V		

<sup>4.</sup> If NG, replace accelerator pedal assembly.

## Removal and Installation

INFOID:0000000003759766

ACCELERATOR PEDAL

Refer to "ACCELERATOR CONTROL SYSTEM" in FE section.

Н

K

ı

M

Ν

0


Р

INFOID:0000000003759767

# DTC P2146, P2149 FUEL INJECTOR POWER SUPPLY

## **Component Description**

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



## CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759768

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	Engine: After warming up	No load	0.50 - 0.70 msec
MAIN INJ WID	Shift lever: Neutral position     Idle speed	Blower fan switch: ON	0.50 - 0.80 msec

## On Board Diagnosis Logic

INFOID:0000000003759769

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2146 2146	No. 1 and 4 cylinder fuel injector power supply circuit open	An improper voltage signal is sent to ECM through No. 1 and 3 cylinder fuel injector.	Harness or connectors
P2149 2149	No. 2 and 3 cylinder fuel injector power supply circuit open	An improper voltage signal is sent to ECM through No. 2 and 4 cylinder fuel injector.	(The fuel injector circuit is open.)

## **DTC Confirmation Procedure**

INFOID:0000000003759770

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


### **TESTING CONDITION**

Before performing the following procedure, confirm the ambient temperature is more than -20°C (-4°F).

- 1. Start engine and let it idle for at least 5 seconds.
- 2. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-265, "Diagnosis Procedure"</u>.

Α

Wiring Diagram



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

	NAL NO. color)	Description	Condition	Value (Approx.)
+		Signal name		(Αργιολ.)
4 (L)	114	Fuel injector power supply (For cylinder No. 1 and 3)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 7.5 V ★
5 (P)	(B)	Fuel injector power supply (For cylinder No. 2 and 4)	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 8.0 V ★    Indicate   Property   Propert
21 (Y)		Fuel injector No. 4	[Engine is running]  • Warm-up condition  • Idle speed	Approximately 7.5 V ★
22 (R)	114	Fuel injector No. 4	NOTE: The pulse cycle changes depending on rpm at idle	>> 10.0 V/Div 20 ms/Div T MBIB1297E
23 (W)	(B)	Fuel injector No. 2		Approximately 8.0 V ★
24 (OR)		Fuel injector No. 2	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	>> 10.0 V/Div 20 ms/Div T MBIB1298E
40 (G)		Fuel injector No. 3	[Engine is running] • Warm-up condition • Idle speed	Approximately 7.5 V ★
41 (BR)	114	Fuel injector No. 3	NOTE: The pulse cycle changes depending on rpm at idle	>> 10.0 V/Div 20 ms/Div T
42 (PU)	(B)	Fuel injector No. 1	[Engine is running]	Approximately 8.0 V ★
43 (SB)		Fuel injector No. 1	Warm-up condition     Engine speed: 2,000 rpm	>> 10.0 V/Div 20 ms/Div T MBIB1298E

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## DTC P2146, P2149 FUEL INJECTOR POWER SUPPLY

### < SERVICE INFORMATION >

[YD25DDTi]


## Diagnosis Procedure

#### INFOID:0000000003759773

# 1. CHECK FUEL INJECTOR POWER SUPPLY CIRCUIT FOR OPEN

- 1. Turn ignition switch OFF.
- Disconnect fuel injector harness connector. Disconnect ECM harness connector.
- 4. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

Terr	Cylinder	
ECM		
4	1	No.1
5	1	No.2
4	1	No.3
5	1	No.4



## Continuity should exist.

## OK or NG

OK >> GO TO 2.

NG >> Repair open circuit in harness or connectors.

# 2. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

D

Е

Н

M


Ν

INFOID:00000000003759774

# DTC P2147, P2148 FUEL INJECTOR CIRCUIT

## Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



## CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759775

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	Engine: After warming up	No load	0.50 - 0.70 msec
MAIN INJ WID	Shift lever: Neutral     Idle speed	Blower fan switch: ON	0.50 - 0.80 msec

## On Board Diagnosis Logic

INFOID:0000000003759776

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P2147 2147	Fuel injector circuit low input	ECM detects the fuel injector circuit is shorted to ground.	Harness or connectors
P2148 2148	Fuel injector circuit high input	ECM detects the fuel injector circuit is shorted to power.	(The fuel injector circuit is shorted.)

## **DTC Confirmation Procedure**


INFOID:0000000003759777

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Start engine and let it idle for at least 5 seconds.
- 2. Check 1st trip DTC.
- If 1st trip DTC is detected, go to <u>EC-269, "Diagnosis Procedure".</u>

Wiring Diagram



Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-III.

	NAL NO. e color)	Description	Condition	Value (Approx.)
+	_	Signal name		(дрргох.)
4 (L)	114	Fuel injector power supply (For cylinder No. 1 and 3)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 7.5 V ★
5 (P)	(B)	Fuel injector power supply (For cylinder No. 2 and 4)	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 8.0 V ★    Indicate   Property   Propert
21 (Y) 22 (R)		Fuel injector No. 4  Fuel injector No. 4	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 7.5 V ★
23 (W)	114 (B)	Fuel injector No. 2	[Engine is running]	Approximately 8.0 V ★
24 (OR)		Fuel injector No. 2	Warm-up condition     Engine speed: 2,000 rpm	≥ 10.0 V/Dlv 20 ms/Dw T MBIB1298E
40 (G) 41 (BR)	114	Fuel injector No. 3  Fuel injector No. 3	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle</li> </ul>	Approximately 7.5 V ★
42 (PU)	(B)	Fuel injector No. 1  Fuel injector No. 1	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Engine speed: 2,000 rpm</li></ul>	Approximately 8.0 V ★
(SB)				20 ms/Div T MBIB1298E

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## **Diagnosis Procedure**

INFOID:0000000003759780


# 1. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

Disconnect fuel injector (1) harness connector.

: Vehicle front

- Disconnect ECM harness connector.
- Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

Terminal		Continuity
Fuel injector	ECM	Continuity
1	42, 43	Should not exist
	4	Should exist
2	42, 43	Should exist
2	4	Should not exist
1	23, 24	Should not exist
1	5	Should exist
2	23, 24	Should exist
	5	Should not exist
1	40, 41	Should not exist
	4	Should exist
2	40, 41	Should exist
2	4	Should not exist
4	21, 22	Should not exist
ı	5	Should exist
2	21, 22	Should exist
	5	Should not exist
	Fuel injector  1  2  1  2  1  2  1	Fuel injector     ECM       1 $42, 43$ 2 $42, 43$ 4 $42, 43$ 4 $23, 24$ 5 $23, 24$ 5 $40, 41$ 4 $40, 41$ 2 $40, 41$ 4 $40, 41$ 4 $40, 41$ 5 $40, 41$ 2 $40, 41$ 3 $40, 41$ 4 $40, 41$ 4 $40, 41$ 5 $40, 41$ 5 $40, 41$ 2 $40, 41$ 4 $40, 41$ 4 $40, 41$ 4 $40, 41$ 4 $40, 41$ 4 $40, 41$ 4 $40, 41$ 5 $40, 41$ 5 $40, 41$ 6 $40, 41$ 7 $40, 41$ 8 $40, 41$ 9 $40, 41$ 10 $40, 41$ 10 $40, 41$ 10 $40, 41$ 10 $40, 41$ 10 $40, 41$ 10 $40, 41$ 10 $40, 41$ 10 $40, 41$



4. Also check harness for short to ground and short to power.

## OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 2.CHECK FUEL INJECTOR

Refer to EC-270, "Removal and Installation".

### OK or NG

OK >> GO TO 4.

>> GO TO 3. NG

# 3. REPLACE FUEL INJECTOR

- Replace fuel injector of malfunctioning cylinder.
- Perform Injector Adjustment Value Registration. Refer to EC-22, "Injector Adjustment Value Registration".

## >> INSPECTION END

### 4. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

### >> INSPECTION END

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

EC

Α

C

Е

Н

M

Ν

# DTC P2147, P2148 FUEL INJECTOR CIRCUIT

< SERVICE INFORMATION >

[YD25DDTi]

# **Component Inspection**

INFOID:0000000003759781


### **FUEL INJECTOR**

- 1. Disconnect fuel injector harness connector.
- 2. Check resistance between terminals as shown in the figure.

Resistance: 0.2 - 0.8  $\Omega$  [at 10 - 60°C (50 - 140°F)]

3. If NG, replace fuel injector.





MBIB1735E

Removal and Installation

FUEL INJECTOR Refer to EM-8.

INFOID:0000000003759782


Α

EC

# DTC P2228, P2229 BARO SENSOR

Description NFOID:000000003759783

The barometric pressure sensor is built into ECM. The sensor detects ambient barometric pressure and sends the voltage signal to the microcomputer.



MBIB0625E

INFOID:0000000003759784

# On Board Diagnosis Logic

DTC No. Trouble diagnosis name DTC detecting condition Possible cause

P2228 Barometric pressure sensor (built-into ECM) is sent to ECM.

P2229 Barometric pressure sensor (built-into barometric pressure sensor barometric pressure sensor barometric pressure sensor (built-into barometric pressure sensor barometric pressure sensor

sor circuit high input pressure sensor (built-into ECM) is sent to ECM.

DTC Confirmation Procedure

INFOID:0000000003759785

INFOID:0000000003759786

Н

K

M

Ν

Р

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

- 1. Turn ignition switch ON.
- 2. Wait at least 5 seconds.
- 3. Check 1st trip DTC.
- If 1st trip DTC is detected, go to EC-271, "Diagnosis Procedure".

# Diagnosis Procedure

1.INSPECTION START

- With CONSULT-III
- Turn ignition switch ON.
- Select "SELF DIAG RESULTS" mode with CONSULT-III.
- 3. Touch "ERASE"
- 4. Perform EC-271, "DTC Confirmation Procedure", again.
- 5. Is 1st trip DTC P2228 or P2229 displayed again?

### With GST

- 1. Turn ignition switch ON.
- Select Service \$04 with GST.
- 3. Perform EC-271, "DTC Confirmation Procedure", again.
- 4. Is 1st trip DTC P2228 or P2229 displayed again?

### Yes or No

Yes >> GO TO 2.

No >> INSPECTION END

# 2.REPLACE ECM

- 1. Replace ECM.
- 2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to <u>EL-96</u>, <u>"ECM Re-communicating Function"</u>.

hatp: Preford doing to the control of the control o

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

## DTC P2228, P2229 BARO SENSOR

< SERVICE INFORMATION >

[YD25DDTi]

- 4. Perform Fuel Pump Learning Value Clearing. Refer to EC-23, "Fuel Pump Learning Value Clearing".
- 5. Perform EGR Volume Control Valve Closed Position Learning Value Clear. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning Value Clear".
- 6. Perform EGR Volume Control Valve Closed Position Learning. Refer to EC-24, "EGR Volume Control Valve Closed Position Learning".

>> INSPECTION END

Α

EC

D

Е

G

Н

## **GLOW CONTROL SYSTEM**

Description NFOID:000000003759800

### SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor	Engine speed		Glow lamp
Engine coolant temperature sensor	Engine coolant temperature	Glow control	Glow relay Glow plugs

When engine coolant temperature is more than approximately 80°C (176°F), the glow relay turns off. When coolant temperature is lower than approximately 80°C (176°F):

Ignition switch ON

After ignition switch has turned to ON, the glow relay turns ON for a certain period of time in relation to engine coolant temperature, allowing current to flow through glow plug.

Cranking

The glow relay turns ON, allowing current to flow through glow plug.

Starting


After engine has started, current continues to flow through glow plug (after-glow mode) for a certain period in relation to engine coolant temperature.

The glow indicator lamp turns ON for a certain period of time in relation to engine coolant temperature at the time glow relay is turned ON.

### COMPONENT DESCRIPTION

#### Glow Plug

The glow plug is provided with a ceramic heating element to obtain a high-temperature resistance. It glows in response to a signal sent from the ECM, allowing current to flow through the glow plug via the glow relay.



SEF376Y

M


K

Ν

Р

Wiring Diagram

INFOID:0000000003759801



# Diagnosis Procedure

INFOID:0000000003759802

GEC628A

## 1.INSPECTION START

Check fuel level, fuel supplying system, starter motor, etc.

OK or NG

http://probadordemodulos.wix.com/probadorautomotriz

OK >> GO TO 2.

NG >> Correct.


# 2.check installation

Check that glow plug nut (1) and all glow plug connecting plate (2) nuts are installed properly.

< : Vehicle front

### OK or NG

OK >> GO TO 3. NG >> Install properly.



# 3.CHECK GLOW INDICATOR LAMP OPERATION

## With CONSULT-III

1. Turn ignition switch ON.

Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-III.

3. Confirm that "COOLAN TEMP/S" indicates below 80°C (176°F). If it indicates above 80°C (176°F), cool down engine.

Turn ignition switch OFF, wait at least 5 seconds and then turn ON.

Make sure that glow indicator lamp is turned ON for 1.5 seconds or more after turning ignition switch ON, and then glow indicator lamp turned OFF.

### Without CONSULT-III

1. Check voltage between ECM harness connector terminals as follows.

ECM				
Connector	+	_		
Connector	Terminal	Terminal		
M32	51 (Engine coolant temperature sensor)	70 (Sensor ground)		

Confirm that the voltage indicates above 1.23 V. If it indicates below 1.23 V, cool down engine.

Turn ignition switch OFF, wait at least 5 seconds and then turn ON. 3.

Make sure that glow indicator lamp is turned ON for 1.5 seconds or more after turning ignition switch ON, and then glow indicator lamp turned OFF.

### OK or NG

>> GO TO 4. >> GO TO 5.

OK NG

# 4.CHECK GLOW CONTROL SYSTEM OVERALL FUNCTION

### (P) With CONSULT-III

Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-III.

Confirm that "COOLAN TEMP/S" indicates approximately 25°C (77°F). If NG, cool down engine.

Turn ignition switch OFF. 3.

Set voltmeter probe between glow plug and engine body. 4.

Turn ignition switch ON.

http://probadordemodulos.wix.com/probadorautomotriz

EC

Α

C

Е

F

Н

K

L

M

Ν


0

### < SERVICE INFORMATION >

Check the voltage between glow plug and engine body under the following conditions.

∵ Vehicle front

Conditions	Voltage
For 20 seconds after turning ignition switch ON	Battery voltage
More than 20 seconds after turning ignition switch ON	Approx. 0 V



### **W** Without CONSULT-III


Check voltage between ECM harness connector terminals as follows.

ECM				
Connector	+	=		
Connector	Terminal	Terminal		
M32	51 (Engine coolant temperature sensor)	70 (Sensor ground)		

- 2. Confirm that the voltage indicates approximately 3.59 V. If NG, cool down engine.
- Turn ignition switch OFF.
- 4. Set voltmeter probe between glow plug and engine body.
- 5. Turn ignition switch ON.
- Check the voltage between glow plug and engine body under the following conditions.

∵
 ∵
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴
 ∴

Conditions	Voltage
For 20 seconds after turning ignition switch ON	Battery voltage
More than 20 seconds after turning ignition switch ON	Approx. 0 V



#### OK or NG

OK >> INSPECTION END

NG >> GO TO 7.

## 5. CHECK DTC

Check that DTC U1000 is not displayed.

### Yes or No

Yes >> Perform trouble diagnoses for DTC U1000, refer to <u>EC-83</u>.

No >> GO TO 6.

### 6.CHECK COMBINATON METER OPERATION

Does combination meter operate normally?

### Yes or No

Yes >> GO TO 15.

No >> Check combination meter circuit. Refer to EL-51.

# 7.CHECK GLOW RELAY POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.

## **GLOW CONTROL SYSTEM**

### < SERVICE INFORMATION >

Disconnect glow relay (1) harness connector.

: Vehicle front




Check voltage between glow relay terminals 1, 3 and ground with CONSULT-III or tester.

### Voltage: Battery voltage

## OK or NG

OK >> GO TO 9. NG >> GO TO 8.



PBIB1413E

# 8. DETECT MALFUNCTIONING PART

Check the following.

- 60 A fusible link (letter b)
- Harness for open or short between glow relay and battery

>> Repair harness or connectors.

# 9.CHECK GLOW RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 37 and glow relay terminal 2. Refer to Wiring Diagram.

### Continuity should exist.

3. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 11. >> GO TO 10. NG

# 10. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E101, M5
- Harness for open or short between glow relay and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

## 11. CHECK HARNESS CONTINUITY BETWEEN GLOW RELAY AND GLOW PLUG FOR OPEN AND SHORT

- Disconnect glow plug harness connector.
- Check harness continuity between glow relay terminal 5 and glow plug harness connector. Refer to Wiring Diagram.

### Continuity should exist.

Also check harness for short to ground and short to power.

EC

Е

K

M

Ν

Р

http://probadordemodulos.wix.com/probadorautomotriz

### < SERVICE INFORMATION >

### OK or NG

OK >> GO TO 13.

NG >> GO TO 12.

# 12. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E72, E232
- Harness for open or short between glow relay and glow plug
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

# 13. CHECK GLOW RELAY

Refer to EC-278, "Component Inspection".

### OK or NG

OK >> GO TO 14.

NG >> Replace glow relay.

# 14. CHECK GLOW PLUG

Refer to EC-278, "Component Inspection".

### OK or NG

OK >> GO TO 15.

NG >> Replace glow plug.

# 15. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

### >> INSPECTION END

## Component Inspection


INFOID:0000000003759803

#### **GLOW RELAY**

Check continuity between glow relay terminals (3) and (5) under the following conditions.

Conditions	Continuity
12 V direct current supply between terminals (1) and (2)	Yes
No current supply	No

Operation takes less than 1 second.



PBIB0428E

### **GLOW PLUG**

1. Remove glow plug connecting plate (1).


: Vehicle front

- Glow plug (2)
- 2. Check glow plug resistance.

Resistance: Approximately 0.8  $\Omega$  [at 25°C (77°F)]

#### NOTE:

- Do not bump glow plug heating element. If it is bumped, replace glow plug with a new one.
- If glow plug is dropped from a height of 10 cm (3.94 in) or higher, replace with a new one.



## **GLOW CONTROL SYSTEM**

< SERVICE INFORMATION > [YD25DDTi]

• If glow plug installation hole is contaminated with carbon, remove it with a reamer or suitable tool.

 Hand-tighten glow plug by turning it two or three times, then tighten using a tool to specified torque.

[일: 20.1 N-m (2.1 kg-m, 15 ft-lb)

Removal and Installation

INFOID:0000000003759804

**GLOW PLUG** 

Refer to "CYLINDER HEAD" in EM section.

F

Е

EC

C

D

G

Н

K

L

 $\mathbb{N}$ 

Ν

0


# **HEAT UP SWITCH**

Description INFOID:000000003759811

The heat up switch (1) is located on the lower side of the instrument panel. This switch is used to speed up the heater's operation when the engine is cold. When the ECM received the heat up switch ON signal, the ECM increases the engine idle speed to 1,400 rpm to warm up engine quickly.

This system works when all conditions listed below are met.

Heat up switch	ON Shift
lever	Neutral
Accelerator pedal	Fully released




## CONSULT-III Reference Value in Data Monitor Mode

INFOID:0000000003759812

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
WARM UP SW	Ignition switch: ON	Heat up switch: OFF	OFF
WAINWOF 3W	• Ignition Switch. ON	Heat up switch: ON	ON



Specification data are reference values and are measured between each terminal and ground.

### < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)
+	-	Signal name		(Αρρίολ.)
13	114	Heat up switch	[Ignition switch ON] • Heat up switch: OFF	Approximately 0 V
(BR)	(B)	rieat up switch	[Ignition switch ON] • Heat up switch: ON	BATTERY VOLTAGE (11 - 14V)

## Diagnosis Procedure

INFOID:0000000003759814

# 1. CHECK OVERALL FUNCTION-I

# (III) With CONSULT-III

1. Turn ignition switch ON.

2. Check "WARM UP SW" in "DATA MONITOR" mode with CONSULT-III under the following conditions.

CONDITION	WARM UP SW
Heat up switch: OFF	OFF
Heat up switch: ON	ON

# **W** Without CONSULT-III

1. Turn ignition switch ON.

2. Check voltage between ECM harness connector terminals as follows.

ECM						
+ -			_	Condition		Voltage
Connector	Terminal	Connector	Terminal			
			1		ON	Battery voltage
M32	13	M32	2	Heat up awitab	Heat up switch	Battery voltage
		3	3	Heat up switch	OFF	Approx 0.V
		M33	114		OFF	Approx. 0 V

### OK or NG

OK >> GO TO 2.

NG >> GO TO 3.

# 2. CHECK OVERALL FUNCTION-II

Check indicator in the heat up switch under the following condition.

CONDITION	INDICATION
Heat up switch: OFF	OFF
Heat up switch: ON	ON

### OK or NG

OK >> INSPECTION END

NG >> GO TO 7.


# 3. CHECK HEAT UP SWITCH POWER SUPPLY CIRCUIT

- Turn heat up switch OFF.
- 2. Turn ignition switch OFF.

## **HEAT UP SWITCH**

### < SERVICE INFORMATION >

- Disconnect heat up switch (1) harness connector.
- Turn ignition switch ON.




Check voltage between heat up switch terminal 6 and ground with CONSULT-III or tester.

# ED CON MIT

### Voltage: Battery voltage

### OK or NG

OK >> GO TO 5. NG >> GO TO 4.



# 4. DETECT MALFUNCTIONING PART

Check the following.

- 10 A fuse (No. 11)
- Harness connectors M7, N2
- · Harness for open or short between heat up switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 5.CHECK HEAT UP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 13 and heat up switch terminal 5. Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 8. NG >> GO TO 6.

# **6.** DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors N2, M7
- Harness for open or short between ECM and heat up switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 7.check heat up switch indicator ground circuit for open and short

Check harness continuity between heat up switch terminal 4 and ground. Refer to Wiring Diagram.

### Continuity should exist.

Also check harness for short to power.

Α

Е

E

K

M

Ν

Ρ

probadordemodulos@gmail.com

### < SERVICE INFORMATION >

### OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to power in harness or connectors.

# 8.CHECK HEAT UP SWITCH

Refer to EC-284, "Component Inspection".

### OK or NG

OK >> GO TO 9.

NG >> Replace heat up switch.

9. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

### >> INSPECTION END

## Component Inspection


INFOID:0000000003759815

### **HEAT UP SWITCH**

- 1. Turn ignition switch OFF.
- 2. Disconnect heat up switch harness connector.
- 3. Check continuity between heat up switch terminals 5 and 6 under the following conditions.

CONDITION	CONTINUITY	
Heat up switch: OFF	Should not exist	
Heat up switch: ON	Should exist	


4. If NG, replace heat up switch. If OK, go to following step.



Check continuity between heat up switch terminals 4 and 6 under the following conditions.

CONDITION	CONTINUITY	
Heat up switch: OFF	Should not exist	
Heat up switch: ON	Should exist	

6. If NG, replace heat up switch.




JMBIA1427ZZ

# **BRAKE SWITCH**

Description INFOID:000000003759825

### STOP LAMP SWITCH

The stop lamp switch (1) is installed to brake pedal bracket. The switch senses brake pedal position and sends an ON-OFF signal to the ECM. The ECM uses the signal to control the fuel injection control system.



## CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW	Ignition switch: ON	Brake pedal: Fully released	OFF
(Stop lamp switch)	- Ignition switch. Oil	Brake pedal: Slightly depressed	ON

EC

Α

С

D

Е

INFOID:0000000003759826

G

Н

M


Ν


 $\cup$ 


Wiring Diagram

INFOID:0000000003759827

## EC-BRK/SW-01







GEC620A

Specification data are reference values and are measured between each terminal and ground.

### **BRAKE SWITCH**

· Brake pedal: Slightly depressed

### < SERVICE INFORMATION >

TERMINAL NO.

(Wire color)

100

(GY)

Condition	Value (Approx.)	Α
[Ignition switch OFF] • Brake pedal: Fully released	Approximately 0 V	EC
[Ignition switch OFF]	BATTERY VOLTAGE	

(11 - 14 V)

# Diagnosis Procedure

114

(B)

INFOID:0000000003759828

[YD25DDTi]

# 1. CHECK OVERALL FUNCTION

# (III) With CONSULT-III

- Turn ignition switch ON.
- Select "BRAKE SW" in "DATA MONITOR" mode with CONSULT-III.
- Check "BRAKE SW" indication under the following conditions.

Description

Signal name

Stop lamp switch

CONDITION	INDICATION
Brake pedal: Fully released	OFF
Brake pedal: Slightly depressed	ON

# Without CONSULT-III

Check voltage between ECM harness connector terminals as follows.

+		-		Condition		Voltage
Connector	Terminal	Connector	Terminal	Condition		vollage
			1		Slightly de-	Battery voltage
M33	100	M32	2	Brake pedal	pressed	Battery voltage
			3		Fully released	Approx 0.V
		M33	114		i ully released	Approx. 0 V


### OK or NG

OK >> INSPECTION END

NG >> GO TO 2.

# 2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect stop lamp switch (2) harness connector.



D

Е

Н

K

M

Ν


### < SERVICE INFORMATION >

Check voltage between stop lamp switch terminal 1 and ground with CONSULT-III or tester.

# Voltage: Battery voltage

### OK or NG

OK >> GO TO 4. NG >> GO TO 3.



# 3. DETECT MALFUNCTIONING PART

Check the following.

- 10 A fuse (No. 2)
- · Harness for open or short between stop lamp switch and battery
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

## 4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 100 and stop lamp switch terminal 2. Refer to Wiring Diagram.

### Continuity should exist.

3. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

## 5. CHECK STOP LAMP SWITCH

Refer to EC-288, "Component Inspection".

### OK or NG

OK >> GO TO 6.

NG >> Replace stop lamp switch.

### O.CHECK INTERMITTENT INCIDENT

Refer to EC-70.

#### >> INSPECTION END

## Component Inspection


INFOID:0000000003759829

### STOP LAMP SWITCH

- 1. Disconnect stop lamp switch harness connector.
- Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Condition	Continuity
Brake pedal: Fully released	Should not exist
Brake pedal: Slightly depressed	Should exist

If NG, adjust stop lamp switch installation, refer to "BREAKE PEDAL AND BRACKET" in BR section, and perform step 2 again.



JMBIA1429ZZ

INFOID:0000000003759831

# PNP SWITCH

Description INFOID:0000000003759830

When the gear position is in Neutral, park/neutral position is ON. ECM detects the position because the continuity of the line (the "ON" signal) exists.

# EC

## CONSULT-III Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	• Ignition switch: ON	Shift lever: Neutral position	ON
F/N F 031 3W	Ignition switch: ON	Shift lever: Except above	OFF

Α

C

Е

D

F

G

Н


K

M

Ν

0

Wiring Diagram



GEC630A

Specification data are reference values and are measured between each terminal and ground.

### < SERVICE INFORMATION >

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)	
+		Signal name		(Арргох.)	
110	110 114 Park/neutral position switch		[Ignition switch ON] • Shift lever: Neutral	Approximately 0 V	
(BR)	(B)	r anvineuti ai position switch	[Ignition switch ON] • Except the above position	BATTERY VOLTAGE (11 - 14 V)	

## Diagnosis Procedure

INFOID:0000000003759833

[YD25DDTi]

# 1. CHECK OVERALL FUNCTION

### **⋓** With CONSULT-III

Turn ignition switch ON.

- Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-III. Check "P/N POSI SW" signal under the following conditions.

Shift lever position	P/N POSI SW
Neutral position	ON
Except the above position	OFF

## Without CONSULT-III

Turn ignition switch ON.

Check voltage between ECM harness connector terminals as follows.

+		-		Condition		Voltage
Connector	Terminal	Connector	Terminal	Contailon		Voltage
M33		M32	1	Shift lever	Neutral	Approx. 0 V  BATTERY VOLTAGE
	110		2			
	110		3	Shirt level	Event shove	
		M33	114		Except above	DATTERT VOLIAGE

### OK or NG

OK >> INSPECTION END

NG >> GO TO 2.

# 2.CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch OFF.
- Disconnect park/neutral position (PNP) switch (1) harness connector (2).

 $\Diamond$ : Vehicle front

Check harness continuity between PNP switch terminal 2 and

Refer to Wiring Diagram.


## Continuity should exist.

4. Also check harness for short to power.

#### OK or NG

>> GO TO 4. OK >> GO TO 3. NG

3. DETECT MALFUNCTIONING PART



Α

EC

Е

Н

M

Ν

0

Р

http://probadordemodulos.wix.com/probadorautomotriz

probadordemodulos@gmail.com

Check the following.

- Harness connectors E249, E88
- · Harness for open or short between PNP switch and ground
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

# 4. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 110 and PNP switch terminal 1. Refer to Wiring Diagram.

### Continuity should exist.

3. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 6. NG >> GO TO 5.

## 5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M285, E254
- · Harness for open or short between PNP switch and ECM
  - >> Repair open circuit or short to ground or short to power in harness or connectors.

## 6. CHECK PARK/NEUTRAL POSITION SWITCH

Refer to "ON-VEHICLE SERVICE" in MT section.

### OK or NG

OK >> GO TO 7.

NG >> Replace park/neutral position switch.

# 7. CHECK INTERMITTENT INCIDENT

Refer to EC-70.


#### >> INSPECTION END

# START SIGNAL

Wiring Diagram

INFOID:0000000003759834

Α



GEC631A

TERMINAL NO. (Wire color)		Description	Condition	Value (Approx.)	
+	-	Signal name		(Approx.)	
99 114 (R) (B) Start signal		[Ignition switch ON]	Approximately 0 V		
	Start signal	[Ignition switch START]	BATTERY VOLTAGE (11 - 14 V)		

<sup>★:</sup> Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## Diagnosis Procedure

INFOID:0000000003759835

# 1. CHECK START SIGNAL OVERALL FUNCTION

# With CONSULT-III

- 1. Turn ignition switch ON.
- 2. Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-III under the following conditions.

Condition	START SIGNAL
Ignition switch: ON	OFF
Ignition switch: START	ON

## **®** Without CONSULT-III

Check voltage between ECM harness connector terminals as follows.

ECM						
+		_	Condition		Voltage	
Connector	Terminal	Connector	Terminal			1
		M32	1	Ignition switch	ON	Approx. 0 V
M33	00		2			
IVISS	99		3	- Ignition switch	START	Pottory voltage
		M33	114		SIARI	Battery voltage

### OK or NG

OK >> INSPECTION END

NG >> GO TO 2.

# 2.CHECK START SIGNAL INPUT SIGNAL CIRCUIT

- Turn ignition switch OFF.
- 2. Disconnect ECM harness connector and ignition switch harness connector.
- Check harness continuity between ECM terminal 99 and ignition switch terminal 6. Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 4. NG >> GO TO 3.

# 3. DETECT MALFUNCTIONING PART

Check the following.

- 10 A fuse (No. 20)
- 40 A fusible link (letter f)
- Harness connectors E101, M5
- Fuse block (J/B) connectors M12

htlgn/forbaidordemosuros.wix.com/probadorautomotriz

probadordemodulos@gmail.com

## **START SIGNAL**

< SERVICE INFORMATION > [YD25DDTi]

• Harness for open or short between ECM and fusible link

>> Repair open circuit or short to ground or short to power in harness or connectors.

# 4. CHECK INTERMITTENT INCIDENT

Refer to EC-70.

>> INSPECTION END

D

C

Α

Е

F

G

Η

Κ

L


M


Ν

 $\circ$ 

# MI & DATA LINK CONNECTORS

Wiring Diagram





GEC632A


Α

C

Е

L

## EC-MIL/DL-02



GEC633A

# SERVICE DATA AND SPECIFICATIONS (SDS)

# **General Specification**

INFOID:0000000003759845

Target idle speed No load* (in Neutral position)		750 ± 25 rpm	
Air conditioner: ON	In Neutral position	800 rpm or more	
Maximum engine speed	4,900 rpm		

<sup>\*:</sup> Under the following conditions:

- · Heat up switch: OFF
- · Air conditioner switch: OFF
- Electric load: OFF (Lights & heater fan)
- · Steering wheel: Kept in straight-ahead position

## Mass Air Flow Sensor

INFOID:0000000003759846

Supply voltage	Battery voltage (11 - 14 V)		
Ignition switch ON (Engine stopped.)	Approx. 0.4 V (CONSULT-III DATA MONITOR) Approx. 0.7 V (ECM terminal 54 and ground)		
Idle (Engine is warmed up to normal operating temperature.)	1.3 - 1.8 V* (CONSULT-III DATA MONITOR) 1.7 - 2.1 V* (ECM terminal 54 and ground)		

<sup>\*:</sup> Engine is warmed up to normal operating temperature and running under no load.

## Intake Air Temperature Sensor

INFOID:0000000003759847

Temperature [°C (°F)]	Resistance (k $\Omega$ )	
25 (77)	1.800 - 2.200	
80 (176)	0.283 - 0.359	

# **Engine Coolant Temperature Sensor**

INFOID:0000000003759848

Temperature [°C (°F)]	Resistance (k $\Omega$ )	
20 (68)	2.1 - 2.9	
50 (122)	0.68 - 1.00	
90 (194)	0.236 - 0.260	

## Fuel Rail Pressure Sensor

INFOID:0000000003759850

Supply voltage	Approximately 5 V
Idle (Engine is warmed up to normal operating temperature.)	1.7 - 2.0 V
2,000 rpm (Engine is warmed up to normal operating temperature.)	2.0 - 2.3 V

Fuel Injector

Resistance [at 10 - 60°C (50 - 140°F)] 0.2 - 0.8 Ω

## Crankshaft Position Sensor

INFOID:0000000003759852

Refer to EC-156, "Component Inspection".

# **SERVICE DATA AND SPECIFICATIONS (SDS)**

< SERVICE INFORMATION >	IND SPECIFIC	ATIONS (SDS)	[YD25DDTi]	
Camshaft Position Sensor			INFOID:000000003759853	
Refer to EC-166, "Component Inspection".  Glow Plug			INFOID:000000003759854 EC	
Resistance [at 25°C (77°F)] Fuel Pump		Approximately 0.8 $\Omega$	INFOID:0000000003759857	
Resistance [at 10 - 60°C (50 - 140°F)]		1.5 - 3.0 Ω	D	
			Е	
			F	
			G	
			Н	
			I	
			J	
			K	
			L	
			М	
			N	
			0	
			D	